

# WSM

---

**WORKSHOP MANUAL**  
**DIESEL ENGINE**

**03-M-E3B SERIES,**  
**03-M-DI-E3B SERIES,**  
**03-M-E3BG SERIES**

---

**Kubota**

# TO THE READER

This Workshop Manual tells the servicing personnel about the mechanism, servicing and maintenance of the 03-M-E3B, the 03-M-DI-E3B and the 03-M-E3BG series. It contains 4 parts: "**Information**", "**General**", "**Mechanism**" and "**Servicing**".

## ■ **Information**

This section contains information below.

- Safety First
- Specification
- Dimensions
- Wiring Diagram

## ■ **General**

This section contains information below.

- Engine Identification
- General Precautions
- Maintenance Check List
- Check and Maintenance
- Special Tools

## ■ **Mechanism**

This section contains information on the structure and the function of the unit. Before you continue with the subsequent sections, make sure that you read this section.

Refer to Workshop Manual (Code No. 9Y021-01870) for the diesel engine mechanism that this workshop manual does not include.

## ■ **Servicing**

This section contains information below.

- Troubleshooting
- Servicing Specifications
- Tightening Torques
- Checking, Disassembling and Servicing

All illustrations, photographs and specifications contained in this manual are of the newest information available at the time of publication.

KUBOTA reserves the right to change all information at any time without notice.

Since this manual includes many models, information or illustrations and photographs can show more than one model.

**January, 2009**

© **KUBOTA Corporation 2009**

## **Record of Revisions**

For pdf, use search function {Search word} to find all the revised locations.

| <b>Last digit of the Code No.</b> | <b>Issue month</b> | <b>Main Revised Point and Corrective Measures {Search word}</b>  | <b>Reference Page</b>                                |
|-----------------------------------|--------------------|--|--|
| <b>3</b>                          | 2013.04            | 2. SPECIFICATION<br>[1] MODEL NAME AND OLD ENGINE SERIAL NUMBER<br>[2] MODEL NAME AND NEW ENGINE SERIAL NUMBER<br>Battery Specific Gravity<br>Battery Specific Gravity<br>Replacement of Valve Guide | I-10 to I-14<br>G-1<br>G-2<br>G-26<br>1-S39<br>1-S81 |
| <b>4</b>                          | 2014.07            | ELECTRONIC GOVERNOR<br>Blinking Pattern of Glow Lamp   | 1-S9   |

# **I INFORMATION**

# INFORMATION

## CONTENTS

- 1. SAFETY FIRST ..... I-1
- 2. SPECIFICATION ..... I-4
- 3. DIMENSIONS ..... I-15
- 4. WIRING DIAGRAM..... I-21

# 1. SAFETY FIRST

## SAFETY FIRST

- This symbol, the industry's "Safety Alert Symbol", is used throughout this manual and on labels on the machine itself to warn of the possibility of personal injury. Read these instructions carefully.
- It is essential that you read the instructions and safety regulations before you attempt to repair or use this unit.

### DANGER

- Indicates an imminently hazardous situation which, if not avoided, will result in death or serious injury.

### WARNING

- Indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.

### CAUTION

- Indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury.


### ■ IMPORTANT

- Indicates that equipment or property damage could result if instructions are not followed.

### ■ NOTE

- Gives helpful information.

M0000003INI0001US1



IBM001A

### BEFORE YOU START SERVICE

- Read all instructions and safety instructions in this manual and on your engine safety decals.
- Clean the work area and engine.
- Park the machine on a stable and level ground.
- Let the temperature of the engine decrease before you start a job.
- Stop the engine, then remove the key.
- Disconnect the battery negative cable.
- Hang a "**DO NOT OPERATE**" tag in the operator station.

M0000003INI0002US1







IBM011A

### START SAFELY

- Do not do the procedures below when you start the engine.
  - short across starter terminals
  - bypass the safety start switch
- Do not make unauthorized modifications to the engine. This can cause damage and decrease the engine life.

M0000003INI0003US1



### OPERATE SAFELY


- Do not use the machine after you consume alcohol or medication or when you are tired.
- Put on applicable clothing and safety equipment.
- Use applicable tools only. Do not use alternative tools or parts.
- When 2 or more persons do servicing, make sure that you do it safely.
- Do not touch the hot parts or parts that turn when the engine operates.
- Do not remove the radiator cap when the engine operates, or immediately after it stops. If not, hot water can spout out from the radiator. Only remove the radiator cap when it is at a sufficiently low temperature to touch with bare hands. Slowly loosen the cap to release the pressure before you remove it fully.
- Released fluid (fuel or hydraulic oil) under pressure can cause damage to the skin and cause serious injury. Release the pressure before you disconnect hydraulic or fuel lines. Tighten all connections before you apply the pressure.
- Do not open a fuel system under high pressure. The fluid under high pressure that stays in fuel lines can cause serious injury. Do not disconnect or repair the fuel lines, sensors, or any other components between the fuel pump and injectors on engines with a common rail fuel system under high pressure.
- Put on an applicable ear protective device (earmuffs or earplugs) to prevent injury against loud noises.
- Be careful about electric shock. The engine generates a high voltage of more than DC100 V in the ECU and is applied to the injector.

M0000003INI0004US1

### PREVENT A FIRE

- Fuel is very flammable and explosive under some conditions. Do not smoke or let flames or sparks in your work area.
- To prevent sparks from an accidental short circuit, always disconnect the battery negative cable first and connect it last.
- The battery gas can cause an explosion. Keep the sparks and open flame away from the top of battery, especially when you charge the battery.
- Make sure that you do not spill fuel on the engine.

M0000003INI0005US1



IBM007A

**KEEP A GOOD AIRFLOW IN THE WORK AREA**

- If the engine is in operation, make sure that the area has good airflow. Do not operate the engine in a closed area. The exhaust gas contains poisonous carbon monoxide.

M00000003INI0006US1




IBM009A

**DISCARD FLUIDS CORRECTLY**

- Do not discard fluids on the ground, down the drain, into a stream, pond, or lake. Obey related environmental protection regulations when you discard oil, fuel, coolant, electrolyte and other dangerous waste.

M00000003INI0007US1



IBM008A

**PREVENT ACID BURNS**

- Keep electrolyte away from your eyes, hands and clothing. Sulfuric acid in battery electrolyte is poisonous and it can burn your skin and clothing and cause blindness. If you spill electrolyte on yourself, clean yourself with water, and get medical aid immediately.

M00000003INI0008US1



IBM010A

**PREPARE FOR EMERGENCIES**

- Keep a first aid kit and fire extinguisher ready at all times.
- Keep the emergency contact telephone numbers near your telephone at all times.

M00000003INI0009US1

## 2. SPECIFICATION

| Model                     |                                    | D1503-M  | D1703-M  |
|---------------------------|------------------------------------|--|--|
| Number of Cylinders       |                                    | 3  |  |
| Type                      |                                    | Vertical, Water-cooled, 4 cycle diesel engine  |  |
| Bore × Stroke             |                                    | 83.0 × 92.4 mm (3.27 × 3.64 in.)   | 87.0 × 92.4 mm (3.43 × 3.64 in.)   |
| Total Displacement        |                                    | 1499 cm <sup>3</sup> (91.47 cu.in.)  | 1647 cm <sup>3</sup> (100.5 cu.in.)  |
| ISO Net Continuous        |                                    | 19.5 kW / 2800 min <sup>-1</sup> (rpm)<br>(26.1 HP / 2800 min <sup>-1</sup> (rpm))   | 21.2 kW / 2800 min <sup>-1</sup> (rpm)<br>(28.4 HP / 2800 min <sup>-1</sup> (rpm)) |
| ISO/SAE Net Intermittent  |                                    | 22.4 kW / 2800 min <sup>-1</sup> (rpm)<br>(30.0 HP / 2800 min <sup>-1</sup> (rpm))   | 24.4 kW / 2800 min <sup>-1</sup> (rpm)<br>(32.7 HP / 2800 min <sup>-1</sup> (rpm)) |
| SAE Gross Intermittent    |                                    | 23.8 kW / 2800 min <sup>-1</sup> (rpm)<br>(31.9 HP / 2800min <sup>-1</sup> (rpm))  | 26.1 kW / 2800 min <sup>-1</sup> (rpm)<br>(35.0 HP / 2800 min <sup>-1</sup> (rpm)) |
| Maximum Bare Speed        |                                    | 3020 min <sup>-1</sup> (rpm)   |  |
| Minimum Bare Idling Speed |                                    | 750 to 850 min <sup>-1</sup> (rpm)   |  |
| Combustion Chamber        |                                    | Spherical Type (E-TVCS)  |  |
| Fuel Injection Pump       |                                    | PFR 3M Type Mini Pump (DENSO)  |  |
| Governor                  |                                    | Mechanical all speed governor  |  |
| Direction of Rotation     |                                    | Counter-clockwise (viewed from flywheel side)  |  |
| Injection Nozzle          |                                    | OPD Mini Nozzle (DENSO)  |  |
| Injection Timing          |                                    | 0.2662 rad (15.25 °) before T.D.C.   | 0.2836 rad (16.25 °) before T.D.C.   |
| Firing Order              |                                    | 1-2-3  |  |
| Injection Pressure        |                                    | 13.73 MPa (140.0 kgf/cm <sup>2</sup> , 1991 psi)   |  |
| Compression Ratio         |                                    | 22.8 : 1   | 22.0 : 1   |
| Lubricating System        |                                    | Forced Lubrication by Trochoid Pump  |  |
| Oil Pressure Indicating   |                                    | Electrical type switch   |  |
| Lubricating Filter        |                                    | Full flow paper filter (cartridge type)  |  |
| Cooling System            |                                    | Pressurized radiator, forced circulation with water pump   |  |
| Starting System           |                                    | Electric Starting with Starter   |  |
| Starting Motor            |                                    | 12 V, 1.2 kW   |  |
| Starting Support Device   |                                    | By glow plug in combustion chamber   |  |
| EGR                       |                                    | NONE   |  |
| Battery                   |                                    | 12 V, 60 AH equivalent   |  |
| Charging Alternator       |                                    | 12 V, 360 W  |  |
| Fuel                      |                                    | Diesel Fuel No.2-D (ASTM D975)   |  |
| Lubricating Oil           |                                    | Class CF lubricating oil as per API classification is recommended.<br>For details on recommended lubricating oils, see page G-8, G-11. |  |
| Lubricating Oil Capacity  | Oil Pan Depth<br>90 mm (3.5 in.)   | 5.6 L (1.5 U.S.gals)   |  |
|                           | Oil Pan Depth<br>124 mm (4.88 in.) | 7.0 L (1.8 U.S.gals)   |  |
| Weight (Dry)              |                                    | 148 kg (326 lbs)   |  |

\*The specification described above is of the standard engine of each model.

\*Conversion Formula : HP = 0.746 kW, PS = 0.7355 kW

M00000003INI0010US1

| Model                     |                                    | D1803-M  |
|---------------------------|------------------------------------|--|
| Number of Cylinders       |                                    | 3  |
| Type                      |                                    | Vertical, Water-cooled, 4 cycle diesel engine  |
| Bore × Stroke             |                                    | 87.0 × 102.4 mm (3.43 × 4.031 in.)   |
| Total Displacement        |                                    | 1826 cm <sup>3</sup> (111.4 cu.in.)  |
| ISO Net Continuous        |                                    | 22.8 kW / 2700 min <sup>-1</sup> (rpm)<br>(30.6 HP / 2700 min <sup>-1</sup> (rpm))   |
| ISO/SAE Net Intermittent  |                                    | 26.3 kW / 2700 min <sup>-1</sup> (rpm)<br>(35.3 HP / 2700 min <sup>-1</sup> (rpm))   |
| SAE Gross Intermittent    |                                    | 27.9 kW / 2700 min <sup>-1</sup> (rpm)<br>(37.4 HP / 2700 min <sup>-1</sup> (rpm))   |
| Maximum Bare Speed        |                                    | 3020 min <sup>-1</sup> (rpm)   |
| Minimum Bare Idling Speed |                                    | 750 to 850 min <sup>-1</sup> (rpm)   |
| Combustion Chamber        |                                    | Spherical Type (E-TVCS)  |
| Fuel Injection Pump       |                                    | PFR 3M Type Mini Pump (DENSO)  |
| Governor                  |                                    | Mechanical all speed governor  |
| Direction of Rotation     |                                    | Counter-clockwise (viewed from flywheel side)  |
| Injection Nozzle          |                                    | OPD Mini Nozzle (DENSO)  |
| Injection Timing          |                                    | 0.2836 rad (16.25 °) before T.D.C.   |
| Firing Order              |                                    | 1-2-3  |
| Injection Pressure        |                                    | 13.73 MPa (140.0 kgf/cm <sup>2</sup> , 1991 psi)   |
| Compression Ratio         |                                    | 24.3 : 1   |
| Lubricating System        |                                    | Forced Lubrication by Trochoid Pump  |
| Oil Pressure Indicating   |                                    | Electrical type switch   |
| Lubricating Filter        |                                    | Full flow paper filter (cartridge type)  |
| Cooling System            |                                    | Pressurized radiator, forced circulation with water pump   |
| Starting System           |                                    | Electric Starting with Starter   |
| Starting Motor            |                                    | 12 V, 2.0 kW   |
| Starting Support Device   |                                    | By glow plug in combustion chamber   |
| EGR                       |                                    | NONE   |
| Battery                   |                                    | 12 V, 92 AH equivalent   |
| Charging Alternator       |                                    | 12 V, 360 W  |
| Fuel                      |                                    | Diesel Fuel No.2-D (ASTM D975)   |
| Lubricating Oil           |                                    | Class CF lubricating oil as per API classification is recommended.<br>For details on recommended lubricating oils, see page G-8, G-11. |
| Lubricating Oil Capacity  | Oil Pan Depth<br>90 mm (3.5 in.)   | 5.6 L (1.5 U.S.gals)   |
|                           | Oil Pan Depth<br>124 mm (4.88 in.) | 7.0 L (1.8 U.S.gals)   |
| Weight (Dry)              |                                    | 151 kg (333 lbs)   |

\*The specification described above is of the standard engine of each model.

\*Conversion Formula : HP = 0.746 kW, PS = 0.7355 kW

M00000003INI0011US1

| Model                     |                                    | V2003-M  | V2203-M  |
|---------------------------|------------------------------------|--|--|
| Number of Cylinders       |                                    | 4  |  |
| Type                      |                                    | Vertical, Water-cooled, 4 cycle diesel engine  |  |
| Bore × Stroke             |                                    | 83.0 × 92.4 mm (3.27 × 3.64 in.)   | 87.0 × 92.4 mm (3.43 × 3.64 in.)   |
| Total Displacement        |                                    | 1999 cm <sup>3</sup> (122.0 cu.in.)  | 2197 cm <sup>3</sup> (134.1 cu.in.)  |
| ISO Net Continuous        |                                    | 26.7 kW / 2800 min <sup>-1</sup> (rpm)<br>(35.8 HP / 2800 min <sup>-1</sup> (rpm))   | 29.6 kW / 2800 min <sup>-1</sup> (rpm)<br>(39.7 HP / 2800 min <sup>-1</sup> (rpm)) |
| ISO/SAE Net Intermittent  |                                    | 30.8 kW / 2800 min <sup>-1</sup> (rpm)<br>(41.3 HP / 2800 min <sup>-1</sup> (rpm))   | 34.1 kW / 2800 min <sup>-1</sup> (rpm)<br>(45.7 HP / 2800 min <sup>-1</sup> (rpm)) |
| SAE Gross Intermittent    |                                    | 32.6 kW / 2800 min <sup>-1</sup> (rpm)<br>(43.7 HP / 2800 min <sup>-1</sup> (rpm))   | 35.9 kW / 2800 min <sup>-1</sup> (rpm)<br>(48.1 HP / 2800 min <sup>-1</sup> (rpm)) |
| Maximum Bare Speed        |                                    | 3020 min <sup>-1</sup> (rpm)   |  |
| Minimum Bare Idling Speed |                                    | 750 to 850 min <sup>-1</sup> (rpm)   |  |
| Combustion Chamber        |                                    | Spherical Type (E-TVCS)  |  |
| Fuel Injection Pump       |                                    | PFR 4M Type Mini Pump (DENSO)  |  |
| Governor                  |                                    | Mechanical all speed governor  |  |
| Direction of Rotation     |                                    | Counter-clockwise (viewed from flywheel side)  |  |
| Injection Nozzle          |                                    | OPD Mini Nozzle (DENSO)  |  |
| Injection Timing          |                                    | 0.2836 rad (16.25 °) before T.D.C.   |  |
| Firing Order              |                                    | 1-3-4-2  |  |
| Injection Pressure        |                                    | 13.73 MPa (140.0 kgf/cm <sup>2</sup> , 1991 psi)   |  |
| Compression Ratio         |                                    | 22.8 : 1   | 22.0 : 1   |
| Lubricating System        |                                    | Forced Lubrication by Trochoid Pump  |  |
| Oil Pressure Indicating   |                                    | Electrical type switch   |  |
| Lubricating Filter        |                                    | Full flow paper filter (cartridge type)  |  |
| Cooling System            |                                    | Pressurized radiator, forced circulation with water pump   |  |
| Starting System           |                                    | Electric Starting with Starter   |  |
| Starting Motor            |                                    | 12 V, 1.4 kW   |  |
| Starting Support Device   |                                    | By glow plug in combustion chamber   |  |
| EGR                       |                                    | NONE   |  |
| Battery                   |                                    | 12 V, 88 AH equivalent   |  |
| Charging Alternator       |                                    | 12 V, 480 W  |  |
| Fuel                      |                                    | Diesel Fuel No.2-D (ASTM D975)   |  |
| Lubricating Oil           |                                    | Class CF lubricating oil as per API classification is recommended.<br>For details on recommended lubricating oils, see page G-8, G-11. |  |
| Lubricating Oil Capacity  | Oil Pan Depth<br>90 mm (3.5 in.)   | 7.6 L (2.0 U.S.gals)   |  |
|                           | Oil Pan Depth<br>124 mm (4.88 in.) | 9.5 L (2.5 U.S.gals)   |  |
| Weight (Dry)              |                                    | 180 kg (397 lbs)   |  |

\*The specification described above is of the standard engine of each model.

\*Conversion Formula : HP = 0.746 kW, PS = 0.7355 kW

M00000003INI0012US1

| Model                     |                                    | V2403-M  | V2403-M-T  |
|---------------------------|------------------------------------|--|--|
| Number of Cylinders       |                                    | 4  |  |
| Type                      |                                    | Vertical, Water-cooled, 4 cycle diesel engine  |  |
| Bore × Stroke             |                                    | 87.0 × 102.4 mm (3.43 × 4.031 in.)   |  |
| Total Displacement        |                                    | 2434 cm <sup>3</sup> (148.5 cu.in.)  |  |
| ISO Net Continuous        |                                    | 30.2 kW / 2700 min <sup>-1</sup> (rpm)<br>(40.5 HP / 2700 min <sup>-1</sup> (rpm))   | 36.4 kW / 2700 min <sup>-1</sup> (rpm)<br>(48.8 HP / 2700 min <sup>-1</sup> (rpm)) |
| ISO/SAE Net Intermittent  |                                    | 34.8 kW / 2700 min <sup>-1</sup> (rpm)<br>(46.7 HP / 2700 min <sup>-1</sup> (rpm))   | 41.9 kW / 2700 min <sup>-1</sup> (rpm)<br>(56.2 HP / 2700 min <sup>-1</sup> (rpm)) |
| SAE Gross Intermittent    |                                    | 36.5 kW / 2700 min <sup>-1</sup> (rpm)<br>(48.9 HP / 2700 min <sup>-1</sup> (rpm))   | 44.0 kW / 2700 min <sup>-1</sup> (rpm)<br>(59.0 HP / 2700 min <sup>-1</sup> (rpm)) |
| Maximum Bare Speed        |                                    | 3020 min <sup>-1</sup> (rpm)   | 2950 min <sup>-1</sup> (rpm)   |
| Minimum Bare Idling Speed |                                    | 750 to 850 min <sup>-1</sup> (rpm)   | 750 min <sup>-1</sup> (rpm)  |
| Combustion Chamber        |                                    | Spherical Type (E-TVCS)  |  |
| Fuel Injection Pump       |                                    | PFR 4M Type Mini Pump (DENSO)  |  |
| Governor                  |                                    | Mechanical all speed governor  |  |
| Direction of Rotation     |                                    | Counter-clockwise (viewed from flywheel side)  |  |
| Injection Nozzle          |                                    | OPD Mini Nozzle (DENSO)  |  |
| Injection Timing          |                                    | 0.2836 rad (16.25 °) before T.D.C.   | 0.14 rad (8.3 °) before T.D.C.   |
| Firing Order              |                                    | 1-3-4-2  |  |
| Injection Pressure        |                                    | 13.73 MPa (140.0 kgf/cm <sup>2</sup> , 1991 psi)   |  |
| Compression Ratio         |                                    | 23.2 : 1   | 23.0 : 1   |
| Lubricating System        |                                    | Forced Lubrication by Trochoid Pump  |  |
| Oil Pressure Indicating   |                                    | Electrical type switch   |  |
| Lubricating Filter        |                                    | Full flow paper filter (cartridge type)  |  |
| Cooling System            |                                    | Pressurized radiator, forced circulation with water pump   |  |
| Starting System           |                                    | Electric Starting with Starter   |  |
| Starting Motor            |                                    | 12 V, 2.0 kW   |  |
| Starting Support Device   |                                    | By glow plug in combustion chamber   |  |
| EGR                       |                                    | NONE   |  |
| Battery                   |                                    | 12 V, 92 AH equivalent   |  |
| Charging Alternator       |                                    | 12 V, 480 W  |  |
| Fuel                      |                                    | Diesel Fuel No.2-D (ASTM D975)   |  |
| Lubricating Oil           |                                    | Class CF lubricating oil as per API classification is recommended.<br>For details on recommended lubricating oils, see page G-8, G-11. |  |
| Lubricating Oil Capacity  | Oil Pan Depth<br>90 mm (3.5 in.)   | 7.6 L (2.0 U.S.gals)   | -  |
|                           | Oil Pan Depth<br>124 mm (4.88 in.) | 9.5 L (2.5 U.S.gals)   |  |
| Weight (Dry)              |                                    | 184 kg (406 lbs)   | 190 kg (419 lbs)   |

\*The specification described above is of the standard engine of each model.

\*Conversion Formula : HP = 0.746 kW, PS = 0.7355 kW

M00000003INI0013US1

| Model                     |                                    | D1803-M-DI   |
|---------------------------|------------------------------------|--|
| Number of Cylinders       |                                    | 3  |
| Type                      |                                    | Vertical, Water-cooled, 4 cycle diesel engine  |
| Bore × Stroke             |                                    | 87.0 × 102.4 mm (3.43 × 4.031 in.)   |
| Total Displacement        |                                    | 1826 cm <sup>3</sup> (111.4 cu.in.)  |
| ISO Net Continuous        |                                    | 23.2 kW / 2700 min <sup>-1</sup> (rpm)<br>(31.1 HP / 2700 min <sup>-1</sup> (rpm))   |
| ISO/SAE Net Intermittent  |                                    | 26.7 kW / 2700 min <sup>-1</sup> (rpm)<br>(35.8 HP / 2700 min <sup>-1</sup> (rpm))   |
| SAE Gross Intermittent    |                                    | 27.9 kW / 2700 min <sup>-1</sup> (rpm)<br>(37.4 HP / 2700 min <sup>-1</sup> (rpm))   |
| Maximum Bare Speed        |                                    | 2920 min <sup>-1</sup> (rpm)   |
| Minimum Bare Idling Speed |                                    | 850 to 950 min <sup>-1</sup> (rpm)   |
| Combustion Chamber        |                                    | Reentrant Type (Direct Injection)  |
| Fuel Injection Pump       |                                    | Bosch "K" Type Mini Pump   |
| Governor                  |                                    | Mechanical all speed governor  |
| Direction of Rotation     |                                    | Counter-clockwise (viewed from flywheel side)  |
| Injection Nozzle          |                                    | Bosch "P" Type Hole Nozzle   |
| Injection Timing          |                                    | 0.087 rad (5.0 °) before T.D.C.  |
| Firing Order              |                                    | 1-2-3  |
| Injection Pressure        | 1st Stage                          | 18.63 MPa (190.0 kgf/cm <sup>2</sup> , 2702 psi)   |
|                           | 2nd Stage                          | 22.56 MPa (230.0 kgf/cm <sup>2</sup> , 3271 psi)   |
| Compression Ratio         |                                    | 20.5 : 1   |
| Lubricating System        |                                    | Forced Lubrication by Trochoid Pump  |
| Oil Pressure Indicating   |                                    | Electrical type switch   |
| Lubricating Filter        |                                    | Full flow paper filter (cartridge type)  |
| Cooling System            |                                    | Pressurized radiator, forced circulation with water pump   |
| Starting System           |                                    | Electric Starting with Starter   |
| Starting Motor            |                                    | 12 V, 1.4 kW   |
| Starting Support Device   |                                    | By glow plug in combustion chamber   |
| EGR                       |                                    | NONE   |
| Battery                   |                                    | 12 V, 88 AH equivalent   |
| Charging Alternator       |                                    | 12 V, 360 W  |
| Fuel                      |                                    | Diesel Fuel No.2-D (ASTM D975)   |
| Lubricating Oil           |                                    | Class CF lubricating oil as per API classification is recommended.<br>For details on recommended lubricating oils, see page G-8, G-11. |
| Lubricating Oil Capacity  | Oil Pan Depth<br>90 mm (3.5 in.)   | 5.6 L (1.5 U.S.gals)   |
|                           | Oil Pan Depth<br>124 mm (4.88 in.) | 7.0 L (1.8 U.S.gals)   |
| Weight (Dry)              |                                    | 151 kg (333 lbs)   |

\*The specification described above is of the standard engine of each model.

\*Conversion Formula : HP = 0.746 kW, PS = 0.7355 kW

M00000003INI0014US1

| Model                     |                                    | V2403-M-DI   | V2403-M-DI-T   |
|---------------------------|------------------------------------|--|--|
| Number of Cylinders       |                                    | 4  |  |
| Type                      |                                    | Vertical, Water-cooled, 4 cycle diesel engine  |  |
| Bore × Stroke             |                                    | 87.0 × 102.4 mm (3.43 × 4.031 in.)   |  |
| Total Displacement        |                                    | 2434 cm <sup>3</sup> (148.5 cu.in.)  |  |
| ISO Net Continuous        |                                    | 30.5 kW / 2700 min <sup>-1</sup> (rpm)<br>(40.9 HP / 2700 min <sup>-1</sup> (rpm))   | 30.7 kW / 2400 min <sup>-1</sup> (rpm)<br>(41.2 HP / 2400 min <sup>-1</sup> (rpm)) |
| ISO/SAE Net Intermittent  |                                    | 35.1 kW / 2700 min <sup>-1</sup> (rpm)<br>(47.1 HP / 2700 min <sup>-1</sup> (rpm))   | 35.3 kW / 2400 min <sup>-1</sup> (rpm)<br>(47.3 HP / 2400 min <sup>-1</sup> (rpm)) |
| SAE Gross Intermittent    |                                    | 36.5 kW / 2700 min <sup>-1</sup> (rpm)<br>(48.9 HP / 2700 min <sup>-1</sup> (rpm))   | 36.5 kW / 2400 min <sup>-1</sup> (rpm)<br>(48.9 HP / 2400 min <sup>-1</sup> (rpm)) |
| Maximum Bare Speed        |                                    | 2920 min <sup>-1</sup> (rpm)   | 2450 min <sup>-1</sup> (rpm)   |
| Minimum Bare Idling Speed |                                    | 850 to 950 min <sup>-1</sup> (rpm)   | 900 min <sup>-1</sup> (rpm)  |
| Combustion Chamber        |                                    | Reentrant Type (Direct Injection)  |  |
| Fuel Injection Pump       |                                    | Bosch "K" Type Mini Pump   |  |
| Governor                  |                                    | Mechanical all speed governor  |  |
| Direction of Rotation     |                                    | Counter-clockwise (viewed from flywheel side)  |  |
| Injection Nozzle          |                                    | Bosch "P" Type Hole Nozzle   |  |
| Injection Timing          |                                    | 0.087 rad (5.0 °) before T.D.C.  | 0.096 rad (5.5 °) before T.D.C.  |
| Firing Order              |                                    | 1-3-4-2  |  |
| Injection Pressure        | 1st Stage                          | 18.63 MPa (190.0 kgf/cm <sup>2</sup> , 2702 psi)   |  |
|                           | 2nd Stage                          | 22.56 MPa (230.0 kgf/cm <sup>2</sup> , 3271 psi)   |  |
| Compression Ratio         |                                    | 20.5 : 1   | 20.2 : 1   |
| Lubricating System        |                                    | Forced Lubrication by Trochoid Pump  |  |
| Oil Pressure Indicating   |                                    | Electrical type switch   |  |
| Lubricating Filter        |                                    | Full flow paper filter (cartridge type)  |  |
| Cooling System            |                                    | Pressurized radiator, forced circulation with water pump   |  |
| Starting System           |                                    | Electric Starting with Starter   |  |
| Starting Motor            |                                    | 12 V, 2.0 kW   |  |
| Starting Support Device   |                                    | By glow plug in combustion chamber   |  |
| EGR                       |                                    | NONE   |  |
| Battery                   |                                    | 12 V, 92 AH equivalent   |  |
| Charging Alternator       |                                    | 12 V, 480 W  |  |
| Fuel                      |                                    | Diesel Fuel No.2-D (ASTM D975)   |  |
| Lubricating Oil           |                                    | Class CF lubricating oil as per API classification is recommended.<br>For details on recommended lubricating oils, see page G-8, G-11. |  |
| Lubricating Oil Capacity  | Oil Pan Depth<br>90 mm (3.5 in.)   | 7.6 L (2.0 U.S.gals)   |  |
|                           | Oil Pan Depth<br>124 mm (4.88 in.) | 9.5 L (2.5 U.S.gals)   |  |
| Weight (Dry)              |                                    | 184 kg (406 lbs)   | 190 kg (416 lbs)   |

\*The specification described above is of the standard engine of each model.

\*Conversion Formula : HP = 0.746 kW, PS = 0.7355 kW

M00000003INI0015US1

| Model                    |                                    | D1703-M-BG   |  |
|--------------------------|------------------------------------|--|--|
| Number of Cylinders      |                                    | 3  |  |
| Type                     |                                    | Vertical, Water-cooled, 4 cycle diesel engine  |  |
| Bore × Stroke            |                                    | 87.0 × 92.4 mm (3.43 × 3.64 in.)   |  |
| Total Displacement       |                                    | 1647 cm <sup>3</sup> (100.5 cu.in.)  |  |
| STANDBY                  | ISO 3046                           | 15.0 kW / 1500 min <sup>-1</sup> (rpm)   | 18.1 kW / 1800 min <sup>-1</sup> (rpm) |
|                          | SAE J-1349                         | 20.1 HP / 1500 min <sup>-1</sup> (rpm)   | 24.3 HP / 1800 min <sup>-1</sup> (rpm) |
| NET Continuous           | ISO 3046                           | 12.8 kW / 1500 min <sup>-1</sup> (rpm)   | 15.1 kW / 1800 min <sup>-1</sup> (rpm) |
|                          | SAE J-1349                         | 17.2 HP / 1500 min <sup>-1</sup> (rpm)   | 20.2 HP / 1800 min <sup>-1</sup> (rpm) |
| Governor Regulation      |                                    | Less than 5%   |  |
| Combustion Chamber       |                                    | Spherical Type (E-TVCS)  |  |
| Fuel Injection Pump      |                                    | PFR 3M Type Mini Pump (DENSO)  |  |
| Governor                 |                                    | Mechanical all speed governor + Electronic Governor  |  |
| Direction of Rotation    |                                    | Counter-clockwise (viewed from flywheel side)  |  |
| Injection Nozzle         |                                    | OPD Mini Nozzle (DENSO)  |  |
| Injection Timing         |                                    | 0.2487 rad (14.25 °) before T.D.C.   |  |
| Firing Order             |                                    | 1-2-3  |  |
| Injection Pressure       |                                    | 13.73 MPa (140.0 kgf/cm <sup>2</sup> , 1991 psi)   |  |
| Compression Ratio        |                                    | 22.0 : 1   |  |
| Lubricating System       |                                    | Forced Lubrication by Trochoid Pump  |  |
| Oil Pressure Indicating  |                                    | Electrical type switch   |  |
| Lubricating Filter       |                                    | Full flow paper filter (cartridge type)  |  |
| Cooling System           |                                    | Pressurized radiator, forced circulation with water pump   |  |
| Starting System          |                                    | Electric Starting with Starter   |  |
| Starting Motor           |                                    | 12 V, 1.4 kW   |  |
| Starting Support Device  |                                    | By glow plug in combustion chamber   |  |
| EGR                      |                                    | NONE   |  |
| Battery                  |                                    | 12 V, 60 AH equivalent   |  |
| Charging Alternator      |                                    | 12 V, 480 W  |  |
| Fuel                     |                                    | Diesel Fuel No.2-D (ASTM D975)   |  |
| Lubricating Oil          |                                    | Class CF lubricating oil as per API classification is recommended.<br>For details on recommended lubricating oils, see page G-8, G-11. |  |
| Lubricating Oil Capacity | Oil Pan Depth<br>90 mm (3.5 in.)   | 5.6 L (1.5 U.S.gals)   |  |
|                          | Oil Pan Depth<br>124 mm (4.88 in.) | 7.0 L (1.8 U.S.gals)   |  |
| Weight (Dry)             |                                    | 164 kg (362 lbs)   |  |

\*The specification described above is of the standard engine of each model.

\*Conversion Formula : HP = 0.746 kW, PS = 0.7355 kW

M0000003INI0020US1

| Model                    |                                    | V2003-M-BG   |  |
|--------------------------|------------------------------------|--|--|
| Number of Cylinders      |                                    | 4  |  |
| Type                     |                                    | Vertical, Water-cooled, 4 cycle diesel engine  |  |
| Bore × Stroke            |                                    | 83.0 × 92.4 mm (3.27 × 3.64 in.)   |  |
| Total Displacement       |                                    | 1999 cm <sup>3</sup> (122.0 cu.in.)  |  |
| STANDBY                  | ISO 3046                           | 18.1 kW / 1500 min <sup>-1</sup> (rpm)   | 21.8 kW / 1800 min <sup>-1</sup> (rpm) |
|                          | SAE J-1349                         | 24.3 HP / 1500 min <sup>-1</sup> (rpm)   | 29.2 HP / 1800 min <sup>-1</sup> (rpm) |
| NET Continuous           | ISO 3046                           | 15.5 kW / 1500 min <sup>-1</sup> (rpm)   | 18.2 kW / 1800 min <sup>-1</sup> (rpm) |
|                          | SAE J-1349                         | 20.8 HP / 1500 min <sup>-1</sup> (rpm)   | 24.4 HP / 1800 min <sup>-1</sup> (rpm) |
| Governor Regulation      |                                    | Less than 5%   |  |
| Combustion Chamber       |                                    | Spherical Type (E-TVCS)  |  |
| Fuel Injection Pump      |                                    | PFR 4M Type Mini Pump (DENSO)  |  |
| Governor                 |                                    | Mechanical all speed governor + Electronic Governor  |  |
| Direction of Rotation    |                                    | Counter-clockwise (viewed from flywheel side)  |  |
| Injection Nozzle         |                                    | OPD Mini Nozzle (DENSO)  |  |
| Injection Timing         |                                    | 0.2487 rad (14.25 °) before T.D.C.   |  |
| Firing Order             |                                    | 1-3-4-2  |  |
| Injection Pressure       |                                    | 13.73 MPa (140.0 kgf/cm <sup>2</sup> , 1991 psi)   |  |
| Compression Ratio        |                                    | 22.8 : 1   |  |
| Lubricating System       |                                    | Forced Lubrication by Trochoid Pump  |  |
| Oil Pressure Indicating  |                                    | Electrical type switch   |  |
| Lubricating Filter       |                                    | Full flow paper filter (cartridge type)  |  |
| Cooling System           |                                    | Pressurized radiator, forced circulation with water pump   |  |
| Starting System          |                                    | Electric Starting with Starter   |  |
| Starting Motor           |                                    | 12 V, 1.4 kW   |  |
| Starting Support Device  |                                    | By glow plug in combustion chamber   |  |
| EGR                      |                                    | NONE   |  |
| Battery                  |                                    | 12 V, 88 AH equivalent   |  |
| Charging Alternator      |                                    | 12 V, 480 W  |  |
| Fuel                     |                                    | Diesel Fuel No.2-D (ASTM D975)   |  |
| Lubricating Oil          |                                    | Class CF lubricating oil as per API classification is recommended.<br>For details on recommended lubricating oils, see page G-8, G-11. |  |
| Lubricating Oil Capacity | Oil Pan Depth<br>90 mm (3.5 in.)   | 7.6 L (2.0 U.S.gals)   |  |
|                          | Oil Pan Depth<br>124 mm (4.88 in.) | 9.5 L (2.5 U.S.gals)   |  |
| Weight (Dry)             |                                    | 195 kg (430 lbs)   |  |

\*The specification described above is of the standard engine of each model.

\*Conversion Formula : HP = 0.746 kW, PS = 0.7355 kW

M00000003INI0021US1

| Model                    |                                    | V2003-M-T-BG   |  |
|--------------------------|------------------------------------|--|--|
| Number of Cylinders      |                                    | 4  |  |
| Type                     |                                    | Vertical, Water-cooled, 4 cycle diesel engine  |  |
| Bore × Stroke            |                                    | 83.0 × 92.4 mm (3.27 × 3.64 in.)   |  |
| Total Displacement       |                                    | 1999 cm <sup>3</sup> (122.0 cu.in.)  |  |
| STANDBY                  | ISO 3046                           | 22.5 kW / 1500 min <sup>-1</sup> (rpm)   | 27.1 kW / 1800 min <sup>-1</sup> (rpm) |
|                          | SAE J-1349                         | 30.2 HP / 1500 min <sup>-1</sup> (rpm)   | 36.3 HP / 1800 min <sup>-1</sup> (rpm) |
| NET Continuous           | ISO 3046                           | 20.4 kW / 1500 min <sup>-1</sup> (rpm)   | 24.5 kW / 1800 min <sup>-1</sup> (rpm) |
|                          | SAE J-1349                         | 27.4 HP / 1500 min <sup>-1</sup> (rpm)   | 32.9 HP / 1800 min <sup>-1</sup> (rpm) |
| Governor Regulation      |                                    | Less than 5%   |  |
| Combustion Chamber       |                                    | Spherical Type (E-TVCS)  |  |
| Fuel Injection Pump      |                                    | PFR 4M Type Mini Pump (DENSO)  |  |
| Governor                 |                                    | Mechanical all speed governor + Electronic Governor  |  |
| Direction of Rotation    |                                    | Counter-clockwise (viewed from flywheel side)  |  |
| Injection Nozzle         |                                    | OPD Mini Nozzle (DENSO)  |  |
| Injection Timing         |                                    | 0.2662 rad (15.25 °) before T.D.C.   |  |
| Firing Order             |                                    | 1-3-4-2  |  |
| Injection Pressure       |                                    | 13.73 MPa (140.0 kgf/cm <sup>2</sup> , 1991 psi)   |  |
| Compression Ratio        |                                    | 21.7 : 1   |  |
| Lubricating System       |                                    | Forced Lubrication by Trochoid Pump  |  |
| Oil Pressure Indicating  |                                    | Electrical type switch   |  |
| Lubricating Filter       |                                    | Full flow paper filter (cartridge type)  |  |
| Cooling System           |                                    | Pressurized radiator, forced circulation with water pump   |  |
| Starting System          |                                    | Electric Starting with Starter   |  |
| Starting Motor           |                                    | 12 V, 1.4 kW   |  |
| Starting Support Device  |                                    | By glow plug in combustion chamber   |  |
| EGR                      |                                    | NONE   |  |
| Battery                  |                                    | 12 V, 88 AH equivalent   |  |
| Charging Alternator      |                                    | 12 V, 480 W  |  |
| Fuel                     |                                    | Diesel Fuel No.2-D (ASTM D975)   |  |
| Lubricating Oil          |                                    | Class CF lubricating oil as per API classification is recommended.<br>For details on recommended lubricating oils, see page G-8, G-11. |  |
| Lubricating Oil Capacity | Oil Pan Depth<br>90 mm (3.5 in.)   | 7.6 L (2.0 U.S.gals)   |  |
|                          | Oil Pan Depth<br>124 mm (4.88 in.) | 9.5 L (2.5 U.S.gals)   |  |
| Weight (Dry)             |                                    | 208 kg (459 lbs)   |  |

\*The specification described above is of the standard engine of each model.

\*Conversion Formula : HP = 0.746 kW, PS = 0.7355 kW

M0000003INI0022US1

| Model                    |                                    | V2203-M-BG   |  |
|--------------------------|------------------------------------|--|--|
| Number of Cylinders      |                                    | 4  |  |
| Type                     |                                    | Vertical, Water-cooled, 4 cycle diesel engine  |  |
| Bore × Stroke            |                                    | 87.0 × 92.4 mm (3.43 × 3.64 in.)   |  |
| Total Displacement       |                                    | 2197 cm <sup>3</sup> (134.1 cu.in.)  |  |
| STANDBY                  | ISO 3046                           | 20.1 kW / 1500 min <sup>-1</sup> (rpm)   | 24.2 kW / 1800 min <sup>-1</sup> (rpm) |
|                          | SAE J-1349                         | 27.0 HP / 1500 min <sup>-1</sup> (rpm)   | 32.5 HP / 1800 min <sup>-1</sup> (rpm) |
| NET Continuous           | ISO 3046                           | 17.2 kW / 1500 min <sup>-1</sup> (rpm)   | 20.2 kW / 1800 min <sup>-1</sup> (rpm) |
|                          | SAE J-1349                         | 23.1 HP / 1500 min <sup>-1</sup> (rpm)   | 27.1 HP / 1800 min <sup>-1</sup> (rpm) |
| Governor Regulation      |                                    | Less than 5%   |  |
| Combustion Chamber       |                                    | Spherical Type (E-TVCS)  |  |
| Fuel Injection Pump      |                                    | PFR 4M Type Mini Pump (DENSO)  |  |
| Governor                 |                                    | Mechanical all speed governor + Electronic Governor  |  |
| Direction of Rotation    |                                    | Counter-clockwise (viewed from flywheel side)  |  |
| Injection Nozzle         |                                    | OPD Mini Nozzle (DENSO)  |  |
| Injection Timing         |                                    | 0.2487 rad (14.25 °) before T.D.C.   |  |
| Firing Order             |                                    | 1-3-4-2  |  |
| Injection Pressure       |                                    | 13.73 MPa (140.0 kgf/cm <sup>2</sup> , 1991 psi)   |  |
| Compression Ratio        |                                    | 22.0 : 1   |  |
| Lubricating System       |                                    | Forced Lubrication by Trochoid Pump  |  |
| Oil Pressure Indicating  |                                    | Electrical type switch   |  |
| Lubricating Filter       |                                    | Full flow paper filter (cartridge type)  |  |
| Cooling System           |                                    | Pressurized radiator, forced circulation with water pump   |  |
| Starting System          |                                    | Electric Starting with Starter   |  |
| Starting Motor           |                                    | 12 V, 1.4 kW   |  |
| Starting Support Device  |                                    | By glow plug in combustion chamber   |  |
| EGR                      |                                    | NONE   |  |
| Battery                  |                                    | 12 V, 88 AH equivalent   |  |
| Charging Alternator      |                                    | 12 V, 480 W  |  |
| Fuel                     |                                    | Diesel Fuel No.2-D (ASTM D975)   |  |
| Lubricating Oil          |                                    | Class CF lubricating oil as per API classification is recommended.<br>For details on recommended lubricating oils, see page G-8, G-11. |  |
| Lubricating Oil Capacity | Oil Pan Depth<br>90 mm (3.5 in.)   | 7.6 L (2.0 U.S.gals)   |  |
|                          | Oil Pan Depth<br>124 mm (4.88 in.) | 9.5 L (2.5 U.S.gals)   |  |
| Weight (Dry)             |                                    | 195 kg (430 lbs)   |  |

\*The specification described above is of the standard engine of each model.

\*Conversion Formula : HP = 0.746 kW, PS = 0.7355 kW

M00000003INI0023US1


| Model                    |                                    | V2403-M-BG   |  |
|--------------------------|------------------------------------|--|--|
| Number of Cylinders      |                                    | 4  |  |
| Type                     |                                    | Vertical, Water-cooled, 4 cycle diesel engine  |  |
| Bore × Stroke            |                                    | 87.0 × 102.4 mm (3.43 × 4.031 in.)   |  |
| Total Displacement       |                                    | 2434 cm <sup>3</sup> (148.5 cu.in.)  |  |
| STANDBY                  | ISO 3046                           | 22.0 kW / 1500 min <sup>-1</sup> (rpm)   | 26.5 kW / 1800 min <sup>-1</sup> (rpm) |
|                          | SAE J-1349                         | 29.5 HP / 1500 min <sup>-1</sup> (rpm)   | 35.5 HP / 1800 min <sup>-1</sup> (rpm) |
| NET Continuous           | ISO 3046                           | 18.8 kW / 1500 min <sup>-1</sup> (rpm)   | 22.1 kW / 1800 min <sup>-1</sup> (rpm) |
|                          | SAE J-1349                         | 25.2 HP / 1500 min <sup>-1</sup> (rpm)   | 29.6 HP / 1800 min <sup>-1</sup> (rpm) |
| Governor Regulation      |                                    | Less than 5%   |  |
| Combustion Chamber       |                                    | Spherical Type (E-TVCS)  |  |
| Fuel Injection Pump      |                                    | PFR 4M Type Mini Pump (DENSO)  |  |
| Governor                 |                                    | Mechanical all speed governor + Electronic Governor  |  |
| Direction of Rotation    |                                    | Counter-clockwise (viewed from flywheel side)  |  |
| Injection Nozzle         |                                    | OPD Mini Nozzle (DENSO)  |  |
| Injection Timing         |                                    | 0.2487 rad (14.25 °) before T.D.C.   |  |
| Firing Order             |                                    | 1-3-4-2  |  |
| Injection Pressure       |                                    | 13.73 MPa (140.0 kgf/cm <sup>2</sup> , 1991 psi)   |  |
| Compression Ratio        |                                    | 23.2 : 1   |  |
| Lubricating System       |                                    | Forced Lubrication by Trochoid Pump  |  |
| Oil Pressure Indicating  |                                    | Electrical type switch   |  |
| Lubricating Filter       |                                    | Full flow paper filter (cartridge type)  |  |
| Cooling System           |                                    | Pressurized radiator, forced circulation with water pump   |  |
| Starting System          |                                    | Electric Starting with Starter   |  |
| Starting Motor           |                                    | 12 V, 2.0 kW   |  |
| Starting Support Device  |                                    | By glow plug in combustion chamber   |  |
| EGR                      |                                    | NONE   |  |
| Battery                  |                                    | 12 V, 88 AH equivalent   |  |
| Charging Alternator      |                                    | 12 V, 480 W  |  |
| Fuel                     |                                    | Diesel Fuel No.2-D (ASTM D975)   |  |
| Lubricating Oil          |                                    | Class CF lubricating oil as per API classification is recommended.<br>For details on recommended lubricating oils, see page G-8, G-11. |  |
| Lubricating Oil Capacity | Oil Pan Depth<br>90 mm (3.5 in.)   | 7.6 L (2.0 U.S.gals)   |  |
|                          | Oil Pan Depth<br>124 mm (4.88 in.) | 9.5 L (2.5 U.S.gals)   |  |
| Weight (Dry)             |                                    | 190 kg (419 lbs)   |  |

\*The specification described above is of the standard engine of each model.

\*Conversion Formula : HP = 0.746 kW, PS = 0.7355 kW


M00000003INI0024US1

### 3. DIMENSIONS



|          | <b>D1503-M</b>       | <b>D1703-M</b>       | <b>D1803-M</b>       |
|----------|----------------------|----------------------|----------------------|
| <b>A</b> | 567.0 mm (22.32 in.) | 560.0 mm (22.05 in.) | 560.0 mm (22.05 in.) |
| <b>B</b> | 512.0 mm (20.16 in.) | 480.0 mm (18.90 in.) | 480.0 mm (18.90 in.) |
| <b>C</b> | 643.0 mm (25.31 in.) | 643.0 mm (25.31 in.) | 648.0 mm (25.51 in.) |


M00000003INI0016US1



3EEADACFP002A


|   | V2003-M              | V2203-M              | V2403-M              | V2403-M-T            |
|---|----------------------|----------------------|----------------------|----------------------|
| A | 652.0 mm (25.67 in.) | 652.0 mm (25.67 in.) | 652.0 mm (25.67 in.) | 667.1 mm (26.26 in.) |
| B | 480.0 mm (18.90 in.) | 480.0 mm (18.90 in.) | 480.0 mm (18.90 in.) | 449.0 mm (17.68 in.) |
| C | 643.0 mm (25.31 in.) | 643.0 mm (25.31 in.) | 648.0 mm (25.51 in.) | 737.3 mm (29.03 in.) |

M00000003INI0017US1



| <b>D1803-M-DI</b> |                      |
|-------------------|----------------------|
| <b>A</b>          | 560.0 mm (22.05 in.) |
| <b>B</b>          | 492.0 mm (19.37 in.) |
| <b>C</b>          | 636.0 mm (25.04 in.) |


M00000003INI0018US1



3EEADABFP002B


|          | V2403-M-DI           | V2403-M-DI-T         |
|----------|----------------------|----------------------|
| <b>A</b> | 655.0 mm (25.79 in.) | 667.1 mm (26.26 in.) |
| <b>B</b> | 492.0 mm (19.37 in.) | 449.0 mm (17.68 in.) |
| <b>C</b> | 636.0 mm (25.04 in.) | 737.3 mm (29.03 in.) |

M00000003INI0019US1



| <b>D1703-M-BG</b> |                      |
|-------------------|----------------------|
| <b>A</b>          | 605.6 mm (23.84 in.) |
| <b>B</b>          | 505.0 mm (19.88 in.) |
| <b>C</b>          | 642.8 mm (25.31 in.) |


M00000003INI0025US1



|          | <b>V2003-M-BG</b>    | <b>V2003-M-T-BG</b>  | <b>V2203-M-BG</b>    | <b>V2403-M-BG</b>    |
|----------|----------------------|----------------------|----------------------|----------------------|
| <b>A</b> | 700.6 mm (27.58 in.) |
| <b>B</b> | 505.0 mm (19.88 in.) |
| <b>C</b> | 633.3 mm (24.93 in.) | 674.0 mm (26.54 in.) | 633.3 mm (24.93 in.) | 684.0 mm (26.93 in.) |

M00000003INI0026US1

# 4. WIRING DIAGRAM



9Y1210257IGM001A

9Y1210257INI0001US1

# **G GENERAL**


# GENERAL

## CONTENTS

|   |      |
|---|------|
| 1. ENGINE IDENTIFICATION .....                    | G-1  |
| [1] MODEL NAME AND OLD ENGINE SERIAL NUMBER ..... | G-1  |
| [2] MODEL NAME AND NEW ENGINE SERIAL NUMBER ..... | G-2  |
| [3] E3B ENGINE .....                              | G-4  |
| [4] CYLINDER NUMBER.....                          | G-4  |
| 2. GENERAL PRECAUTIONS.....                       | G-5  |
| 3. MAINTENANCE CHECK LIST .....                   | G-6  |
| 4. CHECK AND MAINTENANCE .....                    | G-9  |
| [1] DAILY CHECK POINTS .....                      | G-9  |
| [2] CHECK POINTS FOR THE INITIAL 50 HOURS.....    | G-11 |
| [3] CHECK POINTS FOR EVERY 50 HOURS .....         | G-13 |
| [4] CHECK POINTS FOR EVERY 100 HOURS .....        | G-14 |
| [5] CHECK POINTS FOR EVERY 150 HOURS .....        | G-16 |
| [6] CHECK POINTS FOR EVERY 200 HOURS .....        | G-18 |
| [7] CHECK POINTS FOR EVERY 400 HOURS .....        | G-21 |
| [8] CHECK POINTS FOR EVERY 500 HOURS .....        | G-23 |
| [9] CHECK POINTS FOR EVERY 1 OR 2 MONTHS .....    | G-25 |
| [10]CHECK POINTS FOR EVERY YEAR.....              | G-27 |
| [11]CHECK POINTS FOR EVERY 800 HOURS .....        | G-28 |
| [12]CHECK POINTS FOR EVERY 1500 HOURS .....       | G-29 |
| [13]CHECK POINTS FOR EVERY 3000 HOURS .....       | G-32 |
| [14]CHECK POINTS FOR EVERY 2 YEARS.....           | G-35 |
| 5. SPECIAL TOOLS .....                            | G-39 |

# 1. ENGINE IDENTIFICATION

## [1] MODEL NAME AND OLD ENGINE SERIAL NUMBER



You must identify the engine model name and serial number before you start a job. When you get in touch with the manufacturer, always tell your engine model name and serial number.

### Engine Serial Number

The engine serial number is an identified number for the engine. It appears after the engine model name.

It shows the month and year of manufacture as below.

- (1) Engine Model Name and Serial Number

### Year of manufacture

| Alphabet or Number | Year | Alphabet or Number | Year |
|--------------------|------|--------------------|------|
| 1                  | 2001 | F                  | 2015 |
| 2                  | 2002 | G                  | 2016 |
| 3                  | 2003 | H                  | 2017 |
| 4                  | 2004 | J                  | 2018 |
| 5                  | 2005 | K                  | 2019 |
| 6                  | 2006 | L                  | 2020 |
| 7                  | 2007 | M                  | 2021 |
| 8                  | 2008 | N                  | 2022 |
| 9                  | 2009 | P                  | 2023 |
| A                  | 2010 | R                  | 2024 |
| B                  | 2011 | S                  | 2025 |
| C                  | 2012 | T                  | 2026 |
| D                  | 2013 | V                  | 2027 |
| E                  | 2014 |                    |      |

### Month of manufacture


| Month     | Engine Lot Number |               |
|-----------|-------------------|---------------|
| January   | A0001 ~ A9999     | B0001 ~ BZ999 |
| February  | C0001 ~ C9999     | D0001 ~ DZ999 |
| March     | E0001 ~ E9999     | F0001 ~ FZ999 |
| April     | G0001 ~ G9999     | H0001 ~ HZ999 |
| May       | J0001 ~ J9999     | K0001 ~ KZ999 |
| June      | L0001 ~ L9999     | M0001 ~ MZ999 |
| July      | N0001 ~ N9999     | P0001 ~ PZ999 |
| August    | Q0001 ~ Q9999     | R0001 ~ RZ999 |
| September | S0001 ~ S9999     | T0001 ~ TZ999 |
| October   | U0001 ~ U9999     | V0001 ~ VZ999 |
| November  | W0001 ~ W9999     | X0001 ~ XZ999 |
| December  | Y0001 ~ Y9999     | Z0001 ~ ZZ999 |

\* Alphabetical letters "I" and "O" are not used.

(a) (b)(c) (d)  
e.g. D1803 - 7 B A001

- (a) Engine Model Name **D1803**
- (b) Year: **7** indicates **2007**
- (c) Month: **A** or **B** indicates January
- (d) Lot Number: (**0001 ~ 9999** or **A001 ~ Z999**)

## [2] MODEL NAME AND NEW ENGINE SERIAL NUMBER



You must identify the engine model name and serial number before you start a job. When you get in touch with the manufacturer, always tell your engine model name and serial number.

### Engine Serial Number

The engine serial number is an identified number for the engine. It appears after the engine model name.

It shows the month and year of manufacture as below.

### Engine Series

| Number or Alphabet | Series              | Number or Alphabet | Series                  |
|--------------------|---------------------|--------------------|-------------------------|
| 1                  | 05 (include: WG)    | 7                  | 03                      |
| 2                  | V3                  | 8                  | 07                      |
| 3                  | 08                  | A                  | EA, RK                  |
| 4                  | SM (include: WG)    | B                  | 03 (KET Production)     |
| 5                  | Air Cooled Gasoline | C                  | V3, 07 (KEW Production) |
| 6                  | GZ, OC, AC, EA, E   |                    |                         |

### Production Year

| Alphabet or Number | Year | Alphabet or Number | Year |
|--------------------|------|--------------------|------|
| 1                  | 2001 | F                  | 2015 |
| 2                  | 2002 | G                  | 2016 |
| 3                  | 2003 | H                  | 2017 |
| 4                  | 2004 | J                  | 2018 |
| 5                  | 2005 | K                  | 2019 |
| 6                  | 2006 | L                  | 2020 |
| 7                  | 2007 | M                  | 2021 |
| 8                  | 2008 | N                  | 2022 |
| 9                  | 2009 | P                  | 2023 |
| A                  | 2010 | R                  | 2024 |
| B                  | 2011 | S                  | 2025 |
| C                  | 2012 | T                  | 2026 |
| D                  | 2013 | V                  | 2027 |
| E                  | 2014 |                    |      |

(1) Engine Model Name and Serial Number

**(To be continued)**

(Continued)

**Production Month and Lot Number**

| Month     | Engine Lot Number |         |
|-----------|-------------------|---------|
| January   | A0001 ~ A9999     | B0001 ~ |
| February  | C0001 ~ C9999     | D0001 ~ |
| March     | E0001 ~ E9999     | F0001 ~ |
| April     | G0001 ~ G9999     | H0001 ~ |
| May       | J0001 ~ J9999     | K0001 ~ |
| June      | L0001 ~ L9999     | M0001 ~ |
| July      | N0001 ~ N9999     | P0001 ~ |
| August    | Q0001 ~ Q9999     | R0001 ~ |
| September | S0001 ~ S9999     | T0001 ~ |
| October   | U0001 ~ U9999     | V0001 ~ |
| November  | W0001 ~ W9999     | X0001 ~ |
| December  | Y0001 ~ Y9999     | Z0001 ~ |

\* Alphabetical letters "I" and "O" are not used.

(a) (b)(c)(d) (e)  
 e.g. D1803 - 7 7 B A001

- (a) **D1803**: Engine Model Name
- (b) **7**: Engine Series (03 series)
- (c) **7**: Production Year (2007)
- (d) **B**: Production Month (January)
- (e) **A001**: Lot Number: (**0001 ~ 9999** or **A001 ~ Z999**)

9Y1210257GEG0002US0


### [3] E3B ENGINE

[Example : Engine Model Name D1803-M-**E3B**-XXXX or D1803-M-DI-**E3B**-XXXX]

The emission controls previously implemented in various countries to prevent air pollution will be stepped up as Nonroad Emission Standards continue to change. The timing or applicable date of the specific Nonroad Emission regulations depends on the engine output classification.

Over the past several years, Kubota has been supplying diesel engines that comply with regulations in the respective countries affected by Nonroad Emission regulations. For Kubota Engines, E3B will be the designation that identifies engine models affected by the next emission phase (See the table below).

When servicing or repairing ###-E3B series engines, use only replacement parts for that specific E3B engine, designated by the appropriate E3B Kubota Parts List and perform all maintenance services listed in the appropriate Kubota Operator's Manual or in the appropriate E3B Kubota Workshop Manual. Use of incorrect replacement parts or replacement parts from other emission level engines (for example: E2B engines), may result in emission levels out of compliance with the original E3B design and EPA or other applicable regulations. Please refer to the emission label located on the engine head cover to identify Output classification and Emission Control Information. E3B engines are identified with "ET" at the end of the Model designation, on the US EPA label. Please note : E3B is not marked on the engine.




| Category (1) | Engine output classification | EU regulation |
|--------------|------------------------------|---------------|
| K            | From 19 to less than 37 kW   | STAGE IIIA    |
| J            | From 37 to less than 75 kW   | STAGE IIIA    |
| I            | From 75 to less than 130 kW  | STAGE IIIA    |

| Category (2) | Engine output classification | EPA regulation |
|--------------|------------------------------|----------------|
| ET           | Less than 19kW               | Tier 4         |
|              | From 19 to less than 56 kW   | Interim Tier 4 |
|              | From 56 to less than 75 kW   | Tier 3         |
|              | From 75 to less than 130 kW  | Tier 3         |

- (1) EU regulation engine output classification category
- (2) "E3B" engines are identified with "ET" at the end of the Model designation, on the US EPA label. "E3B" designates Tier 3 and some Interim Tier 4 / Tier 4 models, depending on engine output classification.

M00000003GEG0002US1


### [4] CYLINDER NUMBER



You can see the cylinder numbers of KUBOTA diesel engine in the figure. The sequence of cylinder numbers is No.1, No.2, No.3 and No.4 and it starts from the gear case side.

M00000003GEG0003US1

## 2. GENERAL PRECAUTIONS



- When you disassemble, carefully put the parts in a clean area to make it easy to find the parts. You must install the screws, bolts and nuts in their initial position to prevent the reassembly errors.
- When it is necessary to use special tools, use KUBOTA special tools. Refer to the drawings when you make special tools that you do not use frequently.
- Before you disassemble or repair machine, make sure that you always disconnect the ground cable from the battery first.
- Remove oil and dirt from parts before you measure.
- Use only KUBOTA genuine parts for replacement to keep the machine performance and to make sure of safety.
- You must replace the gaskets and O-rings when you assemble again. Apply grease (1) to new O-rings or oil seals before you assemble.
- When you assemble the external or internal snap rings, make sure that the sharp edge (3) faces against the direction from which force (2) is applied.
- Make sure that you try to operate the engine after you repair or assemble it. Do not try to give a heavy load immediately, if not, you can cause serious damage to the engine.

- (1) Grease  
 (2) Force  
 (3) Sharp Edge

- (A) External Snap Ring  
 (B) Internal Snap Ring

M00000003GEG0004US1

### 3. MAINTENANCE CHECK LIST

To make sure that the engine operates safely for a long time, refer to the table below to do regular inspections.  
**[D1503-M, D1703-M, D1803-M, V2003-M, V2203-M, V2403-M, V2403-M-T, D1703-M-BG, V2003-M-BG, V2003-M-T-BG, V2203-M-BG, V2403-M-BG]**

| Item  | Service Interval                     |         |         |         |         |         |               |        |         |          |          |         |
|---|--------------------------------------|---------|---------|---------|---------|---------|---------------|--------|---------|----------|----------|---------|
|   | Every                                |         |         |         |         |         |               |        |         |          |          |         |
|   | 50 hrs                               | 100 hrs | 150 hrs | 200 hrs | 400 hrs | 500 hrs | 1 or 2 months | 1 year | 800 hrs | 1500 hrs | 3000 hrs | 2 years |
| * Check of fuel hoses and clamp bands   | ☆                                    |         |         |         |         |         |               |        |         |          |          |         |
| Change of engine oil (depending on the oil pan)                                 | (1) Oil pan depth (90 mm, 3.5 in.)   | ★       |         | ☆       |         |         |               |        |         |          |          |         |
|   | (2) Oil pan depth (124 mm, 4.88 in.) | ★       |         |         | ☆       |         |               |        |         |          |          |         |
| * Cleaning of air cleaner element (replace the element after 6-times cleanings) |                                      | ☆       |         |         |         |         |               |        |         |          |          |         |
| * Cleaning of fuel filter (Element type)  |                                      | ☆       |         |         |         |         |               |        |         |          |          |         |
| Check of battery electrolyte level  |                                      | ☆       |         |         |         |         |               |        |         |          |          |         |
| Check of fan belt tension and damage  |                                      | ☆       |         |         |         |         |               |        |         |          |          |         |
| Replacement of oil filter cartridge   | (1) Oil pan depth (90 mm, 3.5 in.)   | ★       |         | ☆       |         |         |               |        |         |          |          |         |
|   | (2) Oil pan depth (124 mm, 4.88 in.) | ★       |         |         | ☆       |         |               |        |         |          |          |         |
| Check of radiator hoses and clamp bands   |                                      |         |         | ☆       |         |         |               |        |         |          |          |         |
| * Check of intake air line  |                                      |         |         | ☆       |         |         |               |        |         |          |          |         |
| Replacement of fuel filter cartridge  |                                      |         |         |         | ☆       |         |               |        |         |          |          |         |
| Cleaning of water jacket and radiator interior                                  |                                      |         |         |         |         | ☆       |               |        |         |          |          |         |
| Replacement of fan belt   |                                      |         |         |         |         | ☆       |               |        |         |          |          |         |
| Recharge of battery   |                                      |         |         |         |         |         | ☆             |        |         |          |          |         |
| * Replacement of air cleaner element  |                                      |         |         |         |         |         |               | ☆      |         |          |          |         |
| Check of valve clearance  |                                      |         |         |         |         |         |               |        | ☆       |          |          |         |
| * Check of injection nozzle   |                                      |         |         |         |         |         |               |        |         | ☆        |          |         |
| * Check of turbocharger   |                                      |         |         |         |         |         |               |        |         |          | ☆        |         |
| * Check of injection pump   |                                      |         |         |         |         |         |               |        |         |          | ☆        |         |
| * Replacement of intake air line  |                                      |         |         |         |         |         |               |        |         |          |          | ☆       |
| Replacement of battery  |                                      |         |         |         |         |         |               |        |         |          |          | ☆       |
| Replacement of radiator hoses and clamp bands                                   |                                      |         |         |         |         |         |               |        |         |          |          | ☆       |
| * Replacement of fuel hoses and clamps  |                                      |         |         |         |         |         |               |        |         |          |          | ☆       |
| Change of radiator coolant (L.L.C.)   |                                      |         |         |         |         |         |               |        |         |          |          | ☆       |

★ Change the engine oil and replace the oil filter cartridge after the first 50 hours of operation.

\* The items above (\* marked) are registered as emission related critical parts by KUBOTA in the U.S. EPA nonroad emission regulation. As the owner of the engine, you are responsible for the performance of the required maintenance above.

M00000003GEG0005US1

**[D1803-M-DI, V2403-M-DI, V2403-M-DI-T]**

| Item |   | Service Interval                     |         |         |         |         |               |        |         |          |          |         |   |   |
|------|---|--------------------------------------|---------|---------|---------|---------|---------------|--------|---------|----------|----------|---------|---|---|
|      |   | Every                                |         |         |         |         |               |        |         |          |          |         |   |   |
|      |   | 50 hrs                               | 100 hrs | 200 hrs | 400 hrs | 500 hrs | 1 or 2 months | 1 year | 800 hrs | 1500 hrs | 3000 hrs | 2 years |   |   |
| *    | Check of fuel hoses and clamp bands   | ☆                                    |         |         |         |         |               |        |         |          |          |         |   |   |
|      | Change of engine oil (depending on the oil pan)                               | (1) Oil pan depth (90 mm, 3.5 in.)   | ★       |         | ☆       |         |               |        |         |          |          |         |   |   |
|      |   | (2) Oil pan depth (124 mm, 4.88 in.) | ★       |         |         | ☆       |               |        |         |          |          |         |   |   |
| *    | Cleaning of air cleaner element (replace the element after 6-times cleanings) |                                      | ☆       |         |         |         |               |        |         |          |          |         |   |   |
| *    | Cleaning of fuel filter (Element type)  |                                      | ☆       |         |         |         |               |        |         |          |          |         |   |   |
|      | Check of battery electrolyte level  |                                      | ☆       |         |         |         |               |        |         |          |          |         |   |   |
|      | Check of fan belt tension and damage  |                                      | ☆       |         |         |         |               |        |         |          |          |         |   |   |
|      | Replacement of oil filter cartridge   | (1) Oil pan depth (90 mm, 3.5 in.)   | ★       |         | ☆       |         |               |        |         |          |          |         |   |   |
|      |   | (2) Oil pan depth (124 mm, 4.88 in.) | ★       |         |         | ☆       |               |        |         |          |          |         |   |   |
|      | Check of radiator hoses and clamp bands                                       |                                      |         | ☆       |         |         |               |        |         |          |          |         |   |   |
| *    | Check of intake air line  |                                      |         | ☆       |         |         |               |        |         |          |          |         |   |   |
|      | Replacement of fuel filter cartridge  |                                      |         |         | ☆       |         |               |        |         |          |          |         |   |   |
|      | Cleaning of water jacket and radiator interior                                |                                      |         |         |         | ☆       |               |        |         |          |          |         |   |   |
|      | Replacement of fan belt   |                                      |         |         |         | ☆       |               |        |         |          |          |         |   |   |
|      | Recharge of battery   |                                      |         |         |         |         | ☆             |        |         |          |          |         |   |   |
| *    | Replacement of air cleaner element  |                                      |         |         |         |         |               | ☆      |         |          |          |         |   |   |
|      | Check of valve clearance  |                                      |         |         |         |         |               |        | ☆       |          |          |         |   |   |
| *    | Check of injection nozzle   |                                      |         |         |         |         |               |        |         | ☆        |          |         |   |   |
| *    | Check of turbocharger   |                                      |         |         |         |         |               |        |         |          | ☆        |         |   |   |
| *    | Check of injection pump   |                                      |         |         |         |         |               |        |         |          |          | ☆       |   |   |
| *    | Replacement of intake air line  |                                      |         |         |         |         |               |        |         |          |          |         | ☆ |   |
|      | Replacement of battery  |                                      |         |         |         |         |               |        |         |          |          |         |   | ☆ |
|      | Replacement of radiator hoses and clamp bands                                 |                                      |         |         |         |         |               |        |         |          |          |         |   | ☆ |
| *    | Replacement of fuel hoses and clamps  |                                      |         |         |         |         |               |        |         |          |          |         |   | ☆ |
|      | Change of radiator coolant (L.L.C.)   |                                      |         |         |         |         |               |        |         |          |          |         |   | ☆ |

★ Change the engine oil and replace the oil filter cartridge after the first 50 hours of operation.

\* The items above (\* marked) are registered as emission related critical parts by KUBOTA in the U.S. EPA nonroad emission regulation. As the owner of the engine, you are responsible for the performance of the required maintenance above.

M00000003GEG0006US1


**CAUTION**

- When changing or inspecting, be sure to level and stop the engine.

**NOTE**
**Engine oil**

- Refer to the following table for the suitable American Petroleum Institute (API) classification of engine oil according to the engine type (with internal EGR, external EGR or non-EGR) and the Fuel Type Used : (Low Sulfur, Ultra Low Sulfur or High Sulfur Fuels).

| Fuel Type  | Engine oil classification (API classification)   |  |
|--|--|--|
|  | Engines with non-EGR<br>Engines with internal EGR  | Engines with external EGR  |
| High Sulfur Fuel<br>[0.05 % (500 ppm) ≤<br>Sulfur Content <<br>0.50 % (5000 ppm)]  | <b>CF</b><br>(If the "CF-4, CG-4, CH-4, or CI-4" engine oil is used with a high-sulfur fuel, change the engine oil at shorter intervals. (approximately half)) | –  |
| Low Sulfur Fuel<br>[Sulfur Content <<br>0.05 % (500 ppm)] or<br>Ultra Low Sulfur Fuel<br>[Sulfur Content <<br>0.0015 % (15 ppm)] | <b>CF, CF-4, CG-4, CH-4 or CI-4</b>  | <b>CF or CI-4</b><br>(Class CF-4, CG-4 and CH-4 engine oils cannot be used on EGR type engines.) |

EGR : Exhaust Gas Re-circulation

- **CJ-4 classification oil is intended for use in engines equipped with DPF (Diesel Particulate Filter) and is Not Recommended for use in Kubota E3 specification engines.**
- Oil used in the engine should have API classification and Proper SAE Engine Oil Viscosity according to the ambient temperatures where the engine is operated.
- With strict emission control regulations now in effect, the CF-4 and CG-4 engine oils have been developed for use with low sulfur fuels, for On-Highway vehicle engines. When a Nonroad engine operates on high sulfur fuel, it is advisable to use a "CF or better" classification engine oil with a high Total Base Number (a minimum TBN of 10 is recommended).

**Fuel**

- **Cetane Rating** : The minimum recommended Fuel Cetane Rating is 45. A cetane rating greater than 50 is preferred, especially for ambient temperatures below –20 °C (–4 °F) or elevations above 1500 m (5000 ft).
- **Diesel Fuel Specification Type and Sulfur Content % (ppm) used, must be compliant with all applicable emission regulations for the area in which the engine is operated.**
- Use of diesel fuel with sulfur content less than 0.10 % (1000 ppm) is strongly recommended.
- If high-sulfur fuel (sulfur content 0.50 % (5000 ppm) to 1.0 % (10000 ppm)) is used as a diesel fuel, change the engine oil and oil filter at shorter intervals. (approximately half)
- **DO NOT USE Fuels that have sulfur content greater than 1.0 % (10000 ppm).**
- Diesel fuels specified to EN 590 or ASTM D975 are recommended.
- No.2-D is a distillate fuel of lower volatility for engines in industrial and heavy mobile service. (SAE J313 JUN87)
- Since KUBOTA diesel engines of less than 56 kW (75 hp) utilize EPA Tier 4 and Interim Tier 4 standards, the use of low sulfur fuel or ultra low sulfur fuel is mandatory for these engines, when operated in US EPA regulated areas. Therefore, please use No.2-D S500 or S15 diesel fuel as an alternative to No.2-D, and use No.1-D S500 or S15 diesel fuel as an alternative to No.1-D for ambient temperatures below –10 °C (14 °F).

1) SAE : Society of Automotive Engineers

2) EN : European Norm

3) ASTM : American Society of Testing and Materials


4) US EPA : United States Environmental Protection Agency

5) No.1-D or No.2-D, S500 : Low Sulfur Diesel (LSD) less than 500 ppm or 0.05 wt. %  
No.1-D or No.2-D, S15 : Ultra Low Sulfur Diesel (ULSD) 15 ppm or 0.0015 wt. %

M00000003GEG0007US1

## 4. CHECK AND MAINTENANCE

### [1] DAILY CHECK POINTS



#### Check of Engine Oil Level

1. Make the engine level.
2. Pull out the dipstick (1) and clean it.
3. Put in and pull it out again.  
Make sure that the oil level is between the 2 notches.
4. If the level is too low, add new oil to the specified level.

#### ■ IMPORTANT

- When you use an oil of different brand or viscosity from the previous, drain the remaining oil. Do not mix 2 different types of oil.

#### ■ NOTE



- When you check the engine oil level, make sure that you put it in a level position. If not, you cannot measure oil quantity accurately.
- Make sure that you keep the oil level between the upper and lower lines of the dipstick. Too much oil can decrease the output or cause too much blow-by gas. On the closed breather type engine, the port absorbs the mist and too much oil can cause oil hammer. But if the oil level is not sufficient, the moving parts of engine can get a seizure.

(1) Dipstick

(a) Upper Line

(b) Lower Line

M00000003GEG0008US1



## Check of Coolant Level and Replenishment

### ⚠ CAUTION

- Do not remove the radiator cap when the engine is hot. Then loosen the cap slightly to release unwanted pressure before you remove the cap fully.

#### 1. Without recovery tank

Remove the radiator cap (1) and make sure that the coolant level is immediately below the port.

#### With recovery tank (2)

Make sure that the coolant level is between **FULL A** and **LOW B**.

2. If the coolant level is too low, find out the cause that there is less coolant.

#### Case 1

If the coolant decreases by evaporation, add only clean and soft water.

#### Case 2

If the coolant decreases by leak, add coolant of the same manufacturer and brand in the specified mixture ratio (clean, soft water and L.L.C.). If you cannot identify the coolant brand, drain all the remaining coolant and add a new brand of coolant mix.

### ■ IMPORTANT



- When you add the coolant, release the air from the engine coolant channels. The engine releases the air when it shakes the radiator upper and lower hoses.
- Make sure that you close the radiator cap correctly. If the cap is loose or incorrectly closed, coolant can flow out and the engine can overheat.
- Do not use an anti-freeze and scale inhibitor at the same time.
- Do not mix the different type or brand of L.L.C..

- (1) Radiator Cap  
(2) Recovery Tank

A : FULL  
B : LOW

M00000003GEG0009US1

## [2] CHECK POINTS FOR THE INITIAL 50 HOURS



### Change of Engine Oil

#### **CAUTION**

- **Make sure that you stop the engine before you change the engine oil.**
1. Start and warm-up the engine for approximately 5 minutes.
  2. Put an oil pan below the engine.
  3. Remove the drain plug (1) at the bottom of the engine and drain the oil fully.
  4. Tighten the drain plug (1).
  5. Fill new oil until the upper line on the dipstick (2).

#### **IMPORTANT**

- **When you use an oil of different brand or viscosity from the previous, drain the remaining oil. Do not mix 2 different types of oil.**
- **Engine oil must have the properties of API classification CF/CF-4/CG-4/CH-4/CI-4.**
- **Use the correct SAE Engine Oil by reference to the ambient temperature.**

|                                |                                      |
|--------------------------------|--------------------------------------|
| Above 25 °C (77 °F)            | SAE 30 or<br>SAE 10W-30, SAE 10W-40  |
| 0 °C to 25 °C (32 °F to 77 °F) | SAE 20 or<br>SAE 10W-30, SAE 10W-40  |
| Below 0 °C (32 °F)             | SAE 10W or<br>SAE 10W-30, SAE 10W-40 |


| Models   | Oil Pan Depth         |                       |
|--|-----------------------|-----------------------|
|  | 124 mm (4.88 in.)     | *90 mm (3.5 in.)      |
| D1503-M, D1703-M,<br>D1803-M, D1803-M-DI,<br>D1703-M-BG  | 7.0 L<br>1.8 U.S.gals | 5.6 L<br>1.5 U.S.gals |
| V2003-M, V2203-M,<br>V2403-M, V2403-M-DI,<br>V2403-M-DI-T,<br>V2003-M-BG,<br>V2003-M-T-BG,<br>V2203-M-BG, V2403-M-BG | 9.5 L<br>2.5 U.S.gals | 7.6 L<br>2.0 U.S.gals |
| V2403-M-T  | 9.5 L<br>2.5 U.S.gals | —                     |

\*90 mm (3.5 in.) oil pan depth is optional.

(1) Drain Plug

(2) Dipstick

M0000003GEG0010US1



## Replacement of Oil Filter Cartridge

### CAUTION

- **Make sure that you stop the engine before you replace the oil filter cartridge.**

1. Remove the oil filter cartridge (1) with the filter wrench.
2. Apply a thin layer of oil on the new cartridge gasket.
3. Install the new cartridge by hand. Do not tighten too much because it can cause deformation of the rubber gasket.
4. After you replace the cartridge, the engine oil usually decrease by a small level. Make sure that the engine oil does not flow through the seal and read the oil level on the dipstick.
5. Fill the engine oil until the specified level.






### ■ IMPORTANT

- **To prevent serious damage to the engine, use only KUBOTA genuine filters or its equivalent.**

(1) Oil Filter Cartridge

M00000003GEG0011US1

### [3] CHECK POINTS FOR EVERY 50 HOURS



#### Check of Fuel Hoses and Clamp Bands

#### ⚠ CAUTION

- **Stop the engine before you do the check below.**
1. If the clamp (2) is loose, apply oil to the threads and tighten it again correctly.
  2. The fuel hose (1) material is rubber and deteriorates naturally. Replace the fuel hose together with the clamp in a 2-years interval.
  3. But if the fuel hose and clamp has damages before 2 years, then replace them.
  4. After you replace the fuel hose and the clamp, bleed the fuel system.

#### (When you bleed the fuel system)

1. Fill the tank with fuel.
2. Open the fuel cock (4). ([B] only)
3. Loosen the air vent plug (3) of the fuel filter by a few turns.
4. Tighten the plug when the bubbles do not come up.
5. Open the air vent cock (5) on top of the fuel injection pump.
6. **Engine with the electrical fuel feed pump**  
Turn the key to the AC position and supply the fuel with the pump for 10 to 15 seconds.
7. Close the air vent cock correctly after you bled the air.

#### Engine with the mechanical fuel feed pump

Set the stop lever on STOP position and crank the engine with the starter for 10 to 15 seconds.

#### ■ NOTE


- **Always keep the air vent cock on the fuel injection pump closed unless when you release the air. If not, it can cause the engine to stop.**

- (1) Fuel Hose
- (2) Clamp
- (3) Air Vent Plug
- (4) Fuel Cock
- (5) Air Vent Cock

- [A] Cartridge Type
- [B] Element Type

M00000003GEG0012US1

## [4] CHECK POINTS FOR EVERY 100 HOURS




### Cleaning of Air Cleaner Element

1. Remove the air cleaner element.
2. Use clean dry compressed air on the inner side of the element. The pressure of compressed air must be less than 210 kPa (2.1 kgf/cm<sup>2</sup>, 30 psi). Keep an appropriate distance between the nozzle and the filter.

■ **NOTE**

- The air cleaner uses a dry element. Do not apply oil to it.
- Do not operate the engine without the filter element.
- Replace the element once a year or every sixth cleaning.

M00000003GEG0013US1



### Cleaning of Fuel Filter (Element Type Only)


1. Close the fuel cock (3).
2. Remove the retaining ring (6).
3. Remove the filter cup (5).
4. Flush the inner side with kerosene.
5. Remove the filter element (4) and clean it in the kerosene.
6. After you clean, assemble the fuel filter again. Make sure that you keep out dust and dirt.
7. Bleed the fuel system.

■ **IMPORTANT**

- If dust and dirt go into the fuel, the fuel injection pump and injection nozzle can wear out quickly. To prevent this, make sure that you clean the filter cup (5) periodically.

- |                   |                    |
|-------------------|--------------------|
| (1) Cock Body     | (4) Filter Element |
| (2) Air Vent Plug | (5) Filter Cup     |
| (3) Fuel Cock     | (6) Retaining Ring |

M00000003GEG0014US1




### Check of Battery Electrolyte Level

1. Check the battery electrolyte level.
2. If the level is below the lower level line (2), fill each cell with distilled water until the upper level line.

- |                      |                      |
|----------------------|----------------------|
| (1) Upper Level Line | (2) Lower Level Line |
|----------------------|----------------------|

M00000003GEG0015US1



### Fan Belt Tension

1. Push the belt halfway between the fan drive pulley and alternator pulley at a specified force 98 N (10 kgf, 22 lbf) to measure the deflection (A).
2. If the measurement is out of the factory specifications, loosen the alternator mounting screws and adjust its position.

|                |                       |                                   |
|----------------|-----------------------|-----------------------------------|
| Deflection (A) | Factory specification | 7.0 to 9.0 mm<br>0.28 to 0.35 in. |
|----------------|-----------------------|-----------------------------------|

(A) Deflection

M00000003GEG0016US1




**Fan Belt Damage and Wear**

- 1. Check the fan belt for damage.
- 2. If the fan belt has a damage, replace it.
- 3. Check if the fan belt is worn out and sunk in the pulley groove.
- 4. If it is, replace it.



(A) Good

(B) Bad

M00000003GEG0017US1



# [5] CHECK POINTS FOR EVERY 150 HOURS



## Change of Engine Oil (for 90 mm (3.5 in.) Depth Oil Pan)

[D1503-M, D1703-M, D1803-M, V2003-M, V2203-M, V2403-M, D1703-M-BG, V2003-M-BG, V2003-M-T-BG, V2203-M-BG, V2403-M-BG]

### ⚠ CAUTION

- **Make sure that you stop the engine before you change the engine oil.**
1. Start and warm-up the engine for approximately 5 minutes.
  2. Put an oil pan below the engine.
  3. Remove the drain plug (1) at the bottom of the engine and drain the oil fully.
  4. Tighten the drain plug (1).
  5. Fill new oil until the upper line on the dipstick (2).

### ■ IMPORTANT

- **When you use an oil of different brand or viscosity from the previous, drain the remaining oil. Do not mix 2 different types of oil.**
- **Engine oil must have the properties of API classification CF/CF-4/CG-4/CH-4/CI-4.**
- **Use the correct SAE Engine Oil by reference to the ambient temperature.**

|                                |                                      |
|--------------------------------|--------------------------------------|
| Above 25 °C (77 °F)            | SAE 30 or<br>SAE 10W-30, SAE 10W-40  |
| 0 °C to 25 °C (32 °F to 77 °F) | SAE 20 or<br>SAE 10W-30, SAE 10W-40  |
| Below 0 °C (32 °F)             | SAE 10W or<br>SAE 10W-30, SAE 10W-40 |


| Models   | Oil Pan Depth         |
|--|-----------------------|
|  | *90 mm (3.5 in.)      |
| D1503-M, D1703-M,<br>D1803-M, D1703-M-BG   | 5.6 L<br>1.5 U.S.gals |
| V2003-M, V2203-M,<br>V2403-M, V2003-M-BG,<br>V2003-M-T-BG,<br>V2203-M-BG, V2403-M-BG | 7.6 L<br>2.0 U.S.gals |

\*90 mm (3.5 in.) oil pan depth is optional.

(1) Drain Plug

(2) Dipstick

M00000003GEG0018US1



### **Replacement of Oil Filter Cartridge (for 90 mm (3.5 in.) Depth Oil Pan)**

**[D1503-M, D1703-M, D1803-M, V2003-M, V2203-M, V2403-M, D1703-M-BG, V2003-M-BG, V2003-M-T-BG, V2203-M-BG, V2403-M-BG]**

#### **⚠ CAUTION**

- **Make sure that you stop the engine before you replace the oil filter cartridge.**

1. Remove the oil filter cartridge (1) with the filter wrench.
2. Apply a thin layer of oil on the new cartridge gasket.
3. Install the new cartridge by hand. Do not tighten too much because it can cause deformation of the rubber gasket.
4. After you replace the cartridge, the engine oil usually decrease by a small level. Make sure that the engine oil does not flow through the seal and read the oil level on the dipstick.
5. Fill the engine oil until the specified level.



#### **■ IMPORTANT**

- **To prevent serious damage to the engine, use only KUBOTA genuine filters or its equivalent.**

(1) Oil Filter Cartridge

M00000003GEG0019US1

## [6] CHECK POINTS FOR EVERY 200 HOURS



### Change of Engine Oil (for 124 mm (4.88 in.) Depth Oil Pan)

[D1503-M, D1703-M, D1803-M, V2003-M, V2203-M, V2403-M, V2403-M-T, D1703-M-BG, V2003-M-BG, V2003-M-T-BG, V2203-M-BG, V2403-M-BG]

#### CAUTION

- **Make sure that you stop the engine before you change the engine oil.**
1. Start and warm-up the engine for approximately 5 minutes.
  2. Put an oil pan below the engine.
  3. Remove the drain plug (1) at the bottom of the engine and drain the oil fully.
  4. Tighten the drain plug (1).
  5. Fill new oil until the upper line on the dipstick (2).

#### ■ IMPORTANT

- **When you use an oil of different brand or viscosity from the previous, drain the remaining oil. Do not mix 2 different types of oil.**
- **Engine oil must have the properties of API classification CF/CF-4/CG-4/CH-4/CI-4.**
- **Use the correct SAE Engine Oil by reference to the ambient temperature.**



|                                |                                      |
|--------------------------------|--------------------------------------|
| Above 25 °C (77 °F)            | SAE 30 or<br>SAE 10W-30, SAE 10W-40  |
| 0 °C to 25 °C (32 °F to 77 °F) | SAE 20 or<br>SAE 10W-30, SAE 10W-40  |
| Below 0 °C (32 °F)             | SAE 10W or<br>SAE 10W-30, SAE 10W-40 |

| Models   | Oil Pan Depth         |
|--|-----------------------|
|  | 124 mm (4.88 in.)     |
| D1503-M, D1703-M,<br>D1803-M, D1703-M-BG   | 7.0 L<br>1.8 U.S.gals |
| V2003-M, V2203-M,<br>V2403-M, V2003-M-BG,<br>V2003-M-T-BG,<br>V2203-M-BG, V2403-M-BG | 9.5 L<br>2.5 U.S.gals |
| V2403-M-T  | 9.5 L<br>2.5 U.S.gals |

(1) Drain Plug

(2) Dipstick

M00000003GEG0020US1



**Change of Engine Oil (for 90 mm (3.5 in.) Depth Oil Pan)**

[D1803-M-DI, V2403-M-DI, V2403-M-DI-T]

**⚠ CAUTION**

• **Make sure that you stop the engine before you change the engine oil.**

1. Start and warm-up the engine for approximately 5 minutes.
2. Put an oil pan below the engine.
3. Remove the drain plug (1) at the bottom of the engine and drain the oil fully.
4. Tighten the drain plug (1).
5. Fill new oil until the upper line on the dipstick (2).

**■ IMPORTANT**

- **When you use an oil of different brand or viscosity from the previous, drain the remaining oil. Do not mix 2 different types of oil.**
- **Engine oil must have the properties of API classification CF/CF-4/CG-4/CH-4/CI-4.**
- **Use the correct SAE Engine Oil by reference to the ambient temperature.**

|                                |                                      |
|--------------------------------|--------------------------------------|
| Above 25 °C (77 °F)            | SAE 30 or<br>SAE 10W-30, SAE 10W-40  |
| 0 °C to 25 °C (32 °F to 77 °F) | SAE 20 or<br>SAE 10W-30, SAE 10W-40  |
| Below 0 °C (32 °F)             | SAE 10W or<br>SAE 10W-30, SAE 10W-40 |


| Models                   | Oil Pan Depth         |
|--------------------------|-----------------------|
|                          | *90 mm (3.5 in.)      |
| D1803-M-DI               | 5.6 L<br>1.5 U.S.gals |
| V2403-M-DI, V2403-M-DI-T | 7.6 L<br>2.0 U.S.gals |

\*90 mm (3.5 in.) oil pan depth is optional.

(1) Drain Plug

(2) Dipstick

M00000003GEG0021US1



### Replacement of Oil Filter Cartridge (for 124 mm (4.88 in.) Depth Oil Pan)

[D1503-M, D1703-M, D1803-M, V2003-M, V2203-M, V2403-M, V2403-M-T, D1703-M-BG, V2003-M-BG, V2003-M-T-BG, V2203-M-BG, V2403-M-BG]

#### **⚠ CAUTION**

- **Make sure that you stop the engine before you replace the oil filter cartridge.**


1. Remove the oil filter cartridge (1) with the filter wrench.
2. Apply a thin layer of oil on the new cartridge gasket.
3. Install the new cartridge by hand. Do not tighten too much because it can cause deformation of the rubber gasket.
4. After you replace the cartridge, the engine oil usually decrease by a small level. Make sure that the engine oil does not flow through the seal and read the oil level on the dipstick.
5. Fill the engine oil until the specified level.

#### **■ IMPORTANT**

- **To prevent serious damage to the engine, use only KUBOTA genuine filters or its equivalent.**

(1) Oil Filter Cartridge

M00000003GEG0022US1



### Replacement of Oil Filter Cartridge (for 90 mm (3.5 in.) Depth Oil Pan)

[D1803-M-DI, V2403-M-DI, V2403-M-DI-T]

#### **⚠ CAUTION**

- **Make sure that you stop the engine before you replace the oil filter cartridge.**


1. Remove the oil filter cartridge (1) with the filter wrench.
2. Apply a thin layer of oil on the new cartridge gasket.
3. Install the new cartridge by hand. Do not tighten too much because it can cause deformation of the rubber gasket.
4. After you replace the cartridge, the engine oil usually decrease by a small level. Make sure that the engine oil does not flow through the seal and read the oil level on the dipstick.
5. Fill the engine oil until the specified level.

#### **■ IMPORTANT**

- **To prevent serious damage to the engine, use only KUBOTA genuine filters or its equivalent.**

(1) Oil Filter Cartridge

M00000003GEG0023US1




### Check of Radiator Hoses and Clamp Bands

1. Make sure that the radiator hoses connections are correct for every 200 hours of operation or every 6 months, whichever comes first.
2. If the clamp is loose, apply oil to the threads and tighten it again correctly.
3. The radiator hose material is rubber and deteriorates naturally. You must replace the radiator hose every 2 years. Also replace the clamp and tighten it correctly.

(1) Upper Hose

(2) Lower Hose

M00000003GEG0024US1



**Check of Intake Air Line**

1. Make sure that the intake air hose(s) connections are correct for every 200 hours of operation.
2. If the clamp is loose, apply oil to the threads and tighten it again correctly.
3. The intake air hose material is rubber and deteriorates naturally. You must replace the intake air hose(s) every 2 years. Also replace the clamp and tighten it correctly.

**IMPORTANT**


- To prevent serious damage to the engine, keep out dust in the intake air line.

(1) Intake Air Hose

(2) Clamp

M00000003GEG0025US1

**[7] CHECK POINTS FOR EVERY 400 HOURS**



**Change of Engine Oil (for 124 mm (4.88 in.) Depth Oil Pan)**

**[D1803-M-DI, V2403-M-DI, V2403-M-DI-T]**


**CAUTION**

- Make sure that you stop the engine before you change the engine oil.

1. Start and warm-up the engine for approximately 5 minutes.
2. Put an oil pan below the engine.
3. Remove the drain plug (1) at the bottom of the engine and drain the oil fully.
4. Tighten the drain plug (1).
5. Fill new oil until the upper line on the dipstick (2).

**IMPORTANT**

- When you use an oil of different brand or viscosity from the previous, drain the remaining oil. Do not mix 2 different types of oil.
- Engine oil must have the properties of API classification CF/CF-4/CG-4/CH-4/CI-4.
- Use the correct SAE Engine Oil by reference to the ambient temperature.




|                                |                                      |
|--------------------------------|--------------------------------------|
| Above 25 °C (77 °F)            | SAE 30 or<br>SAE 10W-30, SAE 10W-40  |
| 0 °C to 25 °C (32 °F to 77 °F) | SAE 20 or<br>SAE 10W-30, SAE 10W-40  |
| Below 0 °C (32 °F)             | SAE 10W or<br>SAE 10W-30, SAE 10W-40 |

| Models                   | Oil Pan Depth         |
|--------------------------|-----------------------|
|                          | 124 mm (4.88 in.)     |
| D1803-M-DI               | 7.0 L<br>1.8 U.S.gals |
| V2403-M-DI, V2403-M-DI-T | 9.5 L<br>2.5 U.S.gals |

(1) Drain Plug

(2) Dipstick

M00000003GEG0026US1



### **Replacement of Oil Filter Cartridge (for 124 mm (4.88 in.) Depth Oil Pan)**

[D1803-M-DI, V2403-M-DI, V2403-M-DI-T]

#### **CAUTION**

- **Make sure that you stop the engine before you replace the oil filter cartridge.**


1. Remove the oil filter cartridge (1) with the filter wrench.
2. Apply a thin layer of oil on the new cartridge gasket.
3. Install the new cartridge by hand. Do not tighten too much because it can cause deformation of the rubber gasket.
4. After you replace the cartridge, the engine oil usually decrease by a small level. Make sure that the engine oil does not flow through the seal and read the oil level on the dipstick.
5. Fill the engine oil until the specified level.

#### **IMPORTANT**

- **To prevent serious damage to the engine, use only KUBOTA genuine filters or its equivalent.**

(1) Oil Filter Cartridge

M00000003GEG0027US1




### **Replacement of Fuel Filter Cartridge (Cartridge Type)**

The fuel filter cartridge collects water and dust in the fuel. In service, replace the fuel filter cartridge every 400 hours.

1. Remove the used filter cartridge (1) with filter wrench.
2. Apply a thin layer of fuel to the surface of the new filter cartridge gasket before you put it on.
3. Tighten the new cartridge by hand.
4. Bleed the fuel system.

(1) Fuel Filter Cartridge

M00000003GEG0028US1



### **Replacement of Fuel Filter Element (Element Type)**





1. Close the fuel cock (3).
2. Remove the retaining ring (6).
3. Remove the filter cup (5).
4. Flush the inner side with kerosene.
5. Replace the filter element (4) with a new one.
6. Keep out dust and dirt from work area and then assemble the fuel filter again.
7. Bleed the fuel system.

(1) Cock Body  
(2) Air Vent Plug  
(3) Fuel Cock

(4) Filter Element  
(5) Filter Cup  
(6) Retaining Ring

M00000003GEG0029US1

## [8] CHECK POINTS FOR EVERY 500 HOURS



### Cleaning of Water Jacket and Radiator Interior

#### **CAUTION**

- Do not remove the radiator cap when the engine is hot. Then loosen the cap slightly to release unwanted pressure before you remove the cap fully.
1. Stop the engine and let the coolant temperature decrease.
  2. Remove the radiator cap (1) to drain the coolant fully.
  3. Open the drain cock (2) and (3).
  4. After you drained all coolant, close the drain cocks.
  5. Fill with clean water and cooling system cleaner.
  6. Obey the directions of the cleaner instruction.
  7. After you flush, fill with clean water and anti-freeze until the coolant level is immediately below the port. Install the radiator cap (1) correctly.
  8. Fill with the coolant until the "FULL" **A** mark on the recovery tank (4).
  9. Start and operate the engine for a few minutes.
  10. Stop the engine and let the coolant temperature decrease. Check the coolant level of radiator and recovery tank (4) and add coolant if necessary.


#### **IMPORTANT**

- Do not start the engine without coolant.
- Use clean and soft water with anti-freeze to fill the radiator and recovery tank.
- Make sure that when you mix the anti-freeze and water, the ratio of anti-freeze is less than 50 %.
- Make sure that you close the radiator cap correctly. If the cap is loose or incorrectly closed, coolant can flow out and the engine can overheat.

- (1) Radiator Cap  
 (2) Drain Cock  
 (3) Drain Cock  
 (4) Recovery Tank

**A : FULL**  
**B : LOW**

M00000003GEG0030US1



**Anti-freeze**

- There are 2 types of anti-freeze available : use the permanent type (PT) for this engine.
- When you add anti-freeze for the first time, flush the water jacket and radiator interior with clean, soft water several times.
- The brand of the anti-freeze and the ambient temperature have an effect on the procedure to mix water and anti-freeze. Refer to the SAE J1034 standard, especially to the SAE J814c.
- Mix the anti-freeze with clean, soft water, and then fill into the radiator.

■ **IMPORTANT**

- **Make sure that when you mix the anti-freeze and water, the ratio of anti-freeze is less than 50 %.**


| Vol %<br>Anti-freeze | Freezing Point |     | Boiling Point* |     |
|----------------------|----------------|-----|----------------|-----|
|                      | °C             | °F  | °C             | °F  |
| 40                   | -24            | -11 | 106            | 223 |
| 50                   | -37            | -35 | 108            | 226 |

\* At 1.01 × 100000 Pa (760 mmHg) pressure (atmospheric). Use a radiator pressure cap that lets the pressure collect in the cooling system to get a higher boiling point.

■ **NOTE**

- **The above data is the industrial standards that shows the minimum glycol content necessary in the concentrated anti-freeze.**
- **When the coolant level decreases because of evaporation, add clean, soft water only to keep the anti-freeze mixing ratio less than 50 %. If there is a leakage, add anti-freeze and clean, soft water in the specified mixing ratio.**
- **The anti-freeze absorbs moisture. Keep new anti-freeze in a tightly sealed container.**
- **Do not use the radiator cleaning agents after you add anti-freeze to the coolant. Anti-freeze contains an anti-corrosive agent, which reacts with the radiator cleaning agent to make sludge and cause damages to the engine parts.**

M00000003GEG0031US1



**Replacement of Fan Belt**

1. Remove the alternator.
2. Remove the fan belt (1).
3. Replace the fan belt with a new one.
4. Install the alternator.
5. Check the fan belt tension.

| Deflection (A) | Factory specification | 7.0 to 9.0 mm (0.28 to 0.35 in.) deflection at 98 N (10 kgf, 22 lbf) of force |
|----------------|-----------------------|---|
|----------------|-----------------------|---|

(1) Fan Belt

(A) Deflection

M00000003GEG0032US1

## [9] CHECK POINTS FOR EVERY 1 OR 2 MONTHS

### Recharge of Battery



#### CAUTION

- The battery gas can cause an explosion. Keep the sparks and open flames away from the battery at all times, especially when you charge the battery.
- When you charge the battery, remove the battery vent plugs.
- When you disconnect the cable from the battery, start with the negative terminal first. When you connect the cable to the battery, start with the positive terminal first.
- Do not put an object made of metal across the terminals to do a test on the battery charge. Use a voltmeter or hydrometer to do a test on the battery charge.

#### 1) Slow Charge

1. Add distilled water if the electrolyte level is low. When you charge, the quantity of electrolyte must be lower than the specified level to make sure that it does not spill.
2. Connect the battery to the charging unit, obey the manufacturer instructions.
3. When you charge, remove all vent plugs to release the battery gas.
4. The electrolyte temperature must not be more than 40 °C (104 °F) when you charge.  
If it is more than 40 °C (104 °F), decrease the charging amperage or do not charge for a while.
5. When you charge a few batteries in series, charge at the rate of the smallest battery in the line.


#### 2) Quick Charge

1. Find the correct current and time to charge at with the tester attached to the quick charger.
2. Find the correct current that you charge at as 1/1 of the battery capacity. If the battery capacity is more than 50 Ah, use 50 A as the maximum.

#### ■ Precaution when you operate a Quick Charger

- The type of quick charger is different on its operation.  
Refer to the instruction manual.

M0000003GEG0033US1



### Battery Specific Gravity

#### ⚠ CAUTION

- If battery acid (dilute sulfuric acid) gets on you it could cause blindness or burns, or could cause corrosion of machinery and tools so please be careful when handling.
- Wear safety glasses and rubber gloves when performing battery maintenance and inspection (measuring specific gravity, replenishing water, or charging).
- If the gas that is generated is ignited by an ignition source, it may explode so be very careful with sparks and fire.
- Keep your body and face as far away from the battery as you can when performing maintenance and inspection.
- Do not allow people who do not know how to handle a battery or who do not sufficiently understand the danger perform inspection or maintenance.

#### (Measurement items)

##### ■ Zero adjustment

1. Open the cover and drip water on the prism surface using the included rod.
2. Close the cover.
3. Aim in a direction that is bright, look into the lens, and adjust the focus until the gradations can be seen clearly.
4. If the boundary line is not on the gradation baseline (0 position), turn the adjustment screw until it matches.
5. When zero adjustment is complete, wipe the prism and cover surface with a soft cloth or tissue paper.

##### ■ Measurement of test fluid

1. Open the cover and drip test fluid on the prism surface using the included rod.
2. Close the cover.
3. Aim in a direction that is bright, look into the lens and read the gradation of the blue boundary line.
4. When the measurement is complete, wipe the prism and cover surface with a soft cloth or tissue paper.

#### (Reference)

Electrolyte specific gravity and amount of discharge.  
Use the following table as a reference.

|                                  |                            |
|----------------------------------|----------------------------|
| (A) Electrolyte Specific Gravity | (C) Good                   |
| (B) Discharge                    | (D) Charging is necessary. |

#### ■ NOTE


##### Temperature conversion of electrolyte specific gravity

- Battery electrolyte specific gravity changes based on temperature.
- Insert the value identified on a specific gravity meter into the following conversion equation for temperature correction to learn an accurate specific gravity value. (Standard temperature assumed to be 20 °C (68 °F))  

$$D_{20} = D_t + 0.0007 (t - 20)$$


$$D_{20} = \text{specific gravity value converted to standard temperature of } 20 \text{ } ^\circ\text{C (68 } ^\circ\text{F)}$$

$$D_t = \text{measured specific gravity value at the electrolyte temperature } t \text{ } ^\circ\text{C}$$



9Y1210257GEG0003US0

## [10] CHECK POINTS FOR EVERY YEAR



### Replacement of Air Cleaner Element




1. Remove used air cleaner element.
2. Replace it with a new one.

#### ■ NOTE

- The air cleaner uses a dry element. Do not apply oil to it.
- Do not operate the engine without the filter element.

M00000003GEG0035US1

# [11] CHECK POINTS FOR EVERY 800 HOURS



## Valve Clearance

### ■ IMPORTANT

- You must check and adjust the valve clearance when the engine is cold.

- Remove the head cover.
- Align the "1TC" mark line (3) on the flywheel and projection (2) on the housing. Make sure that the No.1 piston comes to the compression or overlap top dead center.
- Check the subsequent valve clearance (1) at the mark "☆" with a feeler gauge.
- If the clearance is out of the factory specifications, adjust with the adjusting screw.

|                 |                       |   |
|-----------------|-----------------------|---|
| Valve clearance | Factory specification | 0.18 to 0.22 mm<br>0.0071 to 0.0086 in. |
|-----------------|-----------------------|---|

### ■ NOTE

- The "1TC" mark line on the flywheel is only for the No. 1 cylinder. There is no "TC" mark for the other cylinders.
- Align the "TC" mark with the projection (2) in the window on the flywheel-housing. No. 1 piston is on the top dead center position at this time. Turn the flywheel 0.26 rad (15 °) to see if the piston is at the compression top dead center or the overlap position. Refer to the table below to adjust the valve clearance (1) again. (The piston is at the compression top dead center when both the IN. and EX. valves do not move. The piston is at the overlap position when both the valves move.)
- Turn the flywheel 6.28 rad (360 °) and align the "1TC" mark line with the projection (2) correctly. Adjust all the other valve clearance if necessary.
- After you turn the flywheel counterclockwise 2 or 3 times, check the valve clearance (1) again.
- After you adjust the valve clearance (1), tighten the lock nut of the adjusting screw.

| Adjustable Cylinder Location of Piston              |       | Valve Arrangement |     |            |     |
|---|-------|-------------------|-----|------------|-----|
|   |       | 3 Cylinder        |     | 4 Cylinder |     |
|   |       | IN.               | EX. | IN.        | EX. |
| When No. 1 piston is at compression top dead center | No. 1 | ☆                 | ☆   | ☆          | ☆   |
|   | No. 2 |                   | ☆   | ☆          |     |
|   | No. 3 | ☆                 |     |            | ☆   |
|   | No. 4 | —                 | —   |            |     |
| When No. 1 piston is at overlap position            | No. 1 |                   |     |            |     |
|   | No. 2 | ☆                 |     |            | ☆   |
|   | No. 3 |                   | ☆   | ☆          |     |
|   | No. 4 | —                 | —   | ☆          | ☆   |

- (1) Valve Clearance  
(2) Projection

- (3) 1TC Mark Line


M0000003GEG0036US1

# [12] CHECK POINTS FOR EVERY 1500 HOURS

## CAUTION

- Check the injection pressure and condition after you make sure that there is no one in the direction of the fumes.
- If the fumes from the nozzle directly touches the human body, they can cause damage to the cells and blood poisoning.

M00000003GEG0037US1



### Nozzle Fume Condition


[D1503-M, D1703-M, D1803-M, V2003-M, V2203-M, V2403-M, V2403-M-T, D1703-M-BG, V2003-M-BG, V2003-M-T-BG, V2203-M-BG, V2403-M-BG]

1. Set the injection nozzle to a nozzle tester, and check the condition of the fumes from the nozzle.
2. If the fume condition is defective, replace the nozzle piece.

(A) Good

(B) Bad

M00000003GEG0038US1



### Nozzle Fume Condition

[D1803-M-DI, V2403-M-DI, V2403-M-DI-T]


1. Set the injection nozzle to a nozzle tester, and check the condition of the fumes from the nozzle.
2. If the fume condition is defective, replace the injection nozzle assembly.

(A) Good

(a) 1.3 rad (72 °)

(B) Bad

M00000003GEG0039US1



### Fuel Injection Pressure

[D1503-M, D1703-M, D1803-M, V2003-M, V2203-M, V2403-M, V2403-M-T, D1703-M-BG, V2003-M-BG, V2003-M-T-BG, V2203-M-BG, V2403-M-BG]

1. Set the injection nozzle to a nozzle tester.
2. Slowly move the tester lever to measure the pressure at which the fuel start to jet out from the nozzle.
3. If the measurement is out of the factory specifications, replace the adjusting washer (1) in the nozzle holder.


#### **(Reference)**


- The pressure variation with 0.025 mm (0.00098 in.) difference in washer thickness is approximately 590 kPa (6.0 kgf/cm<sup>2</sup>, 85 psi).

|                         |                       |  |
|-------------------------|-----------------------|--|
| Fuel injection pressure | Factory specification | 13.73 to 14.70 MPa<br>140.0 to 150.0 kgf/cm <sup>2</sup><br>1992 to 2133 psi |
|-------------------------|-----------------------|--|

(1) Adjusting Washer

M00000003GEG0040US1






**Fuel Injection Pressure**

**[D1803-M-DI, V2403-M-DI, V2403-M-DI-T]**

1. Set the injection nozzle to a nozzle tester.
2. Slowly move the tester lever to measure the pressure at which the fuel start to jet out from the nozzle.
3. If the measurement is out of the factory specifications, replace the injection nozzle assembly.

|                                     |                       |  |
|-------------------------------------|-----------------------|--|
| Fuel injection pressure (1st stage) | Factory specification | 18.64 to 20.10 MPa<br>190.0 to 205.0 kgf/cm <sup>2</sup><br>2703 to 2915 psi |
|-------------------------------------|-----------------------|--|

M00000003GEG0041US1




**Valve Seat Tightness**

**[D1503-M, D1703-M, D1803-M, V2003-M, V2203-M, V2403-M, V2403-M-T, D1703-M-BG, V2003-M-BG, V2003-M-T-BG, V2203-M-BG, V2403-M-BG]**

1. Set the injection nozzle to a nozzle tester.
2. Increase the fuel pressure, and keep it at 12.75 MPa (130.0 kgf/cm<sup>2</sup>, 1849 psi) for 10 seconds.
3. If you find a fuel leakage, replace the nozzle piece.

|                      |                       |   |
|----------------------|-----------------------|---|
| Valve seat tightness | Factory specification | No fuel leak at<br>12.75 MPa<br>130.0 kgf/cm <sup>2</sup><br>1849 psi |
|----------------------|-----------------------|---|

M00000003GEG0042US1




**Valve Seat Tightness**

**[D1803-M-DI, V2403-M-DI, V2403-M-DI-T]**

1. Set the injection nozzle to a nozzle tester.
2. Increase the fuel pressure, and keep it at 16.67 MPa (170.0 kgf/cm<sup>2</sup>, 2418 psi) for 10 seconds.
3. If you find a fuel leakage, replace the injection nozzle assembly.

|                      |                       |   |
|----------------------|-----------------------|---|
| Valve seat tightness | Factory specification | No fuel leak at<br>16.67 MPa<br>170.0 kgf/cm <sup>2</sup><br>2418 psi |
|----------------------|-----------------------|---|

M00000003GEG0043US1



**Nozzle Holder**

[D1503-M, D1703-M, D1803-M, V2003-M, V2203-M, V2403-M, V2403-M-T, D1703-M-BG, V2003-M-BG, V2003-M-T-BG, V2203-M-BG, V2403-M-BG]

1. Hold the nozzle retaining nut (7) with a vise.
2. Remove the nozzle holder (1), and remove the internal parts.

**(When reassembling)**


- Assemble the nozzle in clean fuel oil.
- Install the push rod (4) correctly in its direction.
- After you assemble the nozzle, adjust the fuel injection pressure.

|                   |                             |   |
|-------------------|-----------------------------|---|
| Tightening torque | Nozzle holder               | 35 to 39 N·m<br>3.5 to 4.0 kgf·m<br>26 to 28 lbf·ft |
|                   | Overflow pipe retaining nut | 20 to 24 N·m<br>2.0 to 2.5 kgf·m<br>15 to 18 lbf·ft |
|                   | Nozzle holder assembly      | 49 to 68 N·m<br>5.0 to 7.0 kgf·m<br>37 to 50 lbf·ft |

- |                      |                          |
|----------------------|--------------------------|
| (1) Nozzle Holder    | (5) Distance Piece       |
| (2) Adjusting Washer | (6) Nozzle Piece         |
| (3) Nozzle Spring    | (7) Nozzle Retaining Nut |
| (4) Push Rod         |                          |

M00000003GEG0044US1

## [13] CHECK POINTS FOR EVERY 3000 HOURS



### Check of Turbocharger

#### **Turbine Side**

1. Check the exhaust port (2) and the inlet port (3) side of the turbine housing (1) for exhaust gas leakage.
2. If you find a gas leakage, tighten the bolts and nuts again or replace the gasket with a new one.

#### **Compressor Side**



1. Check the inlet hose (4) of the compressor cover (5) for air leakage.
2. Check the suction side of the intake hose for loose connections or cracks.
3. If you find an air leakage, change the clamp (6) and / or the inlet hoses.


#### **Radial Clearance**

1. If the wheel touches the housing, replace the turbocharger assembly with a new one.

- |                     |                      |
|---------------------|----------------------|
| (1) Turbine Housing | (4) Inlet Hose       |
| (2) Exhaust Port    | (5) Compressor Cover |
| (3) Inlet Port      | (6) Clamp            |

M00000003GEG0045US1





**Check of Injection Pump**

[D1503-M, D1703-M, D1803-M, V2003-M, V2203-M, V2403-M, V2403-M-T, D1703-M-BG, V2003-M-BG, V2003-M-T-BG, V2203-M-BG, V2403-M-BG]

**Fuel Tightness of Pump Element**

1. Remove the engine stop solenoid.
2. Remove the injection pipes and glow plugs.
3. Set the injection pump pressure tester to the injection pump.
4. Set the injection nozzle (2) jetted with the correct injection pressure to the injection pump pressure tester (1). (Refer to the figure.)
5. Set the speed control lever to the maximum speed position.
6. Crank the engine with the starter to increase the pressure.
7. If the pressure is lower than the allowable limit, replace the pump with a new one.

You can also repair the pump at a Kubota-authorized pump service shop.

**Fuel Tightness of Delivery Valve**

1. Remove the engine stop solenoid.
2. Remove the injection pipes and glow plugs.
3. Set the pressure tester to the fuel injection pump.
4. Set the injection nozzle (2) jetted with the correct injection pressure to the injection pump pressure tester (1).
5. Crank the engine with the starter to increase the pressure.
6. Stop the starter when the fuel jets from the injection nozzle. Then turn the flywheel manually and increase the pressure to approximately 13.73 MPa (140.0 kgf/cm<sup>2</sup>, 1991 psi).
7. Turn the flywheel back about half a turn (to keep the plunger free) and keep the flywheel at this position.
8. Measure the time for the pressure to decrease from 13.73 to 12.75 MPa (from 140.0 to 130.0 kgf/cm<sup>2</sup>, from 1991 to 1849 psi).
9. If the measurement is less than allowable limit, replace the pump with a new one.

You can also repair the pump at a Kubota-authorized pump service shop.


|                                  |                       |   |
|----------------------------------|-----------------------|---|
| Fuel tightness of pump element   | Allowable limit       | 13.73 MPa<br>140.0 kgf/cm <sup>2</sup><br>1991 psi                                      |
| Fuel tightness of delivery valve | Factory specification | 10 seconds<br>13.73 → 12.75 MPa<br>140.0 → 130.0 kgf/cm <sup>2</sup><br>1991 → 1849 psi |
|                                  | Allowable limit       | 5 seconds<br>13.73 → 12.75 MPa<br>140.0 → 130.0 kgf/cm <sup>2</sup><br>1991 → 1849 psi  |

**NOTE**

- Do not try to disassemble the injection pump assembly. Repair the pump at a Kubota-authorized pump service shop.

- (1) Injection Pump Pressure Tester      (3) Protection Cover for Jetted Fuel  
 (2) Injection Nozzle

M00000003GEG0046US1



## Check of Injection Pump

[D1803-M-DI, V2403-M-DI, V2403-M-DI-T]

### Fuel Tightness of Pump Element

1. Remove the engine stop solenoid.
2. Remove the injection pipes and glow plugs.
3. Set the injection pump pressure tester to the injection pump.
4. Set the injection nozzle (2) jetted with the correct injection pressure to the injection pump pressure tester (1). (Refer to the figure.)
5. Set the speed control lever to the maximum speed position.
6. Crank the engine with the starter to increase the pressure.
7. If the pressure is lower than the allowable limit, replace the pump with a new one.

You can also repair the pump at a Kubota-authorized pump service shop.

### Fuel Tightness of Delivery Valve

1. Remove the engine stop solenoid.
2. Remove the injection pipes and glow plugs.
3. Set the pressure tester to the fuel injection pump.
4. Set the injection nozzle (2) jetted with the correct injection pressure to the injection pump pressure tester (1).
5. Crank the engine with the starter to increase the pressure.
6. Stop the starter when the fuel jets from the injection nozzle. Then turn the flywheel manually and increase the pressure to approximately 18.63 MPa (190.0 kgf/cm<sup>2</sup>, 2702 psi).
7. Turn the flywheel back about half a turn (to keep the plunger free) and keep the flywheel at this position.
8. Measure the time for the pressure to decrease from 18.63 to 17.65 MPa (from 190.0 to 180.0 kgf/cm<sup>2</sup>, from 2702 to 2560 psi).
9. If the measurement is less than allowable limit, replace the pump with a new one.

You can also repair the pump at a Kubota-authorized pump service shop.

|                                  |                       |   |
|----------------------------------|-----------------------|---|
| Fuel tightness of pump element   | Allowable limit       | 18.63 MPa<br>190.0 kgf/cm <sup>2</sup><br>2702 psi                                      |
| Fuel tightness of delivery valve | Factory specification | 10 seconds<br>18.63 → 17.65 MPa<br>190.0 → 180.0 kgf/cm <sup>2</sup><br>2702 → 2560 psi |
|                                  | Allowable limit       | 5 seconds<br>18.63 → 17.65 MPa<br>190.0 → 180.0 kgf/cm <sup>2</sup><br>2702 → 2560 psi  |


### ■ NOTE

- Do not try to disassemble the injection pump assembly. Repair the pump at a Kubota-authorized pump service shop.

- (1) Injection Pump Pressure Tester      (3) Protection Cover for Jetted Fuel  
(2) Injection Nozzle

M00000003GEG0047US1

## [14] CHECK POINTS FOR EVERY 2 YEARS



### Replacement of Intake Air Line

1. Loosen the clamp (2).
2. Remove the intake air hose (1) and clamp (2).
3. Replace the intake air hose (1) and clamp (2) with new ones.
4. Tighten the clamp (2) correctly.

#### ■ NOTE

- To prevent serious damage to the engine, keep out dust in the intake air line.

(1) Intake Air Hose

(2) Clamp

M00000003GEG0048US1


### Replacement of Battery

#### ⚠ CAUTION

- The battery gas can cause an explosion. Keep the sparks and open flames away from the battery at all times, especially when you charge the battery.
- When you charge the battery, remove the battery vent plugs.
- When you disconnect the cable from the battery, start with the negative terminal first. When you connect the cable to the battery, start with the positive terminal first.
- Do not put an object made of metal across the terminals to do a test on the battery charge. Use a voltmeter or hydrometer to do a test on the battery charge.

1. Disconnect the negative terminal and positive terminal.
2. Remove the battery holder.
3. Remove the used battery.
4. Replace the battery with a new one.
5. Tighten the battery holder.
6. Connect the positive terminal.
7. Connect the negative terminal.

M00000003GEG0049US1



### Replacement of Radiator Hoses and Clamp Bands

#### ⚠ CAUTION

- Do not remove the radiator cap when the engine is hot. Then loosen the cap to the stop to release unwanted pressure before you remove the cap fully.


1. Drain the coolant.
2. Loosen the clamp bands.
3. Remove the upper hose (1) and lower hose (2).
4. Replace the upper / lower hose (1), (2) and clamp bands with new ones.
5. Tighten the clamp bands correctly.
6. Fill with clean water and anti-freeze until the coolant level is immediately below the port. Install the radiator cap correctly.

(1) Upper Hose

(2) Lower Hose


M00000003GEG0050US1

[A]




3EEACAA1P057D

[B]




3EEACAA1P058B

[A]




3EEACAA1P059A

[B]



3EEACAA1P060A



3EEADAA1P005A

## Replacement of Fuel Hoses and Clamp Bands

### ⚠ CAUTION

- **Stop the engine before you do the check below.**
1. Loosen the clamp (2) and remove the fuel hose (1).
  2. Replace the fuel hose (1) and clamp (2) with new ones.
  3. Tighten the clamp (2) correctly.

### (When you bleed the fuel system)

1. Fill the tank with fuel.
2. Open the fuel cock (4). ([B] only)
3. Loosen the air vent plug (3) of the fuel filter by a few turns.
4. Tighten the plug when the bubbles do not come up.
5. Open the air vent cock (5) on top of the fuel injection pump.
6. **Engine with the electrical fuel feed pump**  
Turn the key to the AC position and supply the fuel with the pump for 10 to 15 seconds.

### Engine with the mechanical fuel feed pump

Set the stop lever on STOP position and crank the engine with the starter for 10 to 15 seconds.

7. Close the air vent cock correctly after you bled the air.

### ■ NOTE





- **Always keep the air vent cock on the fuel injection pump closed unless when you release the air. If not, it can cause the engine to stop.**

- (1) Fuel Hose
- (2) Clamp
- (3) Air Vent Plug
- (4) Fuel Cock
- (5) Air Vent Cock

[A] Cartridge Type

[B] Element Type

M00000003GEG0051US1



### Change of Radiator Coolant (L.L.C.)

#### ⚠ CAUTION

- **Do not remove the radiator cap when the engine is hot. Then loosen the cap slightly to release unwanted pressure before you remove the cap fully.**
1. Stop the engine and let the coolant temperature decreases.
  2. Remove the radiator cap (1) to drain the coolant fully.
  3. Open the drain cock (2) and (3).
  4. After you drained all coolant, close the drain cocks.
  5. Fill with clean water and cooling system cleaner.
  6. Obey the directions of the cleaner instruction.
  7. After you flush, fill with clean water and anti-freeze until the coolant level is immediately below the port. Install the radiator cap (1) correctly.
  8. Fill with the coolant until the "FULL" A mark on the recovery tank (4).
  9. Start and operate the engine for a few minutes.
  10. Stop the engine and let the coolant temperature decreases. Check the coolant level of radiator and recovery tank (4) and add coolant if necessary.

#### ■ IMPORTANT

- **Do not start the engine without coolant.**
- **Use clean and soft water with anti-freeze to fill the radiator and recovery tank.**
- **Make sure that when you mix the anti-freeze and water, the ratio of anti-freeze is less than 50 %.**
- **Make sure that you close the radiator cap correctly. If the cap is loose or incorrectly closed, coolant can flow out and the engine can overheat.**


- (1) Radiator Cap  
 (2) Drain Cock  
 (3) Drain Cock  
 (4) Recovery Tank

A : FULL

B : LOW

(To be continued)

(Continued)



3EEABAB1P033A

#### ■ Anti-freeze

- There are 2 types of anti-freeze available : use the permanent type (PT) for this engine.
- When you add anti-freeze for the first time, flush the water jacket and radiator interior with clean, soft water several times.
- The brand of the anti-freeze and the ambient temperature have an effect on the procedure to mix water and anti-freeze. Refer to the SAE J1034 standard, especially to the SAE J814c.
- Mix the anti-freeze with clean, soft water, and then fill into the radiator.

#### ■ IMPORTANT

- **Make sure that when you mix the anti-freeze and water, the ratio of anti-freeze is less than 50 %.**

| Vol %<br>Anti-freeze | Freezing Point |     | Boiling Point* |     |
|----------------------|----------------|-----|----------------|-----|
|                      | °C             | °F  | °C             | °F  |
| 40                   | -24            | -11 | 106            | 223 |
| 50                   | -37            | -35 | 108            | 226 |


\* At  $1.01 \times 100000$  Pa (760 mmHg) pressure (atmospheric). Use a radiator pressure cap that lets the pressure collect in the cooling system to get a higher boiling point.

#### ■ NOTE

- **The above data is the industrial standards that shows the minimum glycol content necessary in the concentrated anti-freeze.**
- **When the coolant level decreases because of evaporation, add clean, soft water only to keep the anti-freeze mixing ratio less than 50 %. If there is a leakage, add anti-freeze and clean, soft water in the specified mixing ratio.**
- **The anti-freeze absorbs moisture. Keep new anti-freeze in a tightly sealed container.**
- **Do not use the radiator cleaning agents after you add anti-freeze to the coolant. Anti-freeze contains an anti-corrosive agent, which reacts with the radiator cleaning agent to make sludge and cause damages to the engine parts.**

M00000003GEG0052US1

# 5. SPECIAL TOOLS



## Diesel Engine Compression Tester

[D1503-M, D1703-M, D1803-M, V2003-M, V2203-M, V2403-M, V2403-M-T, D1703-M-BG, V2003-M-BG, V2003-M-T-BG, V2203-M-BG, V2403-M-BG]

### Code No.


- 07909-30208 (Assembly)
- 07909-30934 (A to F)
- 07909-31211 (E and F)
- 07909-31231 (H)
- 07909-31251 (G)
- 07909-31271 (I)
- 07909-31281 (J)

### Application

- To measure the diesel engine compression and to make a decision for a large overhaul if necessary.

- |               |                |
|---------------|----------------|
| (1) Gauge     | (7) Adaptor F  |
| (2) L Joint   | (8) Adaptor G  |
| (3) Adaptor A | (9) Adaptor H  |
| (4) Adaptor B | (10) Adaptor I |
| (5) Adaptor C | (11) Adaptor J |
| (6) Adaptor E |                |

M00000003GEG0053US1



## Diesel Engine Compression Tester (for Glow Plug)

[D1803-M-DI, V2403-M-DI, V2403-M-DI-T]

### Code No.

- 07909-39081 (Assembly)
- 07909-31291 (K)
- 07909-31301 (L)
- 07909-31311 (M)

### Application


- To measure the diesel engine compression and to make a decision for a large overhaul if necessary.

### Adaptor

- The adaptor K is necessary for the 03-M-DI.

- |                   |               |
|-------------------|---------------|
| (1) Gauge         | (4) Adaptor K |
| (2) Hose Assembly | (5) Adaptor L |
| (3) L Joint       | (6) Adaptor M |

M00000003GEG0054US1



## Oil Pressure Tester

### Code No.

- 07916-32032





### Application

- To measure the engine oil pressure.

- |                    |               |
|--------------------|---------------|
| (1) Gauge          | (5) Adaptor 2 |
| (2) Cable          | (6) Adaptor 3 |
| (3) Threaded Joint | (7) Adaptor 4 |
| (4) Adaptor 1      | (8) Adaptor 5 |

M00000003GEG0055US1





### Valve Guide Replacing Tool

#### Application

- To press out and press fit the valve guide.

|      |  |
|------|--|
| A    | 225 mm (8.86 in.)                              |
| B    | 70 mm (2.8 in.)                                |
| C    | 45 mm (1.8 in.)                                |
| D    | 20 mm dia. (0.79 in. dia.)                     |
| E    | 12.7 to 12.9 mm dia. (0.500 to 0.507 in. dia.) |
| F    | 7.50 to 7.60 mm dia. (0.296 to 0.299 in. dia.) |
| G    | 25 mm dia. (0.98 in. dia.)                     |
| H    | 7.70 to 8.00 mm dia. (0.304 to 0.314 in. dia.) |
| I    | 5 mm (0.2 in.)                                 |
| J    | 20 mm dia. (0.79 in. dia.)                     |
| K    | 13.5 to 13.8 mm dia. (0.532 to 0.543 in. dia.) |
| L    | 8.90 to 9.10 mm (0.351 to 0.358 in.)           |
| C1   | Chamfer 1.0 mm (0.039 in.)                     |
| C2   | Chamfer 2.0 mm (0.079 in.)                     |
| C0.3 | Chamfer 0.3 mm (0.01 in.)                      |

M00000003GEG0058US1

### Bushing Replacing Tools

#### Application

- To press out and press fit the bushing.

#### 1) For small end bushing

|   |  |
|---|--|
| A | 162 mm (6.38 in.)                                  |
| B | 35 mm (1.4 in.)                                    |
| C | 27 mm (1.1 in.)                                    |
| D | 35 mm dia. (1.4 in. dia.)                          |
| E | 27.90 to 27.95 mm dia. (1.099 to 1.100 in. dia.)   |
| F | 25.00 to 25.01 mm dia. (0.9843 to 0.9846 in. dia.) |

#### 2) For idle gear bushing

|   |  |
|---|--|
| A | 175 mm (6.89 in.)                                    |
| B | 40 mm (1.6 in.)                                      |
| C | 38 mm (1.5 in.)                                      |
| D | 45 mm dia. (1.8 in. dia.)                            |
| E | 41.90 to 41.95 mm dia. (1.650 to 1.651 in. dia.)     |
| F | 37.950 to 37.970 mm dia. (1.4941 to 1.4948 in. dia.) |

M00000003GEG0059US1


### Flywheel Stopper

#### Application

- To loosen and tighten the flywheel screw.

|   |                            |
|---|----------------------------|
| A | 20 mm (0.79 in.)           |
| B | 15 mm (0.59 in.)           |
| C | 10 mm dia. (0.39 in. dia.) |
| D | 30 mm (1.2 in.)            |
| E | 8 mm (0.3 in.)             |
| F | 200 mm (7.87 in.)          |

M00000003GEG0060US1



3TMABAB0P068A

**Crankshaft Bearing 1 Replacing Tool**

**Application**

- To press out and press fit the crankshaft bearing 1.

**[1] Extracting tool**

|   |  |
|---|--|
| A | 135 mm (5.31 in.)                                |
| B | 72 mm (2.8 in.)                                  |
| C | 40 mm radius (1.6 in. radius)                    |
| D | 10 mm (0.39 in.)                                 |
| E | 20 mm (0.79 in.)                                 |
| F | 20 mm dia. (0.79 in. dia.)                       |
| G | 64.80 to 64.90 mm dia. (2.552 to 2.555 in. dia.) |
| H | 59.80 to 59.90 mm dia. (2.355 to 2.358 in. dia.) |

**[2] Inserting tool**


|   |  |
|---|--|
| A | 130 mm (5.12 in.)                                |
| B | 72 mm (2.8 in.)                                  |
| C | 40 mm radius (1.6 in. radius)                    |
| D | 9 mm (0.4 in.)                                   |
| E | 4 mm (0.2 in.)                                   |
| F | 20 mm (0.79 in.)                                 |
| G | 20 mm dia. (0.79 in. dia.)                       |
| H | 68 mm dia. (2.7 in. dia.)                        |
| I | 59.80 to 59.90 mm dia. (2.355 to 2.358 in. dia.) |
| J | 64.80 to 64.90 mm dia. (2.552 to 2.555 in. dia.) |

M00000003GEG0061US1

**Socket Wrench for Crank Pulley Nut (46 mm Deep Socket Wrench)**

**Application**



- To loosen and tighten the mounting nut of fan drive pulley.



3EEADAE0P001A

|   |                              |
|---|------------------------------|
| A | 100 mm (3.94 in.)            |
| B | 25.0 mm (0.984 in.)          |
| C | 27.0 mm (1.06 in.)           |
| D | 45.0 mm dia. (1.77 in. dia.) |
| E | 35.0 mm dia. (1.38 in. dia.) |
| F | 62.5 mm dia. (2.46 in. dia.) |
| G | 46.0 mm (1.81 in.)           |

M00000003GEG0062US1



**Auxiliary Socket for Fixing Crankshaft Sleeve**

**Application**

- To fix the crankshaft sleeve of the diesel engine.



|          |  |
|----------|--|
| <b>A</b> | 80.0 mm (3.15 in.)                               |
| <b>B</b> | 60.10 to 60.30 mm (2.367 to 2.374 in.)           |
| <b>C</b> | 80.0 mm dia. (3.15 in. dia.)                     |
| <b>D</b> | 85.0 mm dia. (3.35 in. dia.)                     |
| <b>E</b> | 60.10 to 60.30 mm dia. (2.367 to 2.374 in. dia.) |
| <b>F</b> | 26.30 to 26.40 mm (1.036 to 1.039 in.)           |
| <b>G</b> | 25.85 to 25.90 mm (1.018 to 1.019 in.)           |
| <b>H</b> | 15.0 mm (0.591 in.)                              |
| <b>I</b> | 5.0 mm (0.20 in.)                                |

- (1) Stopper
- (2) Sleeve Guide

- (3) Auxiliary Socket for Pushing

**(To be continued)**

(Continued)



**Application**

- To fix the crankshaft sleeve of the diesel engine.

|             |  |
|-------------|--|
| <b>J</b>    | 42.0 mm (1.65 in.)                                   |
| <b>K</b>    | 30.50 to 30.60 mm (1.201 to 1.204 in.)               |
| <b>L</b>    | 23.0 mm (0.906 in.)                                  |
| <b>M</b>    | 20.0 mm (0.787 in.)                                  |
| <b>N</b>    | 2.0 mm (0.079 in.)                                   |
| <b>O</b>    | 31.911 to 31.950 mm dia. (1.2564 to 1.2578 in. dia.) |
| <b>P</b>    | 30.0 mm dia. (1.18 in. dia.)                         |
| <b>Q</b>    | 5.0 mm dia. (0.20 in. dia.)                          |
| <b>R</b>    | 0.09 rad (5 °)                                       |
| <b>S</b>    | 25.0 mm dia. (0.984 in. dia.)                        |
| <b>T</b>    | 60.0 mm dia. (2.36 in. dia.)                         |
| <b>U</b>    | 79.80 to 79.85 mm dia. (3.142 to 3.143 in. dia.)     |
| <b>V</b>    | 10.0 mm (0.394 in.)                                  |
| <b>W</b>    | 0.04 mm dia. (0.002 in. dia.)                        |
| <b>X</b>    | 140 mm (5.51 in.)                                    |
| <b>Y</b>    | 120 mm (4.72 in.)                                    |
| <b>Z</b>    | 110 mm (4.33 in.)                                    |
| <b>a</b>    | 50.0 mm (1.97 in.)                                   |
| <b>b</b>    | 39.90 to 40.00 mm (1.571 to 1.574 in.)               |
| <b>c</b>    | 25.0 mm (0.984 in.)                                  |
| <b>d</b>    | 90.0 mm dia. (3.54 in. dia.)                         |
| <b>e</b>    | 81.0 mm dia. (3.19 in. dia.)                         |
| <b>f</b>    | 80.10 to 80.15 mm dia. (3.154 to 3.155 in. dia.)     |
| <b>g</b>    | 30.0 mm dia. (1.18 in. dia.)                         |
| <b>h</b>    | 5.0 mm dia. (0.20 in. dia.)                          |
| <b>i</b>    | 70.0 mm (2.76 in.)                                   |
| <b>j</b>    | 50.0 mm (1.97 in.)                                   |
| <b>k</b>    | 40.0 mm dia. (1.57 in. dia.)                         |
| <b>C1</b>   | Chamfer 1.0 mm (0.039 in.)                           |
| <b>C5</b>   | Chamfer 5.0 mm (0.20 in.)                            |
| <b>C0.3</b> | Chamfer 0.3 mm (0.01 in.)                            |
| <b>R1</b>   | 1.0 mm radius (0.039 in. radius)                     |
| <b>R2</b>   | 2.0 mm radius (0.079 in. radius)                     |
| <b>R10</b>  | 10.0 mm radius (0.394 in. radius)                    |

(2) Sleeve Guide


(3) Auxiliary Socket for Pushing

M00000003GEG0063US1

**Balancer Metal Replacing Tool (for Removing)**

**Application**

- To remove the metal bearing.




|          |  |          |  |
|----------|--|----------|--|
| <b>A</b> | 41 mm (1.6 in.)                                      | <b>L</b> | 41.934 to 41.950 mm dia. (1.6510 to 1.6515 in. dia.)   |
| <b>B</b> | 32.5 mm (1.28 in.)                                   | <b>M</b> | 24.959 to 24.980 mm dia. (0.98264 to 0.98346 in. dia.) |
| <b>C</b> | Chamfer 0.3 mm (0.01 in.)                            | <b>N</b> | 21.947 to 21.960 mm dia. (0.86406 to 0.86456 in. dia.) |
| <b>D</b> | 25 mm dia. (0.98 in. dia.)                           | <b>O</b> | 36 mm (1.4 in.)  |
| <b>E</b> | 46.950 to 46.975 mm dia. (1.8485 to 1.8494 in. dia.) | <b>P</b> | 5 mm (0.2 in.)   |
| <b>F</b> | 0.52 rad (30 °)                                      | <b>Q</b> | 29.0 mm (1.14 in.)                                     |
| <b>G</b> | 43.934 to 43.950 mm dia. (1.7297 to 1.7303 in. dia.) | <b>R</b> | 28.0 mm (1.10 in.)                                     |
| <b>H</b> | 148.5 mm (5.846 in.)                                 | <b>S</b> | 195.25 to 195.75 mm (7.6870 to 7.7066 in.)             |
| <b>I</b> | 10 mm (0.39 in.)                                     | <b>T</b> | 145 mm (5.71 in.)                                      |
| <b>J</b> | 46.50 to 46.75 mm dia. (1.831 to 1.840 in. dia.)     | <b>U</b> | 384.75 to 385.25 mm (15.148 to 15.167 in.)             |
| <b>K</b> | 44.950 to 44.975 mm dia. (1.7697 to 1.7706 in. dia.) |          |  |

M00000003GEG0064US1

**Balancer Metal Replacing Tool (for Fitting)**

**Application**


- To press fit the metal bearing.



3TMABAB0P070B

|          |  |          |  |
|----------|--|----------|--|
| <b>A</b> | 182 mm (7.17 in.)                                      | <b>O</b> | 60 mm dia. (2.4 in. dia.)                            |
| <b>B</b> | 140 mm (5.51 in.)                                      | <b>P</b> | 46.950 to 46.975 mm dia. (1.8485 to 1.8494 in. dia.) |
| <b>C</b> | 37 mm (1.5 in.)  | <b>Q</b> | 43.934 to 43.950 mm dia. (1.7297 to 1.7303 in. dia.) |
| <b>D</b> | 35 mm dia. (1.4 in. dia.)                              | <b>R</b> | 140 mm (5.51 in.)                                    |
| <b>E</b> | 60 mm dia. (2.4 in. dia.)                              | <b>S</b> | 36 mm (1.4 in.)                                      |
| <b>F</b> | 10 mm (0.39 in.)                                       | <b>T</b> | 60 mm dia. (2.4 in. dia.)                            |
| <b>G</b> | 0.52 rad (30 °)  | <b>U</b> | 46.950 to 46.975 mm dia. (1.8485 to 1.8494 in. dia.) |
| <b>H</b> | 21.947 to 21.960 mm dia. (0.86406 to 0.86456 in. dia.) | <b>V</b> | 44.950 to 44.975 mm dia. (1.7697 to 1.7706 in. dia.) |
| <b>I</b> | 24.959 to 24.980 mm dia. (0.98264 to 0.98346 in. dia.) | <b>W</b> | 41.934 to 41.950 mm dia. (1.6510 to 1.6515 in. dia.) |
| <b>J</b> | Chamfer 0.3 mm (0.01 in.)                              | <b>X</b> | 145 mm (5.71 in.)                                    |
| <b>K</b> | 8.8 to 9.2 mm (0.35 to 0.36 in.)                       | <b>Y</b> | 195.25 to 195.75 mm (7.6870 to 7.7066 in.)           |
| <b>L</b> | 5 mm (0.2 in.)   | <b>Z</b> | 29 mm (1.1 in.)                                      |
| <b>M</b> | 3.3 to 3.7 mm (0.13 to 0.14 in.)                       | <b>a</b> | 36 mm (1.4 in.)                                      |
| <b>N</b> | 25 mm dia. (0.98 in. dia.)                             |          |  |

M00000003GEG0065US1



3EEADAE0P002B

**Idle Gear 2 Puller**

**Application**

- To remove the idle gear 2 from the shaft.

|           |                                 |
|-----------|---------------------------------|
| <b>A</b>  | 24 mm (0.94 in.)                |
| <b>B</b>  | 10 mm dia. (0.39 in. dia.)      |
| <b>C</b>  | 0.5 mm radius (0.02 in. radius) |
| <b>D</b>  | M20 × Pitch 2.0                 |
| <b>E</b>  | 10 mm (0.39 in.)                |
| <b>F</b>  | 20 mm (0.79 in.)                |
| <b>G</b>  | 5 mm (0.2 in.)                  |
| <b>H</b>  | 95 mm (3.7 in.)                 |
| <b>I</b>  | 125 mm (4.92 in.)               |
| <b>J</b>  | 0.87 rad (50 °)                 |
| <b>K</b>  | 5 mm (0.2 in.)                  |
| <b>L</b>  | 60 mm radius (2.4 in. radius)   |
| <b>M</b>  | M20 × Pitch 2.0                 |
| <b>N</b>  | 30 mm (1.2 in.)                 |
| <b>O</b>  | 10 mm (0.39 in.)                |
| <b>P</b>  | 10 mm (0.39 in.)                |
| <b>Q</b>  | 10 mm (0.39 in.)                |
| <b>R</b>  | 35.5 mm (1.40 in.)              |
| <b>S</b>  | 4.5 mm radius (0.18 in. radius) |
| <b>T</b>  | 40 mm (1.6 in.)                 |
| <b>U</b>  | 40 mm (1.6 in.)                 |
| <b>V</b>  | 12 mm (0.47 in.)                |
| <b>W</b>  | 120 mm (4.72 in.)               |
| <b>C2</b> | Chamfer 2.0 mm (0.079 in.)      |

M0000003GEG0066US1

# 1 ENGINE



# MECHANISM

## CONTENTS

|   |      |
|---|------|
| 1. ENGINE BODY .....                                      | 1-M1 |
| [1] PISTON .....  | 1-M1 |
| [2] BUILT-IN DYNAMIC BALANCER (BALANCER MODEL ONLY) ..... | 1-M2 |
| [3] HALF-FLOATING HEAD COVER .....                        | 1-M3 |
| 2. COOLING SYSTEM .....                                   | 1-M4 |
| [1] BOTTOM BYPASS SYSTEM .....                            | 1-M4 |
| 3. FUEL SYSTEM.....                                       | 1-M5 |
| [1] GOVERNOR.....   | 1-M5 |
| [2] SMOKE REDUCTION DEVICE (S.R.D.).....                  | 1-M5 |
| 4. TURBOCHARGER SYSTEM .....                              | 1-M7 |
| [1] BOOST COMPENSATOR.....                                | 1-M7 |

# 1. ENGINE BODY

## [1] PISTON



The piston skirt has a layer of **molybdenum disulfide** ★, which decreases the piston slap noise and thus the all the engine noise.

★ Molybdenum disulfide ( $\text{MoS}_2$ )


The molybdenum disulfide (1) is a solid lubricant, like Graphite or Teflon. This material helps not to wear the metal even with little lube oil.

(1) Molybdenum Disulfide

[A] D1503-M, D1703-M,  
D1803-M, V2003-M,  
V2203-M, V2403-M,  
V2403-M-T, D1703-M-BG,  
V2003-M-BG,  
V2003-M-T-BG,  
V2203-M-BG, V2403-M-BG  
[B] D1803-M-DI, V2403-M-DI,  
V2403-M-DI-T

M00000003ENM0001US1

## [2] BUILT-IN DYNAMIC BALANCER (BALANCER MODEL ONLY)



The engine causes vibration because of the reciprocation of the piston. This 3-cylinder engine is much less possible to cause vibration than a 4-cylinder one (second inertia, etc.). But all engines have many parts that moves and thus cannot be fully free from vibration.

The 4-cylinder engine can attach the balance weight on the crankcase to absorb the second inertia and decrease vibration.


This engine has 2 balancers internally (1), one at the suction side and the other at the exhaust side.

(1) Balancer


[A] V2003-M, V2203-M,  
V2403-M, V2403-M-T

[B] V2403-M-DI, V2403-M-DI-T

M0000003ENM0002US1



### [3] HALF-FLOATING HEAD COVER




The rubber packing is attached to keep the cylinder head cover approximately 0.5 mm (0.02 in.) off the cylinder head. This decreases the noise from the cylinder head.

- (1) Cylinder Head Cover
- (2) Rubber Packing

M00000003ENM0003US1

## 2. COOLING SYSTEM

### [1] BOTTOM BYPASS SYSTEM



The 03-M Series have a bottom bypass system to enhance the cooling performance.

When the temperature of the coolant in the engine is low, the thermostat (1) stays closed. This lets the coolant flow through the bypass pipe and around the engine.


When the temperature is more than the thermostat valve opening level, the thermostat (1) opens up fully. The hot coolant cannot flow through the bypass into the engine and can flow into the radiator all. Thus, the radiator can decrease the temperature of the coolant more easily.

(1) Thermostat

(A) Bypass Opened


(B) Bypass Closed

M00000003ENM0004US1



## 3. FUEL SYSTEM

### [1] GOVERNOR




The governor refers to the load changes to adjust the fuel quantity supplied to the engine automatically. This makes sure that the engine speed stays constant. This engine uses an all-speed governor that controls the centrifugal force of the steel ball (1) weight. The fuel camshaft (5) turns and makes this centrifugal force, which balances the tension of the governor spring 1 (7) and 2 (8).

- |                        |                        |
|------------------------|------------------------|
| (1) Steel Ball         | (7) Governor Spring 1  |
| (2) Governor Sleeve    | (8) Governor Spring 2  |
| (3) Steel Ball         | (9) Fork Lever 2       |
| (4) Governor Ball Case | (10) Fork Lever 1      |
| (5) Fuel Camshaft      | (11) Fork Lever Shaft  |
| (6) Governor Lever     | (12) Fork Lever Holder |

M0000003ENM0005US1

### [2] SMOKE REDUCTION DEVICE (S.R.D.)




- |                             |
|-----------------------------|
| (1) Injection Pump Assembly |
| (2) Hi-Idling Body          |
| (3) Stop Solenoid Guide     |
| (4) Plunger                 |
| (5) Smoke Reduction Device  |
| (6) Stop Solenoid           |

This Smoke Reduction Device is to reduce the generation of smoke on start up in normal operating temperature as well as on sharp acceleration. As this adjustment is performed and sealed before the fuel limitation is set, the adjustment in the field cannot be performed without a dynamometer.

This Smoke Reduction Device is installed instead of the manual stop lever on the gear case. Especially on removal of the fuel injection pump, the procedure in the workshop manual should be followed.

M0000003ENM0006US1



### **In Normal Operating Temperature**


On start up of the engine, the rack of the fuel injection pump is pushed into the position by the start spring where the amount of injection comes to maximum.

The start up of the engine in this condition makes the fuel injected more than it requires on starting up in normal operating temperature, and smoke is generated.

The thermostat of the Smoke Reduction Device is activated on starting up of the engine in normal operating temperature, and then excessive injection of fuel is controlled.

On sharp acceleration in normal operating temperature, the lever acts as a damper, and the rack of the fuel injection pump moderately moves to the direction where the amount of injected fuel increases, and the amount of smoke during acceleration is reduced.

M00000003ENM0007US1




### **In Low Temperature**

Low temperature starting is secured because Smoke Reduction Device is disabled on starting up the engine in low temperature, and the rack of the fuel injection pump is pushed into the position of the maximum amount of injected fuel by the start spring.

M00000003ENM0008US1


# 4. TURBOCHARGER SYSTEM

## [1] BOOST COMPENSATOR




- (1) Injection Pump Assembly
- (2) Boost Compensator Assembly
- (3) Actuator
- (4) Stop Solenoid
- (5) Plunger
- (6) Stop Solenoid Guide
- (7) Hi-Idling Body

M00000003ENM0009US1



Fuel supply increases when boost pressure increases to make sure that the turbocharger gives sufficient power to the engine.

M00000003ENM0010US1



When the boost pressure drops, fuel supply decreases to decrease black emission.

The system can decrease the emission in low boost pressures at quick speed-up or start-up.

M00000003ENM0011US1

# SERVICING

## CONTENTS

|   |        |
|---|--------|
| 1. TROUBLESHOOTING.....   | 1-S1   |
| [1] ENGINE BODY.....  | 1-S1   |
| [2] ELECTRONIC GOVERNOR.....  | 1-S8   |
| 2. SERVICING SPECIFICATIONS.....  | 1-S11  |
| 3. TIGHTENING TORQUES.....  | 1-S21  |
| [1] TIGHTENING TORQUES OF SCREWS, BOLTS AND NUTS FOR GENERAL USE.....     | 1-S21  |
| [2] TIGHTENING TORQUES OF THE SCREWS, BOLTS AND NUTS FOR SPECIAL USE..... | 1-S22  |
| 4. CHECKING, DISASSEMBLING AND SERVICING.....                             | 1-S24  |
| [1] CHECKING AND ADJUSTING.....   | 1-S24  |
| (1) Engine Body.....  | 1-S24  |
| (2) Lubricating System.....   | 1-S27  |
| (3) Cooling System.....   | 1-S27  |
| (4) Fuel System.....  | 1-S30  |
| (5) Electrical System.....  | 1-S38  |
| (6) Turbocharger.....   | 1-S42  |
| (7) Electronic Governor.....  | 1-S43  |
| [2] DISASSEMBLING AND ASSEMBLING.....                                     | 1-S48  |
| (1) Draining Engine Oil and Coolant.....                                  | 1-S48  |
| (2) External Components.....  | 1-S49  |
| (3) Cylinder Head and Valves.....   | 1-S50  |
| (4) Gear Case and Timing Gears.....                                       | 1-S56  |
| (5) Piston and Connecting Rod.....  | 1-S66  |
| (6) Flywheel and Crankshaft.....  | 1-S73  |
| (7) Starter.....  | 1-S76  |
| (8) Alternator.....   | 1-S77  |
| [3] SERVICING.....  | 1-S78  |
| (1) Cylinder Head and Valves.....   | 1-S78  |
| (2) Timing Gears.....   | 1-S86  |
| (3) Piston and Connecting Rod.....  | 1-S92  |
| (4) Crankshaft.....   | 1-S96  |
| (5) Cylinder.....   | 1-S101 |
| (6) Oil Pump.....   | 1-S103 |
| (7) Starter.....  | 1-S103 |
| (8) Alternator.....   | 1-S106 |

# 1. TROUBLESHOOTING

## [1] ENGINE BODY

| Symptom                               | Probable Cause  | Solution  | Reference Page  |
|---------------------------------------|---|---|---|
| The engine does not start             | No fuel   | Fill up the fuel                                      | G-13  |
|                                       | Air in the fuel system  | Bleed the air   | G-13  |
|                                       | Water in the fuel system  | Change the fuel and repair or replace the fuel system | –   |
|                                       | The fuel hose is clogged  | Clean or replace                                      | G-13  |
|                                       | The fuel filter is clogged  | Replace   | G-22  |
|                                       | The viscosity of fuel or engine oil at low temperature is too high                    | Use the specified fuel or engine oil                  | I-4, G-11   |
|                                       | The cetane number of fuel is low  | Use the specified fuel                                | I-4   |
|                                       | Fuel leakage because of loose injection pipe retaining nut                            | Tighten the retaining nut                             | 1-S50   |
|                                       | Incorrect injection timing  | Adjust  | 1-S30, 1-S32  |
|                                       | The fuel camshaft is worn out   | Replace   | 1-S65   |
|                                       | The injection nozzle is clogged   | Clean or replace (IDI)                                | 1-S36, 1-S37, 1-S38, 1-S51  |
|                                       |   | Repair or replace (DI)                                | 1-S36, 1-S37, 1-S51   |
|                                       | The injection pump is defective   | Repair or replace                                     | 1-S33, 1-S34, 1-S35, 1-S56, 1-S57, 1-S58  |
|                                       | Seizure of the crankshaft, camshaft, piston, cylinder or bearing                      | Repair or replace                                     | 1-S64, 1-S65, 1-S66, 1-S67, 1-S69, 1-S71, 1-S72, 1-S96, 1-S97, 1-S98, 1-S99, 1-S100, 1-S101, 1-S102 |
| Compression leakage from the cylinder | Replace the head gasket, tighten the cylinder head screw, glow plug and nozzle holder | 1-S50, 1-S51, 1-S52, 1-S53                            |   |

| Symptom                             | Probable Cause                           | Solution                           | Reference Page   |
|-------------------------------------|--|------------------------------------|--|
| <b>The engine does not start</b>    | Incorrect valve timing                   | Correct or replace the timing gear | 1-S63,<br>1-S64  |
|                                     | Piston ring and cylinder are worn out    | Replace                            | 1-S24,<br>1-S25,<br>1-S67,<br>1-S69,<br>1-S71,<br>1-S72,<br>1-S94,<br>1-S95,<br>1-S101 |
|                                     | Incorrect valve clearance                | Adjust                             | 1-S26  |
|                                     | The solenoid is defective                | Replace                            | 1-S42,<br>1-S56,<br>1-S57,<br>1-S58  |
| <b>The starter does not operate</b> | Discharged battery                       | Charge                             | G-25, G-26   |
|                                     | Starter is defective                     | Repair or replace                  | 1-S40,<br>1-S49,<br>1-S76,<br>1-S103,<br>1-S104,<br>1-S105,<br>1-S106                  |
|                                     | The key switch is defective              | Replace                            | –  |
|                                     | The connection of the wires is incorrect | Connect                            | –  |

| Symptom   | Probable Cause  | Solution                          | Reference Page   |
|---|---|-----------------------------------|--|
| <b>The engine revolution is not smooth</b>                        | The fuel filter is clogged or dirty   | Replace                           | G-22   |
|   | The air cleaner is clogged  | Clean or replace                  | G-14,<br>G-21, G-27  |
|   | Fuel leakage because of loose injection pipe retaining nut                    | Tighten the retaining nut         | 1-S50  |
|   | The injection pump is defective   | Repair or replace                 | 1-S33,<br>1-S34,<br>1-S35,<br>1-S56,<br>1-S57,<br>1-S58                                |
|   | The nozzle injection pressure is incorrect                                    | Adjust (IDI)                      | 1-S36,<br>1-S51  |
|   |   | Repair or replace (DI)            | 1-S37,<br>1-S51  |
|   | The injection nozzle is clogged   | Repair or replace                 | 1-S36,<br>1-S37,<br>1-S51  |
|   | The governor is defective   | Repair                            | 1-S59,<br>1-S65  |
|   | The turbocharger bearing is worn out  | Replace the turbocharger assembly | 1-S49  |
|   | The turbocharger shaft is bent  | Replace the turbocharger assembly | 1-S49  |
|   | The turbocharger fin or other part has a damage because of unwanted materials | Replace the turbocharger assembly | 1-S49  |
| <b>The exhaust gas is white or blue</b>                           | Too much engine oil   | Reduce it to the specified level  | G-9  |
|   | The piston ring and cylinder is worn out or the piston ring cannot move       | Repair or replace                 | 1-S24,<br>1-S25,<br>1-S67,<br>1-S69,<br>1-S71,<br>1-S72,<br>1-S94,<br>1-S95,<br>1-S101 |
|   | The injection timing is incorrect   | Adjust                            | 1-S30,<br>1-S32  |
| <b>There is oil leakage into the exhaust pipe or suction pipe</b> | The oil pipe is clogged or has a damage                                       | Repair or replace                 | 1-S49  |
|   | The piston ring seal of the turbocharger is defective                         | Replace the turbocharger assembly | 1-S49  |

| Symptom                                      | Probable Cause   | Solution                                  | Reference Page  |
|--|--|---|---|
| <b>The exhaust gas is black or dark gray</b> | Overload   | Decrease the load                         | –   |
|  | The grade of the fuel is low                               | Use the specified fuel                    | I-4   |
|  | The fuel filter is clogged                                 | Replace                                   | G-22  |
|  | The air cleaner is clogged                                 | Clean or replace                          | G-14,<br>G-21, G-27                                     |
|  | The injection nozzle is defective                          | Repair or replace the nozzle              | 1-S36,<br>1-S37,<br>1-S51                               |
| <b>The output is deficient</b>               | The injection timing is incorrect                          | Adjust                                    | 1-S30,<br>1-S32   |
|  | The moving parts of engine have a seizure                  | Repair or replace                         | –   |
|  | The injection pump is defective                            | Repair or replace                         | 1-S33,<br>1-S34,<br>1-S35,<br>1-S56,<br>1-S57,<br>1-S58 |
|  | The injection nozzle is defective                          | Repair or replace the nozzle              | 1-S36,<br>1-S37,<br>1-S38,<br>1-S51                     |
|  | There is compression leakage                               | Check the compression pressure and repair | 1-S24,<br>1-S25   |
|  | There is a gas leakage from the exhaust system             | Repair or replace                         | 1-S42,<br>1-S49   |
|  | There is an air leakage from the compressor discharge side | Repair or replace                         | 1-S42,<br>1-S49   |
|  | The air cleaner is dirty or clogged                        | Clean or replace                          | G-14,<br>G-21, G-27                                     |
|  | The turbocharger compressor wheel turns incorrectly        | Replace the turbocharger assembly         | 1-S49   |

| Symptom  | Probable Cause  | Solution                     | Reference Page   |
|--|---|------------------------------|--|
| <b>The lubricant oil consumption is too much</b> | The gap of the piston ring points to the same direction             | Move the ring gap direction  | 1-S67,<br>1-S69  |
|  | The oil ring is worn out or cannot move                             | Replace                      | 1-S71,<br>1-S72,<br>1-S94,<br>1-S95                      |
|  | The piston ring groove is worn out                                  | Replace the piston           | 1-S71,<br>1-S72,<br>1-S95                                |
|  | The valve stem and valve guide are worn out                         | Replace                      | 1-S55,<br>1-S81  |
|  | The crankshaft bearing and the crankpin bearing is worn out         | Replace                      | 1-S67,<br>1-S69,<br>1-S75,<br>1-S97,<br>1-S98,<br>1-S99, |
|  | There is an oil leakage because of the seal or packing is defective | Replace                      | –  |
| <b>The fuel is mixed into the lubricant oil</b>  | The plunger of the injection pump is worn out                       | Repair or replace            | 1-S33,<br>1-S34,<br>1-S35,<br>1-S56,<br>1-S57,<br>1-S58  |
|  | The injection nozzle is defective                                   | Repair or replace the nozzle | 1-S36,<br>1-S37,<br>1-S38,<br>1-S51                      |
|  | The injection pump is defective                                     | Replace                      | 1-S56,<br>1-S57,<br>1-S58                                |
| <b>Water is mixed into the lubricant oil</b>     | The head gasket is defective  | Replace                      | 1-S53  |
|  | The cylinder block or cylinder head is defective                    | Replace                      | 1-S53,<br>1-S79  |

| Symptom                         | Probable Cause  | Solution                      | Reference Page             |
|---------------------------------|---|-------------------------------|----------------------------|
| <b>The oil pressure is low</b>  | The engine oil is not sufficient                            | Fill up again                 | G-9                        |
|                                 | The oil strainer is clogged                                 | Clean                         | 1-S66                      |
|                                 | The relief valve does not operate with dirt                 | Clean                         | –                          |
|                                 | The relief valve spring is weak or defective                | Replace                       | –                          |
|                                 | The oil clearance of the crankshaft bearing is too much     | Replace                       | 1-S74,<br>1-S98,<br>1-S99  |
|                                 | The oil clearance of the crankpin bearing is too much       | Replace                       | 1-S67,<br>1-S69,<br>1-S97  |
|                                 | The oil clearance of the rocker arm is too much             | Replace                       | 1-S52,<br>1-S85            |
|                                 | The oil passage is clogged                                  | Clean                         | –                          |
|                                 | The type of oil used is incorrect                           | Use the specified type of oil | I-4, G-11                  |
|                                 | The oil pump is defective                                   | Replace                       | 1-S27,<br>1-S65,<br>1-S103 |
| <b>The oil pressure is high</b> | The type of oil used is incorrect                           | Use the specified type of oil | I-4, G-11                  |
|                                 | The relief valve is defective                               | Replace                       | –                          |
| <b>The engine is overheated</b> | The engine oil is not sufficient                            | Fill up again                 | G-11                       |
|                                 | The fan belt is broken or the fan belt tension is too loose | Replace or adjust             | G-15, G-24                 |
|                                 | The coolant is not sufficient                               | Fill up again                 | G-10                       |
|                                 | The radiator net and the radiator fin are clogged with dust | Clean                         | –                          |
|                                 | There is corrosion in the inner side of the radiator        | Clean or replace              | G-23                       |
|                                 | There is corrosion in the coolant flow route                | Clean or replace              | G-23,<br>G-24              |
|                                 | The radiator cap is defective                               | Replace                       | 1-S28                      |
|                                 | The load is too much  | Reduce the load               | –                          |
|                                 | The head gasket is defective                                | Replace                       | 1-S53                      |
|                                 | The injection timing is incorrect                           | Adjust                        | 1-S30,<br>1-S32            |
|                                 | The fuel used is incorrect                                  | Use the specified fuel        | I-4                        |

| Symptom                                  | Probable Cause                            | Solution                           | Reference Page                |
|--|---|------------------------------------|-------------------------------|
| <b>The battery is discharged quickly</b> | The battery electrolyte is not sufficient | Fill in distilled water and charge | G-14, G-25                    |
|  | The fan belt slips                        | Adjust belt tension or replace     | G-14, G-15, G-24              |
|  | The wires connection is incorrect         | Connect again                      | –                             |
|  | The rectifier is defective                | Replace                            | 1-S77, 1-S108                 |
|  | The alternator is defective               | Replace                            | 1-S77, 1-S106, 1-S107, 1-S108 |
|  | The battery is defective                  | Replace                            | –                             |

M00000003ENS0001US1

## [2] ELECTRONIC GOVERNOR

### ■ IMPORTANT

- The engine trouble divides into an electronic governor, the main body of the engine, and the operating constancy.

This manual describes it concerning the check of an electronic governor.

Refer to WSM of engine and operator's manual if you cannot find trouble related to an electronic governor by checking an electronic governor.

M0000003ENS0002US1

Engine will not start.

| Cause   | Corrections                     | Refer to Checking     |
|---|---------------------------------|-----------------------|
| Starter Operating but Not Cranking the Engine | Check operation of the solenoid | Solenoid              |
|   | Check harness of the solenoid   | Solenoid              |
|   | Check harness of the glow plug  | Glow plug             |
| Starter Does Not Operate                      | Check emergency stop switch     | Emergency stop switch |

M0000003ENS0003US1

Engine stopped automatically. Engine can be started again and stops again 10 seconds later.

| Cause  | Corrections  | Refer to Checking                     |
|--|--|---------------------------------------|
| Trouble in the electronic governor composition parts | Check blinking pattern of the glow lamp (1)<br> | Signal pattern sheet<br>(1) Glow Lamp |

M0000003ENS0004US1

Engine speed cannot be controlled.

| Cause                                     | Corrections                     | Refer to Checking |
|---|---------------------------------|-------------------|
| Engine speed does not increase / decrease | Check slow down switch          | Slow down switch  |
|   | Check speed switch              | Speed switch      |
|   | Check operation of the solenoid | Solenoid          |
|   | Check harness of speed sensor   | Harness           |
| Engine operates rough                     | Check operation of the solenoid | Solenoid          |
|   | Check harness of speed sensor   | Harness           |

M0000003ENS0005US1

| Blinking Pattern of Glow Lamp   | Cause                                     | Refer to Checking        |
|---|---|--------------------------|
| (1-Long and 1-Short)<br><br>3EEAAB1P005A   | Overrunning<br>(more than 115 %)          | Solenoid                 |
| (1-Long and 2-Short)<br><br>3EEAAB1P006A   | Low oil pressure                          | Oil sensor               |
| (1-Long and 3-Short)<br><br>3EEAAB1P007A   | Defect of alternator                      | Alternator               |
| (1-Long and 4-Short)<br><br>3EEAAB1P008A   | Coolant temperature is abnormal           | Water temperature switch |
| (1-Long and 5-Short)<br><br>3EEAAB1P009A   | Emergency stop switch operated            | Emergency stop switch    |
| (1-Long and 6-Short)<br><br>3EEAAB1P035A   | Coolant temperature is abnormal           | Water temperature sensor |
| (1-Long and 7-Short)<br><br>3EEAAB1P037A | Starting error                            | Starter ON > 12 sec      |
| (2-Long and 1-Short)<br><br>3EEAAB1P010A | Abnormality of speed sensor               | Speed sensor             |
| (2-Long and 2-Short)<br><br>3EEAAB1P011A | Solenoid malfunction                      | Solenoid                 |
| (2-Long and 4-Short)<br><br>3EEAAB1P012A | Disconnection of water temperature sensor | Water temperature sensor |
| (2-Long and 5-Short)<br><br>3EEAAB1P013A | Short circuit of water temperature sensor | Water temperature sensor |
| (2-Long and 6-Short)<br><br>3EEAAB1P014A | Disconnection of alternator L Terminal    | Alternator L Terminal    |

| Blinking Pattern of Glow Lamp   | Cause                 | Refer to Checking           |
|---|-----------------------|-----------------------------|
| (2-Long and 7-Short)<br><br>3EEAAB1P015A | Over voltage          | Alternator                  |
| (2-Long and 8-Short)<br><br>3EEAAB1P016A | Sensor supply voltage | ECU, Sensor, Wiring Harness |

M00000003ENS0006US1

## 2. SERVICING SPECIFICATIONS

### ENGINE BODY

| Item  |                       | Factory Specification   | Allowable Limit  |
|---|-----------------------|---|--|
| Valve Clearance (When Cold)   |                       | 0.18 to 0.22 mm<br>0.0071 to 0.0086 in.   | –  |
| Compression Pressure<br>(When You Crank the Engine with the Starter)<br>[D1503-M, D1703-M, D1803-M, V2003-M, V2203-M, V2403-M,<br>V2403-M-T, D1703-M-BG, V2003-M-BG, V2003-M-T-BG,<br>V2203-M-BG, V2403-M-BG] |                       | 3.24 to 3.72 MPa /<br>290 min <sup>-1</sup> (rpm)<br>33.0 to 38.0 kgf/cm <sup>2</sup> /<br>290 min <sup>-1</sup> (rpm)<br>470 to 540 psi /<br>290 min <sup>-1</sup> (rpm) | 2.55 MPa /<br>290 min <sup>-1</sup> (rpm)<br>26.0 kgf/cm <sup>2</sup> /<br>290 min <sup>-1</sup> (rpm)<br>370 psi /<br>290 min <sup>-1</sup> (rpm) |
| Compression Pressure<br>(When You Crank the Engine with the Starter)<br>[D1803-M-DI, V2403-M-DI, V2403-M-DI-T]  |                       | 2.95 to 3.23 MPa /<br>290 min <sup>-1</sup> (rpm)<br>30.0 to 33.0 kgf/cm <sup>2</sup> /<br>290 min <sup>-1</sup> (rpm)<br>427 to 469 psi /<br>290 min <sup>-1</sup> (rpm) | 2.35 MPa /<br>290 min <sup>-1</sup> (rpm)<br>24.0 kgf/cm <sup>2</sup> /<br>290 min <sup>-1</sup> (rpm)<br>341 psi /<br>290 min <sup>-1</sup> (rpm) |
| Difference among Cylinders  |                       | –   | 10 % or less   |
| Top Clearance<br>[D1503-M, D1703-M, D1803-M, V2003-M, V2203-M, V2403-M,<br>V2403-M-T, D1703-M-BG, V2003-M-BG, V2003-M-T-BG,<br>V2203-M-BG, V2403-M-BG]  |                       | 0.575 to 0.675 mm<br>0.0227 to 0.0265 in.   | –  |
| Top Clearance<br>[D1803-M-DI, V2403-M-DI, V2403-M-DI-T]   |                       | 0.60 to 0.70 mm<br>0.024 to 0.027 in.   | –  |
| Cylinder Head Surface   | Flatness              | –   | 0.05 mm / 500 mm<br>0.002 in. / 19.7 in.   |
| Valve Recessing<br>(Protrusion to Recessing)<br>[D1503-M, D1703-M, D1803-M, V2003-M,<br>V2203-M, V2403-M, V2403-M-T,<br>D1703-M-BG, V2003-M-BG,<br>V2003-M-T-BG, V2203-M-BG,<br>V2403-M-BG]                   | Protrusion            | 0.05 mm<br>0.002 in.  | –  |
|   | Recessing             | 0.15 mm<br>0.0059 in.   | 0.40 mm<br>0.016 in.   |
| Valve Recessing<br>[D1803-M-DI, V2403-M-DI, V2403-M-DI-T]   | Recessing             | 0.65 to 0.85 mm<br>0.026 to 0.033 in.   | 1.20 mm<br>0.0472 in.  |
| Valve Stem to Valve Guide   | Clearance             | 0.040 to 0.070 mm<br>0.0016 to 0.0027 in.   | 0.10 mm<br>0.0039 in.  |
|   | • Valve Stem<br>O.D.  | 7.960 to 7.975 mm<br>0.3134 to 0.3139 in.   | –  |
|   | • Valve Guide<br>I.D. | 8.015 to 8.030 mm<br>0.3156 to 0.3161 in.   | –  |
| Valve Face<br>[D1503-M, D1703-M, D1803-M, V2003-M,<br>V2203-M, V2403-M, V2403-M-T,<br>D1703-M-BG, V2003-M-BG,<br>V2003-M-T-BG, V2203-M-BG,<br>V2403-M-BG]   | Angle (Intake)        | 1.0 rad<br>60 °   | –  |
|   | Angle (Exhaust)       | 0.79 rad<br>45 °  | –  |
| Valve Face<br>[D1803-M-DI, V2403-M-DI, V2403-M-DI-T]  | Angle (Intake)        | 0.79 rad<br>45 °  | –  |
|   | Angle (Exhaust)       | 0.79 rad<br>45 °  | –  |

| Item  |                 | Factory Specification            | Allowable Limit |
|---|-----------------|----------------------------------|-----------------|
| Valve Seat  | Width (Intake)  | 2.12 mm<br>0.0835 in.            | –               |
|   | Width (Exhaust) | 2.12 mm<br>0.0835 in.            | –               |
| Valve Seat<br>[D1503-M, D1703-M, D1803-M, V2003-M,<br>V2203-M, V2403-M, V2403-M-T,<br>D1703-M-BG, V2003-M-BG,<br>V2003-M-T-BG, V2203-M-BG,<br>V2403-M-BG] | Angle (Intake)  | 1.0 rad<br>60 °                  | –               |
|   | Angle (Exhaust) | 0.79 rad<br>45 °                 | –               |
| Valve Seat<br>[D1803-M-DI, V2403-M-DI, V2403-M-DI-T]  | Angle (Intake)  | 0.79 rad<br>45 °                 | –               |
|   | Angle (Exhaust) | 0.79 rad<br>45 °                 | –               |
| Valve Timing (Intake Valve)<br>[D1503-M, D1703-M-BG]  | Open            | 0.1 rad (8 °)<br>before T.D.C.   | –               |
|   | Close           | 0.35 rad (20 °)<br>after B.D.C.  | –               |
| Valve Timing (Intake Valve)<br>[D1703-M, D1803-M, V2003-M, V2203-M,<br>V2403-M, V2403-M-DI-T, V2003-M-BG,<br>V2203-M-BG, V2403-M-BG]                      | Open            | 0.21 rad (12 °)<br>before T.D.C. | –               |
|   | Close           | 0.63 rad (36 °)<br>after B.D.C.  | –               |
| Valve Timing (Intake Valve)<br>[V2403-M-T, V2003-M-T-BG]  | Open            | 0.35 rad (20 °)<br>before T.D.C. | –               |
|   | Close           | 0.79 rad (45 °)<br>after B.D.C.  | –               |
| Valve Timing (Intake Valve)<br>[D1803-M-DI, V2403-M-DI]   | Open            | 0.2 rad (9 °)<br>before T.D.C.   | –               |
|   | Close           | 0.68 rad (39 °)<br>after B.D.C.  | –               |
| Valve Timing (Exhaust Valve)<br>[D1503-M, V2003-M]  | Open            | 1.0 rad (60 °)<br>before B.D.C.  | –               |
|   | Close           | 0.21 rad (12 °)<br>after T.D.C.  | –               |
| Valve Timing (Exhaust Valve)<br>[D1703-M, D1803-M, V2203-M, V2403-M,<br>V2403-M-BG]   | Open            | 0.99 rad (57 °)<br>before B.D.C. | –               |
|   | Close           | 0.21 rad (12 °)<br>after T.D.C.  | –               |
| Valve Timing (Exhaust Valve)<br>[V2403-M-T, V2403-M-DI-T, D1703-M-BG,<br>V2003-M-BG, V2203-M-BG]  | Open            | 0.87 rad (50 °)<br>before B.D.C. | –               |
|   | Close           | 0 rad (0 °)<br>after T.D.C.      | –               |

| Item   |                                  | Factory Specification  | Allowable Limit  |
|--|----------------------------------|--|--|
| Valve Timing (Exhaust Valve)<br><b>[D1803-M-DI, V2403-M-DI]</b>              | Open                             | 0.72 rad (41 °)<br>before B.D.C.                             | –  |
|  | Close                            | 0.2 rad (9 °)<br>after T.D.C.                                | –  |
| Valve Timing (Exhaust Valve)<br><b>[V2003-M-T-BG]</b>                        | Open                             | 0.96 rad (55 °)<br>before B.D.C.                             | –  |
|  | Close                            | 0.24 rad (14 °)<br>after T.D.C.                              | –  |
| Valve Spring   | Free Length                      | 41.7 to 42.2 mm<br>1.65 to 1.66 in.                          | 41.2 mm<br>1.62 in.  |
|  | Setting Load /<br>Setting Length | 118 N / 35.0 mm<br>12.0 kgf / 35.0 mm<br>26.5 lbf / 1.38 in. | 100 N / 35.0 mm<br>10.2 kgf / 35.0 mm<br>22.5 lbf / 1.38 in. |
|  | Tilt                             | –  | 1.0 mm<br>0.039 in.  |
| Rocker Arm Shaft to Rocker Arm<br><br>• Rocker Arm Shaft<br><br>• Rocker Arm | Oil Clearance                    | 0.016 to 0.045 mm<br>0.00063 to 0.0017 in.                   | 0.10 mm<br>0.0039 in.  |
|  | O.D.                             | 13.973 to 13.984 mm<br>0.55012 to 0.55055 in.                | –  |
|  | I.D.                             | 14.000 to 14.018 mm<br>0.55119 to 0.55188 in.                | –  |
| Push Rod   | Bend                             | –  | 0.25 mm<br>0.0098 in.  |
| Tappet to Tappet Guide<br><br>• Tappet<br><br>• Tappet Guide                 | Oil Clearance                    | 0.020 to 0.062 mm<br>0.00079 to 0.0024 in.                   | 0.07 mm<br>0.003 in.   |
|  | O.D.                             | 23.959 to 23.980 mm<br>0.94327 to 0.94409 in.                | –  |
|  | I.D.                             | 24.000 to 24.021 mm<br>0.94489 to 0.94570 in.                | –  |

| Item   |   | Factory Specification  | Allowable Limit       |
|--|---|--|-----------------------|
| Timing Gear  | • Crank Gear to Idle Gear   | Backlash<br>0.04150 to 0.1122 mm<br>0.001634 to 0.004417 in. | 0.15 mm<br>0.0059 in. |
|  | • Idle Gear to Cam Gear   | Backlash<br>0.04150 to 0.1154 mm<br>0.001634 to 0.004543 in. | 0.15 mm<br>0.0059 in. |
|  | • Idle Gear to Injection Pump Gear                                  | Backlash<br>0.04150 to 0.1154 mm<br>0.001634 to 0.004543 in. | 0.15 mm<br>0.0059 in. |
|  | • Crank Gear to Oil Pump Gear                                       | Backlash<br>0.04150 to 0.1090 mm<br>0.001634 to 0.004291 in. | 0.15 mm<br>0.0059 in. |
|  | • Idle Gear to Balancer Gear<br>(Balancer Model Only)               | Backlash<br>0.03500 to 0.1160 mm<br>0.001378 to 0.004566 in. | 0.15 mm<br>0.0059 in. |
|  | • Cam Gear to Balancer Gear<br>(Balancer Model Only)                | Backlash<br>0.03500 to 0.1160 mm<br>0.001378 to 0.004566 in. | 0.15 mm<br>0.0059 in. |
|  | • Crank Gear to Idle Gear 2<br>(Side PTO Model Only)                | Backlash<br>0.04150 to 0.1154 mm<br>0.001634 to 0.004543 in. | 0.15 mm<br>0.0059 in. |
|  | • Idle Gear 2 to Hydraulic Pump Drive<br>Gear (Side PTO Model Only) | Backlash<br>0.03080 to 0.1062 mm<br>0.001213 to 0.004181 in. | 0.15 mm<br>0.0059 in. |
| Idle Gear  | Side Clearance  | 0.12 to 0.48 mm<br>0.0048 to 0.018 in.                       | 0.9 mm<br>0.04 in.    |
| Idle Gear Shaft to Idle Gear Bushing   | Oil Clearance   | 0.025 to 0.066 mm<br>0.00099 to 0.0025 in.                   | 0.10 mm<br>0.0039 in. |
|  | • Idle Gear Shaft   | O.D.<br>37.959 to 37.975 mm<br>1.4945 to 1.4950 in.          | –                     |
|  | • Idle Gear Bushing   | I.D.<br>38.000 to 38.025 mm<br>1.4961 to 1.4970 in.          | –                     |
| Camshaft   | Side Clearance  | 0.070 to 0.22 mm<br>0.0028 to 0.0086 in.                     | 0.30 mm<br>0.012 in.  |
| Camshaft   | Bend  | –  | 0.01 mm<br>0.0004 in. |
| Cam<br>[D1503-M]   | Height<br>(Intake)  | 33.27 mm<br>1.310 in.  | 33.22 mm<br>1.308 in. |
|  | Height<br>(Exhaust)   | 33.47 mm<br>1.318 in.  | 33.42 mm<br>1.316 in. |
| Cam<br>[D1703-M, D1803-M, V2203-M, V2403-M,<br>D1803-M-DI, V2403-M-DI, V2403-M-BG] | Height<br>(Intake / Exhaust)  | 33.90 mm<br>1.335 in.  | 33.85 mm<br>1.333 in. |
| Cam<br>[V2003-M]   | Height<br>(Intake / Exhaust)  | 33.47 mm<br>1.318 in.  | 33.42 mm<br>1.316 in. |
| Cam<br>[V2403-M-T]   | Height<br>(Intake)  | 33.90 mm<br>1.335 in.  | 33.85 mm<br>1.333 in. |
|  | Height<br>(Exhaust)   | 33.27 mm<br>1.310 in.  | 33.22 mm<br>1.308 in. |

| Item  |                              | Factory Specification                        | Allowable Limit                               |   |
|---|------------------------------|--|---|---|
| Cam<br>[V2403-M-DI-T]   | Height<br>(Intake)           | 33.47 mm<br>1.318 in.                        | 33.42 mm<br>1.316 in.                         |   |
|   | Height<br>(Exhaust)          | 33.00 mm<br>1.299 in.                        | 32.95 mm<br>1.297 in.                         |   |
| Cam<br>[D1703-M-BG]   | Height<br>(Intake / Exhaust) | 33.27 mm<br>1.310 in.                        | 33.22 mm<br>1.308 in.                         |   |
| Cam<br>[V2003-M-BG, V2203-M-BG]   | Height<br>(Intake)           | 33.47 mm<br>1.318 in.                        | 33.42 mm<br>1.316 in.                         |   |
|   | Height<br>(Exhaust)          | 33.27 mm<br>1.310 in.                        | 33.22 mm<br>1.308 in.                         |   |
| Cam<br>[V2003-M-T-BG]   | Height<br>(Intake)           | 33.90 mm<br>1.335 in.                        | 33.85 mm<br>1.333 in.                         |   |
|   | Height<br>(Exhaust)          | 33.47 mm<br>1.318 in.                        | 33.42 mm<br>1.316 in.                         |   |
| Camshaft Journal to Cylinder Block Bore                                       | Oil Clearance                | 0.050 to 0.091 mm<br>0.0020 to 0.0035 in.    | 0.15 mm<br>0.0059 in.                         |   |
| • Camshaft Journal  | O.D.                         | 39.934 to 39.950 mm<br>1.5722 to 1.5728 in.  | –   |   |
| • Cylinder Block Bore   | I.D.                         | 40.000 to 40.025 mm<br>1.5748 to 1.5757 in.  | –   |   |
| Balancer Shaft<br>(Balancer Model Only)                                       | Side Clearance               | 0.070 to 0.22 mm<br>0.0028 to 0.0086 in.     | 0.30 mm<br>0.012 in.                          |   |
| Balancer Shaft<br>(Balancer Model Only)                                       | Bend                         | –  | 0.02 mm<br>0.0008 in.                         |   |
| Balancer Shaft Journal 1 to Balancer Shaft<br>Bearing 1 (Balancer Model Only) | Oil Clearance                | 0.0300 to 0.111 mm<br>0.00119 to 0.00437 in. | 0.20 mm<br>0.0079 in.                         |   |
|   | • Balancer Shaft Journal 1   | O.D.   | 43.934 to 43.950 mm<br>1.7297 to 1.7303 in.   | – |
|   | • Balancer Shaft Bearing 1   | I.D.   | 43.980 to 44.045 mm<br>1.7315 to 1.7340 in.   | – |
| Balancer Shaft Journal 2 to Balancer Shaft<br>Bearing 2 (Balancer Model Only) | Oil Clearance                | 0.0300 to 0.111 mm<br>0.00119 to 0.00437 in. | 0.20 mm<br>0.0079 in.                         |   |
|   | • Balancer Shaft Journal 2   | O.D.   | 41.934 to 41.950 mm<br>1.6509 to 1.6515 in.   | – |
|   | • Balancer Shaft Bearing 2   | I.D.   | 41.980 to 42.045 mm<br>1.6528 to 1.6553 in.   | – |
| Balancer Shaft Journal 3 to Balancer Shaft<br>Bearing 3 (Balancer Model Only) | Oil Clearance                | 0.020 to 0.094 mm<br>0.00079 to 0.0037 in.   | 0.20 mm<br>0.0079 in.                         |   |
|   | • Balancer Shaft Journal 3   | O.D.   | 21.947 to 21.960 mm<br>0.86406 to 0.86456 in. | – |
|   | • Balancer Shaft Bearing 3   | I.D.   | 21.980 to 22.041 mm<br>0.86536 to 0.86775 in. | – |

| Item  |               | Factory Specification                         | Allowable Limit        |
|---|---------------|---|------------------------|
| Piston Pin Bore   | I.D.          | 25.000 to 25.013 mm<br>0.98426 to 0.98476 in. | 25.05 mm<br>0.9862 in. |
| Top Ring to Ring Groove<br>[D1803-M-DI, V2403-M-DI]   | Clearance     | 0.050 to 0.090 mm<br>0.0020 to 0.0035 in.     | 0.20 mm<br>0.0079 in.  |
| Second Ring to Ring Groove<br>[D1503-M, D1703-M, D1803-M, V2003-M,<br>V2203-M, V2403-M, V2403-M-T,<br>V2403-M-DI-T, D1703-M-BG, V2003-M-BG,<br>V2003-M-T-BG, V2203-M-BG,<br>V2403-M-BG] | Clearance     | 0.0930 to 0.128 mm<br>0.00367 to 0.00503 in.  | 0.20 mm<br>0.0079 in.  |
| Second Ring to Ring Groove<br>[D1803-M-DI, V2403-M-DI]  | Clearance     | 0.0780 to 0.110 mm<br>0.00307 to 0.00433 in.  | 0.20 mm<br>0.0079 in.  |
| Oil Ring to Ring Groove<br>[D1503-M, D1703-M, D1803-M, V2003-M,<br>V2203-M, V2403-M, V2403-M-T,<br>V2403-M-DI-T, D1703-M-BG, V2003-M-BG,<br>V2003-M-T-BG, V2203-M-BG,<br>V2403-M-BG]    | Clearance     | 0.020 to 0.060 mm<br>0.00079 to 0.0023 in.    | 0.15 mm<br>0.0059 in.  |
| Oil Ring to Ring Groove<br>[D1803-M-DI, V2403-M-DI]   | Clearance     | 0.030 to 0.070 mm<br>0.0012 to 0.0027 in.     | 0.15 mm<br>0.0059 in.  |
| Top Ring<br>[D1503-M, V2003-M, V2403-M-T,<br>D1803-M-DI, V2403-M-DI, V2403-M-DI-T,<br>V2003-M-BG, V2003-M-T-BG]   | Ring Gap      | 0.20 to 0.35 mm<br>0.0079 to 0.013 in.        | 1.25 mm<br>0.0492 in.  |
| Top Ring<br>[D1703-M, D1803-M, V2203-M, V2403-M,<br>D1703-M-BG, V2203-M-BG, V2403-M-BG]   | Ring Gap      | 0.25 to 0.40 mm<br>0.0099 to 0.015 in.        | 1.25 mm<br>0.0492 in.  |
| Second Ring<br>[D1503-M, D1703-M, D1803-M, V2203-M,<br>V2403-M, D1803-M-DI, V2403-M-DI,<br>D1703-M-BG, V2003-M-BG, V2203-M-BG,<br>V2403-M-BG]   | Ring Gap      | 0.30 to 0.45 mm<br>0.012 to 0.017 in.         | 1.25 mm<br>0.0492 in.  |
| Second Ring<br>[V2003-M, V2403-M-T, V2403-M-DI-T,<br>V2003-M-T-BG]  | Ring Gap      | 0.40 to 0.55 mm<br>0.016 to 0.021 in.         | 1.25 mm<br>0.0492 in.  |
| Oil Ring<br>[D1503-M, D1703-M, D1803-M, V2003-M,<br>V2203-M, V2403-M, V2403-M-T,<br>V2403-M-DI-T, D1703-M-BG, V2003-M-BG,<br>V2003-M-T-BG, V2203-M-BG,<br>V2403-M-BG]                   | Ring Gap      | 0.25 to 0.45 mm<br>0.0099 to 0.017 in.        | 1.25 mm<br>0.0492 in.  |
| Oil Ring<br>[D1803-M-DI, V2403-M-DI]  | Ring Gap      | 0.20 to 0.40 mm<br>0.0079 to 0.015 in.        | 1.25 mm<br>0.0492 in.  |
| Connecting Rod  | Alignment     | –   | 0.05 mm<br>0.002 in.   |
| Piston Pin to Small End Bushing   | Oil Clearance | 0.014 to 0.036 mm<br>0.00056 to 0.0014 in.    | 0.15 mm<br>0.0059 in.  |
| • Piston Pin  | O.D.          | 25.004 to 25.011 mm<br>0.98441 to 0.98468 in. | –                      |
| • Small End Bushing   | I.D.          | 25.025 to 25.040 mm<br>0.98524 to 0.98582 in. | –                      |

| Item   |                        | Factory Specification                               | Allowable Limit         |
|--|------------------------|---|-------------------------|
| Crankshaft   | Bend                   | –   | 0.02 mm<br>0.0008 in.   |
| Crankshaft Journal to Crankshaft Bearing 1   | Oil Clearance          | 0.0400 to 0.118 mm<br>0.00158 to 0.00464 in.        | 0.20 mm<br>0.0079 in.   |
|  | • Crankshaft Journal   | O.D.<br>59.921 to 59.940 mm<br>2.3591 to 2.3598 in. | –                       |
|  | • Crankshaft Bearing 1 | I.D.<br>59.980 to 60.039 mm<br>2.3615 to 2.3637 in. | –                       |
| Crankshaft Journal to Crankshaft Bearing 2   | Oil Clearance          | 0.0400 to 0.104 mm<br>0.00158 to 0.00409 in.        | 0.20 mm<br>0.0079 in.   |
|  | • Crankshaft Journal   | O.D.<br>59.921 to 59.940 mm<br>2.3591 to 2.3598 in. | –                       |
|  | • Crankshaft Bearing 2 | I.D.<br>59.980 to 60.025 mm<br>2.3615 to 2.3631 in. | –                       |
| Crankpin to Crankpin Bearing   | Oil Clearance          | 0.025 to 0.087 mm<br>0.00099 to 0.0034 in.          | 0.20 mm<br>0.0079 in.   |
|  | • Crankpin             | O.D.<br>46.959 to 46.975 mm<br>1.8488 to 1.8494 in. | –                       |
|  | • Crankpin Bearing     | I.D.<br>47.000 to 47.046 mm<br>1.8504 to 1.8522 in. | –                       |
| Crankshaft   | Side Clearance         | 0.15 to 0.31 mm<br>0.0059 to 0.012 in.              | 0.5 mm<br>0.02 in.      |
| Cylinder Bore (Standard)<br>[D1503-M, V2003-M, V2003-M-BG,<br>V2003-M-T-BG]  | I.D.                   | 83.000 to 83.022 mm<br>3.2678 to 3.2685 in.         | 83.170 mm<br>3.2744 in. |
| Cylinder Bore (Standard)<br>[D1703-M, D1803-M, V2203-M, V2403-M,<br>V2403-M-T, D1803-M-DI, V2403-M-DI,<br>V2403-M-DI-T, D1703-M-BG, V2203-M-BG,<br>V2403-M-BG] | I.D.                   | 87.000 to 87.022 mm<br>3.4252 to 3.4260 in.         | 87.170 mm<br>3.4319 in. |
| Cylinder Bore (Oversize)<br>[D1503-M, V2003-M, V2003-M-BG,<br>V2003-M-T-BG]  | I.D.                   | 83.250 to 83.272 mm<br>3.2776 to 3.2784 in.         | 83.420 mm<br>3.2843 in. |
| Cylinder Bore (Oversize)<br>[D1703-M, D1803-M, V2203-M, V2403-M,<br>V2403-M-T, D1803-M-DI, V2403-M-DI,<br>V2403-M-DI-T, D1703-M-BG, V2203-M-BG,<br>V2403-M-BG] | I.D.                   | 87.250 to 87.272 mm<br>3.4351 to 3.4359 in.         | 87.420 mm<br>3.4417 in. |
| Cylinder Maximum I.D. to Cylinder<br>Minimum I.D.  | Difference             | –   | 0.15 mm<br>0.0059 in.   |

**LUBRICATING SYSTEM**

| Item                       |                  | Factory Specification  | Allowable Limit                              |
|----------------------------|------------------|--|--|
| Engine Oil Pressure        | At Idle Speed    | More than<br>98 kPa<br>1.0 kgf/cm <sup>2</sup><br>14 psi         | 50 kPa<br>0.5 kgf/cm <sup>2</sup><br>7 psi   |
|                            | At Rated Speed   | 300 to 440 kPa<br>3.0 to 4.5 kgf/cm <sup>2</sup><br>43 to 64 psi | 250 kPa<br>2.5 kgf/cm <sup>2</sup><br>36 psi |
| Engine Oil Pressure Switch | Working Pressure | 50 kPa<br>0.5 kgf/cm <sup>2</sup><br>7 psi                       | —  |
| Inner Rotor to Outer Rotor | Clearance        | 0.030 to 0.14 mm<br>0.0012 to 0.0055 in.                         | 0.2 mm<br>0.008 in.                          |
| Outer Rotor to Pump Body   | Clearance        | 0.11 to 0.19 mm<br>0.0044 to 0.0074 in.                          | 0.25 mm<br>0.0098 in.                        |
| Inner Rotor to Cover       | Clearance        | 0.105 to 0.150 mm<br>0.00414 to 0.00590 in.                      | 0.20 mm<br>0.008 in.                         |

**COOLING SYSTEM**

| Item  |   | Factory Specification   | Allowable Limit |
|---|---|---|-----------------|
| Fan Belt  | Tension   | 7.0 to 9.0 mm (0.28 to 0.35 in.) deflection at 98 N (10 kgf, 22 lbf) of force                                     | —               |
| Thermostat Valve<br>[D1503-M, D1703-M, D1803-M, V2003-M, V2203-M, V2403-M, V2403-M-T, D1703-M-BG, V2003-M-BG, V2003-M-T-BG, V2203-M-BG, V2403-M-BG] | Opening-Temperature<br>(When the valve starts to open)    | 69.5 to 72.5 °C<br>157.1 to 162.5 °F  | —               |
|   | Opening-Temperature<br>(When the valve opened completely) | 85 °C<br>185 °F   | —               |
| Thermostat Valve<br>[D1803-M-DI, V2403-M-DI, V2403-M-DI-T]  | Opening-Temperature<br>(When the valve starts to open)    | 80.5 to 83.5 °C<br>176.9 to 182.3 °F  | —               |
|   | Opening-Temperature<br>(When the valve opened completely) | 95 °C<br>203 °F   | —               |
| Radiator  | Water Tightness   | No leak at specified pressure   | —               |
| Radiator Cap  | Pressure Decreasing Time                                  | More than 10 seconds for pressure decrease from 90 to 60 kPa from 0.9 to 0.6 kgf/cm <sup>2</sup> from 10 to 9 psi | —               |

**FUEL SYSTEM**

| Item   |                                   | Factory Specification   | Allowable Limit   |
|--|-----------------------------------|---|---|
| Injection Pump<br>[D1503-M, V2003-M-T-BG]  | Injection Timing                  | 0.253 to 0.279 rad<br>(14.5 to 16.0 °)<br>before T.D.C.                                 | –   |
| Injection Pump<br>[D1703-M, D1803-M, V2003-M, V2203-M,<br>V2403-M]   | Injection Timing                  | 0.271 to 0.296 rad<br>(15.5 to 17.0 °)<br>before T.D.C.                                 | –   |
| Injection Pump<br>[V2403-M-T]  | Injection Timing                  | 0.132 to 0.157 rad<br>(7.55 to 9.05 °)<br>before T.D.C.                                 | –   |
| Injection Pump<br>[D1803-M-DI, V2403-M-DI]   | Injection Timing                  | 0.0742 to 0.100 rad<br>(4.25 to 5.75 °)<br>before T.D.C.                                | –   |
| Injection Pump<br>[V2403-M-DI-T]   | Injection Timing                  | 0.0829 to 0.109 rad<br>(4.75 to 6.25 °)<br>before T.D.C.                                | –   |
| Injection Pump<br>[D1703-M-BG, V2003-M-BG, V2203-M-BG,<br>V2403-M-BG]  | Injection Timing                  | 0.236 to 0.261 rad<br>(13.5 to 15.0 °)<br>before T.D.C.                                 | –   |
| Pump Element<br>[D1503-M, D1703-M, D1803-M, V2003-M,<br>V2203-M, V2403-M, V2403-M-T,<br>D1703-M-BG, V2003-M-BG,<br>V2003-M-T-BG, V2203-M-BG,<br>V2403-M-BG]                | Fuel Tightness                    | –   | 13.73 MPa<br>140.0 kgf/cm <sup>2</sup><br>1991 psi  |
| Pump Element<br>[D1803-M-DI, V2403-M-DI, V2403-M-DI-T]   | Fuel Tightness                    | –   | 18.63 MPa<br>190.0 kgf/cm <sup>2</sup><br>2702 psi  |
| Delivery Valve<br>[D1503-M, D1703-M, D1803-M, V2003-M,<br>V2203-M, V2403-M, V2403-M-T,<br>D1703-M-BG, V2003-M-BG,<br>V2003-M-T-BG, V2203-M-BG,<br>V2403-M-BG]              | Fuel Tightness                    | 10 seconds<br>13.73 → 12.75 MPa<br>140.0 → 130.0 kgf/cm <sup>2</sup><br>1991 → 1849 psi | 5 seconds<br>13.73 → 12.75 MPa<br>140.0 → 130.0<br>kgf/cm <sup>2</sup><br>1991 → 1849 psi |
| Delivery Valve<br>[D1803-M-DI, V2403-M-DI, V2403-M-DI-T]   | Fuel Tightness                    | 10 seconds<br>18.63 → 17.65 MPa<br>190.0 → 180.0 kgf/cm <sup>2</sup><br>2702 → 2560 psi | 5 seconds<br>18.63 → 17.65 MPa<br>190.0 → 180.0<br>kgf/cm <sup>2</sup><br>2702 → 2560 psi |
| Injection Nozzle<br>[D1503-M, D1703-M, D1803-M, V2003-M,<br>V2203-M, V2403-M, V2403-M-T,<br>D1703-M-BG, V2003-M-BG,<br>V2003-M-T-BG, V2203-M-BG,<br>V2403-M-BG]            | Injection Pressure                | 13.73 to 14.70 MPa<br>140.0 to 150.0 kgf/cm <sup>2</sup><br>1992 to 2133 psi            | –   |
| Injection Nozzle<br>[D1803-M-DI, V2403-M-DI, V2403-M-DI-T]   | Injection Pressure<br>(1st Stage) | 18.64 to 20.10 MPa<br>190.0 to 205.0 kgf/cm <sup>2</sup><br>2703 to 2915 psi            | –   |
| Injection Nozzle Valve Seat<br>[D1503-M, D1703-M, D1803-M, V2003-M,<br>V2203-M, V2403-M, V2403-M-T,<br>D1703-M-BG, V2003-M-BG,<br>V2003-M-T-BG, V2203-M-BG,<br>V2403-M-BG] | Valve Seat<br>Tightness           | No fuel leak at<br>12.75 MPa<br>130.0 kgf/cm <sup>2</sup><br>1849 psi                   | –   |

| Item  |                      | Factory Specification   | Allowable Limit |
|---|----------------------|---|-----------------|
| Injection Nozzle Valve Seat<br>[D1803-M-DI, V2403-M-DI, V2403-M-DI-T] | Valve Seat Tightness | No fuel leak at<br>16.67 MPa<br>170.0 kgf/cm <sup>2</sup><br>2418 psi | –               |

**ELECTRICAL SYSTEM**

| Item                              |  | Factory Specification                             | Allowable Limit       |
|-----------------------------------|--|---|-----------------------|
| Starter                           | • Commutator<br>[D1503-M, D1703-M, V2003-M,<br>V2203-M, D1803-M-DI, D1703-M-BG,<br>V2003-M-BG, V2003-M-T-BG,<br>V2203-M-BG]  | O.D.<br>30.0 mm<br>1.18 in.                       | 29.0 mm<br>1.14 in.   |
|                                   | [D1803-M, V2403-M, V2403-M-DI,<br>V2403-M-T, V2403-M-DI-T,<br>V2403-M-BG]  | O.D.<br>35.0 mm<br>1.38 in.                       | 34.0 mm<br>1.34 in.   |
|                                   | • Mica<br>[D1503-M, D1703-M, D1803-M,<br>V2003-M, V2203-M, V2403-M,<br>V2403-M-T, D1803-M-DI, V2403-M-DI,<br>V2403-M-DI-T, D1703-M-BG,<br>V2003-M-BG, V2003-M-T-BG,<br>V2203-M-BG] | Undercut<br>0.45 to 0.75 mm<br>0.018 to 0.029 in. | 0.20 mm<br>0.0079 in. |
|                                   | • Mica<br>[V2403-M-BG]   | Undercut<br>0.55 to 0.85 mm<br>0.022 to 0.033 in. | 0.20 mm<br>0.0079 in. |
|                                   | • Brush<br>[D1503-M, D1703-M, V2003-M,<br>V2203-M, D1803-M-DI, D1703-M-BG,<br>V2003-M-BG, V2003-M-T-BG,<br>V2203-M-BG]   | Length<br>15.0 mm<br>0.591 in.                    | 11.0 mm<br>0.433 in.  |
|                                   | • Brush<br>[D1803-M, V2403-M, V2403-M-DI,<br>V2403-M-T, V2403-M-DI-T]  | Length<br>15.0 mm<br>0.591 in.                    | 9.0 mm<br>0.35 in.    |
|                                   | • Brush<br>[V2403-M-BG]  | Length<br>15.0 mm<br>0.591 in.                    | 12.0 mm<br>0.472 in.  |
| • Brush Holder and Holder Support | Resistance   | Infinity  | –                     |
| Alternator                        | No-load voltage  | More than 13.5 V                                  | –                     |
| • Stator                          | Resistance   | Less than 1.0 Ω                                   | –                     |
| • Rotor                           | Resistance   | 2.9 Ω   | –                     |
| • Slip Ring                       | O.D.   | 14.4 mm<br>0.567 in.                              | 14.0 mm<br>0.551 in.  |
| • Brush                           | Length   | 10.5 mm<br>0.413 in.                              | 8.4 mm<br>0.33 in.    |
| Glow Plug                         | Resistance   | Approx. 0.9 Ω                                     | –                     |

M00000003ENS0007US1

### 3. TIGHTENING TORQUES

Use a torque wrench to tighten the screws, bolts and nuts to the specified torque. Tighten the screws, bolts and nuts used, such as on the cylinder head in the correct sequence and torque.

M00000003ENS0012US1

#### [1] TIGHTENING TORQUES OF SCREWS, BOLTS AND NUTS FOR GENERAL USE

If the tightening torque is not specified, refer to the table below for the none specified torques values.

| Indication on top of bolt |  No-grade or 4T   |              |            |  7T |              |              |
|---------------------------|--|--------------|------------|--|--------------|--------------|
| Indication on top of nut  |   No-grade or 4T |              |            |  |              |              |
| Unit                      | N·m  | kgf·m        | lbf·ft     | N·m  | kgf·m        | lbf·ft       |
| <b>M6</b>                 | 7.9 to 9.3   | 0.80 to 0.95 | 5.8 to 6.8 | 9.81 to 11.2   | 1.00 to 1.15 | 7.24 to 8.31 |
| <b>M8</b>                 | 18 to 20   | 1.8 to 2.1   | 13 to 15   | 24 to 27   | 2.4 to 2.8   | 18 to 20     |
| <b>M10</b>                | 40 to 45   | 4.0 to 4.6   | 29 to 33   | 49 to 55   | 5.0 to 5.7   | 37 to 41     |
| <b>M12</b>                | 63 to 72   | 6.4 to 7.4   | 47 to 53   | 78 to 90   | 7.9 to 9.2   | 58 to 66     |

M00000003ENS0013US1

## [2] TIGHTENING TORQUES OF THE SCREWS, BOLTS AND NUTS FOR SPECIAL USE

### ■ NOTE

- For the screws, bolts and nuts with the mark "\*\*\*", apply engine oil to their threads and seats before you tighten.
- The alphabet "M" in Dimension × Pitch shows that the screw, bolt or nut dimensions are in the metric system. The dimension is the nominal external diameter in mm of the threads. The pitch is the nominal distance in mm between 2 threads.

| Item   | Dimension × Pitch | N·m          | kgf·m         | lbf·ft       |
|--|-------------------|--------------|---------------|--------------|
| Cylinder head cover screw                      | M6 × 1.0          | 6.87 to 11.2 | 0.700 to 1.15 | 5.07 to 8.31 |
| *Cylinder head screw                           | M11 × 1.25        | 93.2 to 98.0 | 9.50 to 10.0  | 68.8 to 72.3 |
| *Screw 1 of main bearing case                  | M9 × 1.25         | 46 to 50     | 4.7 to 5.2    | 34 to 37     |
| *Screw 2 of main bearing case                  | M10 × 1.25        | 69 to 73     | 7.0 to 7.5    | 51 to 54     |
| *Flywheel screw                                | M12 × 1.25        | 98.1 to 107  | 10.0 to 11.0  | 72.4 to 79.5 |
| *Connecting rod screw (Old type)               | M8 × 1.0          | 45 to 49     | 4.5 to 5.0    | 33 to 36     |
| *Connecting rod screw (New type)               | M8 × 1.0          | 41 to 45     | 4.1 to 4.6    | 30 to 33     |
| *Rocker arm bracket screw                      | M8 × 1.25         | 24 to 27     | 2.4 to 2.8    | 18 to 20     |
| *Idle gear shaft screw                         | M8 × 1.25         | 24 to 27     | 2.4 to 2.8    | 18 to 20     |
| Mounting nut of fan drive pulley               | M30 × 1.5         | 138 to 156   | 14.0 to 16.0  | 102 to 115   |
| *Mounting screw of bearing case cover          | M8 × 1.25         | 24 to 27     | 2.4 to 2.8    | 18 to 20     |
| Glow plug                                      | M10 × 1.25        | 20 to 24     | 2.0 to 2.5    | 15 to 18     |
| Nozzle holder assembly (IDI)                   | M20 × 1.5         | 49 to 68     | 5.0 to 7.0    | 37 to 50     |
| Nozzle holder (IDI)                            | –                 | 35 to 39     | 3.5 to 4.0    | 26 to 28     |
| Nozzle holder clamp screw (DI)                 | M10 × 1.25        | 26 to 29     | 2.6 to 3.0    | 19 to 21     |
| Oil pressure switch                            | R 1/8             | 15 to 19     | 1.5 to 2.0    | 11 to 14     |
| Injection pipe retaining nut (IDI)             | M12 × 1.5         | 25 to 34     | 2.5 to 3.5    | 18 to 25     |
| Injection pipe retaining nut (DI)              | M12 × 1.5         | 15 to 24     | 1.5 to 2.5    | 11 to 18     |
| Retaining nut of overflow pipe assembly (IDI)  | M12 × 1.5         | 20 to 24     | 2.0 to 2.5    | 15 to 18     |
| Retaining screw of overflow pipe assembly (DI) | M6 × 1.0          | 9.81 to 11.2 | 1.00 to 1.15  | 7.24 to 8.31 |
| Camshaft set screw                             | M8 × 1.25         | 24 to 27     | 2.4 to 2.8    | 18 to 20     |
| Hi-idling body                                 | M14 × 1.0         | 45 to 49     | 4.5 to 5.0    | 33 to 36     |



| Item  | Dimension × Pitch | N·m          | kgf·m        | lbf·ft       |
|---|-------------------|--------------|--------------|--------------|
| Set bolt of the balancer shaft 1<br>(Balancer model only) | M8 × 1.25         | 24 to 27     | 2.4 to 2.8   | 18 to 20     |
| Set bolt of the balancer shaft 2<br>(Balancer model only) | M8 × 1.25         | 24 to 27     | 2.4 to 2.8   | 18 to 20     |
| Pulley nut of alternator                                  | —                 | 58.4 to 78.9 | 5.95 to 8.05 | 43.1 to 58.2 |
| Set screw of idle gear 2 stopper<br>(Side PTO model only) | —                 | 49 to 55     | 5.0 to 5.7   | 37 to 41     |
| Set screw of idle gear 2 shaft<br>(Side PTO model only)   | —                 | 24 to 27     | 2.4 to 2.8   | 18 to 20     |
| <b>B</b> terminal nut of starter                          | M8                | 5.9 to 11    | 0.60 to 1.2  | 4.4 to 8.6   |

IDI : D1503-M, D1703-M, D1803-M, V2003-M, V2203-M, V2403-M, V2403-M-T, D1703-M-BG, V2003-M-BG, V2003-M-T-BG, V2203-M-BG, V2403-M-BG

DI : D1803-M-DI, V2403-M-DI, V2403-M-DI-T

#### ■ NOTE

- Connecting rod screw

|  | Old Type   | New Type   |
|--|--|--|
| Part No.                               | 15521-22140  | 1J700-22140  |
| The serration shape and the screw head |  <p>9Y1210257ENS002A</p> |  <p>9Y1210257ENS003A</p> |
| Tightening torque                      | 45 to 49 N·m<br>4.5 to 5.0 kgf·m<br>33 to 36 lbf·ft  | 41 to 45 N·m<br>4.1 to 4.6 kgf·m<br>30 to 33 lbf·ft  |

(1) Serration (Spiral)

(2) Serration (Axial Direction)

(3) 26 mm (1.0 in.)


(4) 13 mm (0.51 in.)

M00000003ENS0015US1

## 4. CHECKING, DISASSEMBLING AND SERVICING

### [1] CHECKING AND ADJUSTING

#### (1) Engine Body



#### Compression Pressure

[D1503-M, D1703-M, D1803-M, V2003-M, V2203-M, V2403-M, V2403-M-T, D1703-M-BG, V2003-M-BG, V2003-M-T-BG, V2203-M-BG, V2403-M-BG]


1. Operate the engine for warming-up.
2. Stop the engine.
3. Disconnect the **2P** connector from the stop solenoid to stop the fuel supply.
4. Remove the air cleaner, the muffler and all injection nozzles.
5. Set a compression tester with the adaptor to the nozzle hole.
6. Make sure that the stop lever is set at the stop position (non-injection).
7. Crank the engine with the starter to measure the compression pressure.
8. Do the steps 5 through 7 again for each cylinder.
9. If the measurement is below the allowable limit, apply a small quantity of oil to the cylinder wall through the nozzle hole. Then measure the compression pressure again.
10. If the compression pressure stays below the allowable limit, check the top clearance, valve and cylinder head.
11. If the compression pressure increases after you apply oil, check the cylinder wall and piston rings.

#### ■ NOTE

- Check the compression pressure with the specified valve clearance.
- Always use a fully charged battery for you do this test.
- Variances in cylinder compression values must be less than 10 %.

|                      |                       |  |
|----------------------|-----------------------|--|
| Compression pressure | Factory specification | 3.24 to 3.72 MPa<br>33.0 to 38.0 kgf/cm <sup>2</sup><br>470 to 540 psi |
|                      | Allowable limit       | 2.55 MPa<br>26.0 kgf/cm <sup>2</sup><br>370 psi                        |

M00000003ENS0016US1



### Compression Pressure

#### [D1803-M-DI, V2403-M-DI, V2403-M-DI-T]




1. Operate the engine for warming-up.
2. Stop the engine.
3. Disconnect the **2P** connector from the stop solenoid to stop the fuel supply.
4. Remove the air cleaner, the muffler and all glow plugs.
5. Set a compression tester (07909-39081) with the adaptor **K** (07909-31291) to the glow plug hole.
6. Crank the engine with the starter to measure the compression pressure.
7. Do the steps 5 through 6 again for each cylinder.
8. If the measurement is below the allowable limit, check the cylinder wall and piston rings.

#### ■ NOTE

- Check the compression pressure with the specified valve clearance.
- Always use a fully charged battery for you do this test.
- Variances in cylinder compression values must be less than 10 %.

|                      |                       |  |
|----------------------|-----------------------|--|
| Compression pressure | Factory specification | 2.95 to 3.23 MPa<br>30.0 to 33.0 kgf/cm <sup>2</sup><br>427 to 469 psi |
|                      | Allowable limit       | 2.35 MPa<br>24.0 kgf/cm <sup>2</sup><br>341 psi                        |

M00000003ENS0017US1



**Valve Clearance**

■ **IMPORTANT**

• You must check and adjust the valve clearance when the engine is cold.

1. Remove the head cover.
2. Align the "1TC" mark line (3) on the flywheel and projection (2) on the housing. Make sure that the No.1 piston comes to the compression or overlap top dead center.
3. Check the subsequent valve clearance (1) at the mark "☆" with a feeler gauge.
4. If the clearance is out of the factory specifications, adjust with the adjusting screw.

|                 |                       |   |
|-----------------|-----------------------|---|
| Valve clearance | Factory specification | 0.18 to 0.22 mm<br>0.0071 to 0.0086 in. |
|-----------------|-----------------------|---|

■ **NOTE**

- The "1TC" mark line on the flywheel is only for the No. 1 cylinder. There is no "TC" mark for the other cylinders.
- Align the "TC" mark with the projection (2) in the window on the flywheel-housing. No. 1 piston is on the top dead center position at this time. Turn the flywheel 0.26 rad (15 °) to see if the piston is at the compression top dead center or the overlap position. Refer to the table below to adjust the valve clearance (1) again. (The piston is at the compression top dead center when both the IN. and EX. valves do not move. The piston is at the overlap position when both the valves move.)
- Turn the flywheel 6.28 rad (360 °) and align the "1TC" mark line with the projection (2) correctly. Adjust all the other valve clearance if necessary.
- After you turn the flywheel counterclockwise 2 or 3 times, check the valve clearance (1) again.
- After you adjust the valve clearance (1), tighten the lock nut of the adjusting screw.


| Adjustable Cylinder Location of Piston              |       | Valve Arrangement |     |            |     |
|---|-------|-------------------|-----|------------|-----|
|   |       | 3 Cylinder        |     | 4 Cylinder |     |
|   |       | IN.               | EX. | IN.        | EX. |
| When No. 1 piston is at compression top dead center | No. 1 | ☆                 | ☆   | ☆          | ☆   |
|   | No. 2 |                   | ☆   | ☆          |     |
|   | No. 3 | ☆                 |     |            | ☆   |
|   | No. 4 | -                 | -   |            |     |
| When No. 1 piston is at overlap position            | No. 1 |                   |     |            |     |
|   | No. 2 | ☆                 |     |            | ☆   |
|   | No. 3 |                   | ☆   | ☆          |     |
|   | No. 4 | -                 | -   | ☆          | ☆   |

- (1) Valve Clearance  
(2) Projection

- (3) 1TC Mark Line

M00000003GEG0036US1

## (2) Lubricating System



### Engine Oil Pressure

1. Remove the engine oil pressure switch, and set the oil pressure tester (Code No. : 07916-32032). (Adaptor screw : PT 1/8)
2. Operate the engine for warming-up.
3. Measure the oil pressure at the idle speed and rated speed.
4. If the oil pressure is less than the allowable limit, do a check below.
  - Engine oil level
  - Oil pump
  - Oil strainer
  - Oil filter cartridge
  - Oil passage
  - Oil clearance
  - Relief valve

|                     |                |                       |  |
|---------------------|----------------|-----------------------|--|
| Engine oil pressure | At idle speed  | Factory specification | More than 98 kPa<br>1.0 kgf/cm <sup>2</sup><br>14 psi            |
|                     |                | Allowable limit       | 50 kPa<br>0.5 kgf/cm <sup>2</sup><br>7 psi                       |
|                     | At rated speed | Factory specification | 300 to 440 kPa<br>3.0 to 4.5 kgf/cm <sup>2</sup><br>43 to 64 psi |
|                     |                | Allowable limit       | 250 kPa<br>2.5 kgf/cm <sup>2</sup><br>36 psi                     |


### (When reassembling)

- After you check the oil pressure of the engine, tighten its oil pressure switch to the specified torque.

|                   |                     |   |
|-------------------|---------------------|---|
| Tightening torque | Oil pressure switch | 15 to 19 N·m<br>1.5 to 2.0 kgf·m<br>11 to 14 lbf·ft |
|-------------------|---------------------|---|

M00000003ENS0019US1

## (3) Cooling System




### Fan Belt Tension

1. Push the belt halfway between the fan drive pulley and alternator pulley at a specified force 98 N (10 kgf, 22 lbf) to measure the deflection **(A)**.
2. If the measurement is out of the factory specifications, loosen the alternator mounting screws and adjust its position.

|                       |                       |                                   |
|-----------------------|-----------------------|-----------------------------------|
| Deflection <b>(A)</b> | Factory specification | 7.0 to 9.0 mm<br>0.28 to 0.35 in. |
|-----------------------|-----------------------|-----------------------------------|

### (A) Deflection

M00000003GEG0016US1




**Fan Belt Damage and Wear**

1. Check the fan belt for damage.
2. If the fan belt has a damage, replace it.
3. Check if the fan belt is worn out and sunk in the pulley groove.
4. If it is, replace it.

(A) Good

(B) Bad


M00000003GEG0017US1



**CAUTION**

- Remove the radiator cap only after you stop the engine for a minimum of 10 minutes to decrease its temperature. If not, hot water can gush out and cause injury.

M00000003ENS0022US1




**Radiator Cap Air Leakage**

1. Set a radiator tester and an adaptor on the radiator cap.
2. Apply the specified pressure 90 kPa (0.9 kgf/cm<sup>2</sup>, 10 psi), and measure the time for the pressure to decrease to 60 kPa (0.6 kgf/cm<sup>2</sup>, 9 psi).
3. If the measurement is less than the factory specification, replace the radiator cap.

|                          |                       |   |
|--------------------------|-----------------------|---|
| Pressure decreasing time | Factory specification | More than 10 seconds for pressure decrease from 90 to 60 kPa (from 0.9 to 0.6 kgf/cm <sup>2</sup> , from 10 to 9 psi) |
|--------------------------|-----------------------|---|

M00000003ENS0023US1



**Radiator Water Leakage**


1. Fill a specified quantity of water into the radiator.
2. Increase the water pressure to the specified pressure with the radiator tester and adaptor.
3. Check the radiator for water leakage.
4. For water leakages from the pinhole, replace the radiator or repair with the radiator cement. When water leak is too much, replace the radiator.

|                             |                       |                               |
|-----------------------------|-----------------------|-------------------------------|
| Radiator water leakage test | Factory specification | No leak at specified pressure |
|-----------------------------|-----------------------|-------------------------------|

**NOTE**

- The pressure of the leak test is different for each radiator specification. Thus, refer to the test pressure of each radiator specification to do the leakage test.

M00000003ENS0024US1








**Opening-temperature of Thermostat Valve**

1. Hang the thermostat in the water by a string with its end put between the valve and the seat.
2. Increase the temperature of the water gradually, read the temperature when the valve opens and disconnects the string.
3. Continue to increase the temperature and read the temperature when the valve opens approximately 6 mm (0.2 in.).
4. If the measurement is out of the factory specifications, replace the thermostat.

|   |                       |  |                                      |
|---|-----------------------|--|--------------------------------------|
| Opening-temperature<br>(When the valve starts to open)    | Factory specification | D1503-M,<br>D1703-M,<br>D1803-M,<br>V2003-M,<br>V2203-M,<br>V2403-M,<br>V2403-M-T,<br>D1703-M-BG,<br>V2003-M-BG,<br>V2003-M-T-BG,<br>V2203-M-BG,<br>V2403-M-BG | 69.5 to 72.5 °C<br>157.1 to 162.5 °F |
|   |                       | D1803-M-DI,<br>V2403-M-DI,<br>V2403-M-DI-T   | 80.5 to 83.5 °C<br>176.9 to 182.3 °F |
| Opening-temperature<br>(When the valve opened completely) | Factory specification | D1503-M,<br>D1703-M,<br>D1803-M,<br>V2003-M,<br>V2203-M,<br>V2403-M,<br>V2403-M-T,<br>D1703-M-BG,<br>V2003-M-BG,<br>V2003-M-T-BG,<br>V2203-M-BG,<br>V2403-M-BG | 85 °C<br>185 °F                      |
|   |                       | D1803-M-DI,<br>V2403-M-DI,<br>V2403-M-DI-T   | 95 °C<br>203 °F                      |

M0000003ENS0025US1

### (4) Fuel System



#### Injection Timing

[D1503-M, D1703-M, D1803-M, V2003-M, V2203-M, V2403-M, V2403-M-T, D1703-M-BG, V2003-M-BG, V2003-M-T-BG, V2203-M-BG, V2403-M-BG]

1. Remove the solenoid.
2. Remove the injection pipes and the glow plugs.
3. Set the speed control lever to the position of maximum fuel discharge.

#### (Reference)

- Turn the flywheel with a screwdriver.
4. Turn the flywheel counterclockwise (refer to the figure) until the fuel comes to the hole of the delivery valve holder for the first cylinder.
  5. Turn the flywheel more and stop when the fuel starts to flow out, to get the injection timing.
  6. Calculate the angle at which the center of the window points out. (The flywheel has a mark 1TC and 4 lines that shows every 0.09 rad (5 °) of crank angle from 0.17 rad (10 °) to 0.44 rad (25 °) before mark 1TC.)
  7. If the result is different from specified injection timing, add or remove the shim to adjust.

|                  |                       |  |   |
|------------------|-----------------------|--|---|
| Injection timing | Factory specification | D1503-M, V2003-M-T-BG                          | 0.253 to 0.279 rad (14.5 to 16.0 °) before T.D.C. |
|                  |                       | D1703-M, D1803-M, V2003-M, V2203-M, V2403-M    | 0.271 to 0.296 rad (15.5 to 17.0 °) before T.D.C. |
|                  |                       | V2403-M-T                                      | 0.132 to 0.157 rad (7.55 to 9.05 °) before T.D.C. |
|                  |                       | D1703-M-BG, V2003-M-BG, V2203-M-BG, V2403-M-BG | 0.236 to 0.261 rad (13.5 to 15.0 °) before T.D.C. |

- (1) Delivery Valve Holder
  - (2) Timing Mark
  - (3) 2-Holes : 0.20 mm (0.0079 in.) Shim
  - (4) 1-Hole : 0.25 mm (0.0098 in.) Shim
  - (5) Without Hole : 0.30 mm (0.012 in.) Shim
  - (6) 2-Holes : 0.175 mm (0.00689 in.) Shim
- (A) 3 Cylinder  
(B) 4 Cylinder


(To be continued)

(Continued)

■ **NOTE**

- The sealant is applied to the 2 sides of the soft metal gasket shim. The liquid gasket is not necessary to assemble.
- The shims are available in thickness of 0.175 mm (0.00689 in.) (6), 0.20 mm (0.0079 in.) (3), 0.25 mm (0.0098 in.) (4) and 0.30 mm (0.012 in.) (5). Make a combination of these shims for adjustment.
- The 0.175 mm (0.00689 in.) thick shim has only a thin layer on the lower face. Thus, do not use the 0.175 mm (0.00689 in.) thick shim as the top shim of the combination (injection pump side). If not, it can cause oil leakage.
- Addition or reduction of shim (0.05 mm, 0.002 in.) delays or advances the injection timing by approx. 0.009 rad (0.5 °).
- When you disassemble or replace, make sure that you use the same number of new gasket shims with the same thickness.

M00000003ENS0026US1







**Injection Timing**

**[D1803-M-DI, V2403-M-DI, V2403-M-DI-T]**

1. Remove the solenoid.
2. Remove the injection pipes and the glow plugs.
3. Set the speed control lever to the position of maximum fuel discharge.

**(Reference)**

- Turn the flywheel with screwdriver.
4. Turn the flywheel counterclockwise (refer to the figure) until the fuel comes to the hole of the delivery valve holder for the first cylinder.
  5. Turn the flywheel more and stop when the fuel starts to flow out, to get the injection timing.
  6. Calculate the angle at which the center of the window points out. (The flywheel has a mark 1TC and 4 lines that shows every 0.09 rad (5 °) of crank angle from 0.17 rad (10 °) to 0.44 rad (25 °) before mark 1TC.)
  7. If the result is different from specified injection timing, add or remove the shim to adjust.




|                  |                       |                          |  |
|------------------|-----------------------|--------------------------|--|
| Injection timing | Factory specification | D1803-M-DI<br>V2403-M-DI | 0.0742 to 0.100 rad<br>(4.25 ° to 5.75 °)<br>before T.D.C. |
|                  |                       | V2403-M-DI-T             | 0.0829 to 0.109 rad<br>(4.75 ° to 6.25 °)<br>before T.D.C. |

**NOTE**

- The sealant is applied to the 2 sides of the soft metal gasket shim. The liquid gasket is not necessary to assemble.
- The shims are available in thickness of 0.175 mm (0.00689 in.) (7), 0.20 mm (0.0079 in.) (3), 0.25 mm (0.0098 in.) (4), 0.30 mm (0.012 in.) (5) and 0.35 mm (0.014 in.) (6). Make a combination of these shims for adjustment.
- The 0.175 mm (0.00689 in.) thick shim has only a thin layer on the lower face. Thus, do not use the 0.175 mm (0.00689 in.) thick shim as the top shim of the combination (injection pump side). If not, it can cause oil leakage.
- Addition or reduction of shim (0.05 mm, 0.002 in.) delays or advances the injection timing by approx. 0.009 rad (0.5 °).
- When you disassemble or replace, make sure that you use the same number of new gasket shims with the same thickness.

- |   |                |
|---|----------------|
| (1) Delivery Valve Holder                   | (A) 3 Cylinder |
| (2) Timing Mark                             | (B) 4 Cylinder |
| (3) 2-Holes : 0.20 mm (0.0079 in.) Shim     |                |
| (4) 1-Hole : 0.25 mm (0.0098 in.) Shim      |                |
| (5) Without Hole : 0.30 mm (0.012 in.) Shim |                |
| (6) 3-Holes : 0.35 mm (0.014 in.) Shim      |                |
| (7) 2-Holes : 0.175 mm (0.00689 in.) Shim   |                |

M00000003ENS0027US1



### Fuel Tightness of Pump Element

[D1503-M, D1703-M, D1803-M, V2003-M, V2203-M, V2403-M, V2403-M-T, D1703-M-BG, V2003-M-BG, V2003-M-T-BG, V2203-M-BG, V2403-M-BG]

1. Remove the solenoid.
2. Remove the injection pipes and glow plugs.
3. Set the injection pump pressure tester to the injection pump.
4. Set the injection nozzle (2) jetted with the correct injection pressure to the injection pump pressure tester (1). (Refer to the figure.)
5. Set the speed control lever to the maximum speed position.
6. Crank the engine with the starter to increase the pressure.
7. If the pressure is lower than the allowable limit, replace the pump with a new one.

You can also repair the pump at a KUBOTA-authorized pump service shop.


|                                |                 |  |
|--------------------------------|-----------------|--|
| Fuel tightness of pump element | Allowable limit | 13.73 MPa<br>140.0 kgf/cm <sup>2</sup><br>1991 psi |
|--------------------------------|-----------------|--|

#### NOTE

- Do not try to disassemble the injection pump assembly. Repair the pump at a KUBOTA-authorized pump service shop.

- (1) Injection Pump Pressure Tester      (3) Protection Cover for Jetted Fuel  
(2) Injection Nozzle

M00000003ENS0028US1



### Fuel Tightness of Pump Element

[D1803-M-DI, V2403-M-DI, V2403-M-DI-T]

1. Remove the solenoid.
2. Remove the injection pipes and glow plugs.
3. Set the injection pump pressure tester to the injection pump.
4. Set the injection nozzle (2) jetted with the correct injection pressure to the injection pump pressure tester (1). (Refer to the figure.)
5. Set the speed control lever to the maximum speed position.
6. Crank the engine with the starter to increase the pressure.
7. If the pressure is lower than the allowable limit, replace the pump with a new one.

You can also repair the pump at a KUBOTA-authorized pump service shop.


|                                |                 |  |
|--------------------------------|-----------------|--|
| Fuel tightness of pump element | Allowable limit | 18.63 MPa<br>190.0 kgf/cm <sup>2</sup><br>2702 psi |
|--------------------------------|-----------------|--|

#### NOTE

- Do not try to disassemble the injection pump assembly. Repair the pump at a KUBOTA-authorized pump service shop.

- (1) Injection Pump Pressure Tester      (3) Protection Cover for Jetted Fuel  
(2) Injection Nozzle

M00000003ENS0029US1



### Fuel Tightness of Delivery Valve

[D1503-M, D1703-M, D1803-M, V2003-M, V2203-M, V2403-M, V2403-M-T, D1703-M-BG, V2003-M-BG, V2003-M-T-BG, V2203-M-BG, V2403-M-BG]

1. Remove the solenoid.
2. Remove the injection pipes and glow plugs.
3. Set the injection pump pressure tester to the injection pump.
4. Set the injection nozzle (2) jetted with the correct injection pressure to the injection pump pressure tester (1).
5. Crank the engine with the starter to increase the pressure.
6. Stop the starter when the fuel jets from the injection nozzle. Then turn the flywheel manually and increase the pressure to approx. 13.73 MPa (140.0 kgf/cm<sup>2</sup>, 1991 psi).
7. Turn the flywheel back about half a turn (to keep the plunger free) and keep the flywheel at this position.
8. Measure the time for the pressure to decrease from 13.73 to 12.75 MPa (140.0 to 130.0 kgf/cm<sup>2</sup>, 1991 to 1849 psi).
9. If the measurement is less than allowable limit, replace the pump with a new one.

You can also repair the pump at a KUBOTA-authorized pump service shop.


|                                  |                       |   |
|----------------------------------|-----------------------|---|
| Fuel tightness of delivery valve | Factory specification | 10 seconds<br>13.73 → 12.75 MPa<br>140.0 → 130.0 kgf/cm <sup>2</sup><br>1991 → 1849 psi |
|                                  | Allowable limit       | 5 seconds<br>13.73 → 12.75 MPa<br>140.0 → 130.0 kgf/cm <sup>2</sup><br>1991 → 1849 psi  |

#### ■ NOTE

- **Do not try to disassemble the injection pump assembly. Repair the pump at a KUBOTA-authorized pump service shop.**

- (1) Injection Pump Pressure Tester      (3) Protection Cover for Jetted Fuel  
(2) Injection Nozzle

M00000003ENS0030US1



### Fuel Tightness of Delivery Valve

#### [D1803-M-DI, V2403-M-DI, V2403-M-DI-T]

1. Remove the solenoid.
2. Remove the injection pipes and glow plugs.
3. Set the injection pump pressure tester to the injection pump.
4. Set the injection nozzle (2) jetted with the correct injection pressure to the injection pump pressure tester (1).
5. Crank the engine with the starter to increase the pressure.
6. Stop the starter when the fuel jets from the injection nozzle. Then turn the flywheel manually and increase the pressure to approx. 18.63 MPa (190.0 kgf/cm<sup>2</sup>, 2702 psi).
7. Turn the flywheel back about half a turn (to keep the plunger free) and keep the flywheel at this position.
8. Measure the time for the pressure to decrease from 18.63 to 17.65 MPa (190.0 to 180.0 kgf/cm<sup>2</sup>, 2702 to 2560 psi).
9. If the measurement is less than allowable limit, replace the pump with a new one.  
You can also repair the pump at a KUBOTA-authorized pump service shop.

|                                  |                       |   |
|----------------------------------|-----------------------|---|
| Fuel tightness of delivery valve | Factory specification | 10 seconds<br>18.63 → 17.65 MPa<br>190.0 → 180.0 kgf/cm <sup>2</sup><br>2702 → 2560 psi |
|                                  | Allowable limit       | 5 seconds<br>18.63 → 17.65 MPa<br>190.0 → 180.0 kgf/cm <sup>2</sup><br>2702 → 2560 psi  |

#### ■ NOTE

- **Do not try to disassemble the injection pump assembly. Repair the pump at a KUBOTA-authorized pump service shop.**


- (1) Injection Pump Pressure Tester      (3) Protection Cover for Jetted Fuel  
(2) Injection Nozzle

M0000003ENS0031US1

**CAUTION**

- Check the injection pressure and condition after you make sure that there is no one in the direction of the fumes.
- If the fumes from the nozzle directly touches the human body, they can cause damage to the cells and blood poisoning.

M00000003GEG0037US1




**Nozzle Fume Condition**

[D1503-M, D1703-M, D1803-M, V2003-M, V2203-M, V2403-M, V2403-M-T, D1703-M-BG, V2003-M-BG, V2003-M-T-BG, V2203-M-BG, V2403-M-BG]

1. Set the injection nozzle to a nozzle tester, and check the condition of the fumes from the nozzle.
2. If the fume condition is defective, replace the nozzle piece.

(A) Good (B) Bad

M00000003GEG0038US1




**Nozzle Fume Condition**

[D1803-M-DI, V2403-M-DI, V2403-M-DI-T]

1. Set the injection nozzle to a nozzle tester, and check the condition of the fumes from the nozzle.
2. If the fume condition is defective, replace the injection nozzle assembly.

(A) Good (a) 1.3 rad (72 °)  
(B) Bad

M00000003GEG0039US1



**Fuel Injection Pressure**

[D1503-M, D1703-M, D1803-M, V2003-M, V2203-M, V2403-M, V2403-M-T, D1703-M-BG, V2003-M-BG, V2003-M-T-BG, V2203-M-BG, V2403-M-BG]

1. Set the injection nozzle to a nozzle tester.
2. Slowly move the tester lever to measure the pressure at which the fuel start to jet out from the nozzle.
3. If the measurement is out of the factory specifications, replace the adjusting washer (1) in the nozzle holder.


**(Reference)**


- The pressure variation with 0.025 mm (0.00098 in.) difference in washer thickness is approximately 590 kPa (6.0 kgf/cm<sup>2</sup>, 85 psi).

|                         |                       |  |
|-------------------------|-----------------------|--|
| Fuel injection pressure | Factory specification | 13.73 to 14.70 MPa<br>140.0 to 150.0 kgf/cm <sup>2</sup><br>1992 to 2133 psi |
|-------------------------|-----------------------|--|

(1) Adjusting Washer

M00000003GEG0040US1






**Fuel Injection Pressure**

**[D1803-M-DI, V2403-M-DI, V2403-M-DI-T]**

1. Set the injection nozzle to a nozzle tester.
2. Slowly move the tester lever to measure the pressure at which the fuel start to jet out from the nozzle.
3. If the measurement is out of the factory specifications, replace the injection nozzle assembly.

|                                     |                       |  |
|-------------------------------------|-----------------------|--|
| Fuel injection pressure (1st stage) | Factory specification | 18.64 to 20.10 MPa<br>190.0 to 205.0 kgf/cm <sup>2</sup><br>2703 to 2915 psi |
|-------------------------------------|-----------------------|--|

M00000003GEG0041US1




**Valve Seat Tightness**

**[D1503-M, D1703-M, D1803-M, V2003-M, V2203-M, V2403-M, V2403-M-T, D1703-M-BG, V2003-M-BG, V2003-M-T-BG, V2203-M-BG, V2403-M-BG]**

1. Set the injection nozzle to a nozzle tester.
2. Increase the fuel pressure, and keep it at 12.75 MPa (130.0 kgf/cm<sup>2</sup>, 1849 psi) for 10 seconds.
3. If you find a fuel leakage, replace the nozzle piece.

|                      |                       |   |
|----------------------|-----------------------|---|
| Valve seat tightness | Factory specification | No fuel leak at<br>12.75 MPa<br>130.0 kgf/cm <sup>2</sup><br>1849 psi |
|----------------------|-----------------------|---|

M00000003GEG0042US1




**Valve Seat Tightness**

**[D1803-M-DI, V2403-M-DI, V2403-M-DI-T]**

1. Set the injection nozzle to a nozzle tester.
2. Increase the fuel pressure, and keep it at 16.67 MPa (170.0 kgf/cm<sup>2</sup>, 2418 psi) for 10 seconds.
3. If you find a fuel leakage, replace the injection nozzle assembly.

|                      |                       |   |
|----------------------|-----------------------|---|
| Valve seat tightness | Factory specification | No fuel leak at<br>16.67 MPa<br>170.0 kgf/cm <sup>2</sup><br>2418 psi |
|----------------------|-----------------------|---|

M00000003GEG0043US1



3EEABAB1P171A

**Nozzle Holder**

[D1503-M, D1703-M, D1803-M, V2003-M, V2203-M, V2403-M, V2403-M-T, D1703-M-BG, V2003-M-BG, V2003-M-T-BG, V2203-M-BG, V2403-M-BG]

1. Hold the nozzle retaining nut (7) with a vise.
2. Remove the nozzle holder (1), and remove the internal parts.

**(When reassembling)**

- Assemble the nozzle in clean fuel oil.
- Install the push rod (4) correctly in its direction.
- After you assemble the nozzle, adjust the fuel injection pressure.

|                   |                             |   |
|-------------------|-----------------------------|---|
| Tightening torque | Nozzle holder               | 35 to 39 N·m<br>3.5 to 4.0 kgf·m<br>26 to 28 lbf·ft |
|                   | Overflow pipe retaining nut | 20 to 24 N·m<br>2.0 to 2.5 kgf·m<br>15 to 18 lbf·ft |
|                   | Nozzle holder assembly      | 49 to 68 N·m<br>5.0 to 7.0 kgf·m<br>37 to 50 lbf·ft |

- |                      |                          |
|----------------------|--------------------------|
| (1) Nozzle Holder    | (5) Distance Piece       |
| (2) Adjusting Washer | (6) Nozzle Piece         |
| (3) Nozzle Spring    | (7) Nozzle Retaining Nut |
| (4) Push Rod         |                          |

M00000003GEG0044US1

**(5) Electrical System**


**CAUTION**

- To prevent an accidental short circuit, attach the positive cable to the positive terminal before the negative cable is attached to the negative terminal.
- Do not remove the battery cap while the engine operates.
- Keep electrolyte away from eyes, hands and clothes. If you are spattered with it, clean with water immediately.
- Keep open sparks and flames away from the battery at all times. Hydrogen gas mixed with oxygen becomes very explosive.

**IMPORTANT**

- Do not disconnect or remove the battery when you operate engine.

M00000003ENS0040US1



3EEAEAC1P031A


**Battery Voltage**

1. Stop the engine.
2. Measure the voltage with a circuit tester between the battery terminals.
3. If the battery voltage is less than the factory specification, check the battery specific gravity and charge the battery.

|                 |                       |                |
|-----------------|-----------------------|----------------|
| Battery voltage | Factory specification | More than 12 V |
|-----------------|-----------------------|----------------|

- |                       |                       |
|-----------------------|-----------------------|
| (1) Positive Terminal | (2) Negative Terminal |
|-----------------------|-----------------------|

M00000003ENS0041US1



### Battery Specific Gravity

#### ⚠ CAUTION

- If battery acid (dilute sulfuric acid) gets on you it could cause blindness or burns, or could cause corrosion of machinery and tools so please be careful when handling.
- Wear safety glasses and rubber gloves when performing battery maintenance and inspection (measuring specific gravity, replenishing water, or charging).
- If the gas that is generated is ignited by an ignition source, it may explode so be very careful with sparks and fire.
- Keep your body and face as far away from the battery as you can when performing maintenance and inspection.
- Do not allow people who do not know how to handle a battery or who do not sufficiently understand the danger perform inspection or maintenance.

#### (Measurement items)

##### ■ Zero adjustment

1. Open the cover and drip water on the prism surface using the included rod.
2. Close the cover.
3. Aim in a direction that is bright, look into the lens, and adjust the focus until the gradations can be seen clearly.
4. If the boundary line is not on the gradation baseline (0 position), turn the adjustment screw until it matches.
5. When zero adjustment is complete, wipe the prism and cover surface with a soft cloth or tissue paper.

##### ■ Measurement of test fluid

1. Open the cover and drip test fluid on the prism surface using the included rod.
2. Close the cover.
3. Aim in a direction that is bright, look into the lens and read the gradation of the blue boundary line.
4. When the measurement is complete, wipe the prism and cover surface with a soft cloth or tissue paper.

#### (Reference)

Electrolyte specific gravity and amount of discharge.  
Use the following table as a reference.

|                                  |                            |
|----------------------------------|----------------------------|
| (A) Electrolyte Specific Gravity | (C) Good                   |
| (B) Discharge                    | (D) Charging is necessary. |

#### ■ NOTE


##### Temperature conversion of electrolyte specific gravity

- Battery electrolyte specific gravity changes based on temperature.
- Insert the value identified on a specific gravity meter into the following conversion equation for temperature correction to learn an accurate specific gravity value. (Standard temperature assumed to be 20 °C (68 °F))


$$D_{20} = D_t + 0.0007 (t - 20)$$

$D_{20}$  = specific gravity value converted to standard temperature of 20 °C (68 °F)

$D_t$  = measured specific gravity value at the electrolyte temperature t °C



9Y1210257GEG0003US0



### Motor Test

#### ⚠ CAUTION

- **Hold the starter to prevent its movement when you do a test on the motor.**


1. Disconnect the negative cable from the battery.
2. Disconnect the positive cable from the battery.
3. Disconnect the leads from the starter **B** terminal.
4. Remove the starter from the engine.
5. Connect a jumper lead from the starter **C** terminal (1) to the battery positive terminal (2).
6. Connect a jumper lead momentarily between the starter body and the battery negative terminal (3).
7. If the motor does not operate, starter is defective. Repair or replace the starter.

#### ■ NOTE

- **B terminal** : It is the terminal that connects the cable from the battery to the starter.
- **C terminal** : It is the terminal that connects the cable from the motor to the magnet switch.

- (1) C Terminal (3) Negative Terminal  
(2) Positive Terminal

M00000003ENS0043US1



### Magnetic Switch Test


1. Disconnect the negative cable from the battery.
2. Disconnect the positive cable from the battery.
3. Disconnect the leads from the starter **B** terminal.
4. Remove the starter from the engine.
5. Connect a jumper lead from the starter **S** terminal (1) to the battery positive terminal (2).
6. Connect a jumper lead momentarily between the starter body and the battery negative terminal (3).
7. If the pinion gear does not come out, the magnetic switch is defective. Repair or replace the starter.

#### ■ NOTE

- **B terminal** : It is the terminal that connects the cable from the battery to the starter.
- **S terminal** : It is the terminal that connects the cable from the starter switch to the magnetic switch.

- (1) S Terminal (3) Negative Terminal  
(2) Positive Terminal

M00000003ENS0044US1



### Magnetic Switch Continuity Test

1. Push in the plunger. Then check the continuity across the **C** terminal (1) and the **B** terminal (2) with a circuit tester.
2. If it is not continuous or it shows a value, replace the magnetic switch.

- (1) C Terminal (2) B Terminal

M00000003ENS0045US1



3TMACAD9P012A

## Alternator-on Unit Test

### Before testing

- Before the alternator-on unit test, do a check of the list below :
  - Battery terminal connections
  - Circuit connection
  - Fan belt tension
  - Charge indicator lamp
  - Fuses on the circuit
  - Abnormal noise from the alternator
- Prepare full charged battery for the test.

### NOTE


- **Do not touch the engine parts that turns while the engine operates.**

**Keep a safety distance from the engine parts that turn.**

1. Start the engine.
2. When the engine operates, measure the voltage between battery terminals. If the voltage is between 13.8 V and 14.8 V, the alternator operates correctly.
3. If the results of alternator-on unit test are not in the factory specifications, disassemble the alternator. Check each component part to find out the problem. Refer to "DISASSEMBLING AND ASSEMBLING" and "SERVICING" for the alternator.

|                               |                       |                                    |
|-------------------------------|-----------------------|------------------------------------|
| Regulating voltage at no load | Factory specification | 13.8 to 14.8 V<br>at 25 °C (77 °F) |
|-------------------------------|-----------------------|------------------------------------|

M00000003ENS0046US1




3EJACAA1P014B

## Glow Plug Lead Terminal Voltage

1. Turn the key switch to the "**GLOW** (or **PREHEAT**)" position. Then measure the voltage with a circuit tester between the lead terminal and the engine body.
2. If the voltage is different from the battery voltage, the wiring harness or main switch is defective.

|   |                       |                         |
|---|-----------------------|-------------------------|
| Voltage<br>(Main switch key at<br><b>GLOW</b> (or <b>PREHEAT</b> )) | Factory specification | Approx. battery voltage |
|---|-----------------------|-------------------------|

M00000003ENS0047US1




3TMABAB9P012A

## Glow Plug Continuity

1. Remove the glow plug.
2. Measure the resistance with a circuit tester between the glow plug terminal and the glow plug housing.
3. If the measurement does not show the factory specification, the glow plug is defective.

|            |                       |               |
|------------|-----------------------|---------------|
| Resistance | Factory specification | Approx. 0.9 Ω |
|------------|-----------------------|---------------|

M00000003ENS0048US1



### Engine Stop Solenoid

1. Remove the engine stop solenoid from the engine.
2. Connect the jumper leads from the pulling coil **P** terminal to the switch (4). Then connect from the switch (4) to the battery positive terminal.
3. Connect the jumper leads from the holding coil **H** terminal to the switch (3). Then connect from the switch (3) to the battery positive terminal.
4. Connect the jumper leads from the engine stop solenoid body to the battery negative terminal.
5. After you turn on the switch (4), the solenoid body pulls in the plunger. Then turn off the switch (4) and the plunger comes out.
6. Turn on the switch (3), then turn on the switch (4). The solenoid body pulls in the plunger and keep it in the holding position after you turn off the switch (4).
7. If the solenoid do not attract the plunger, the solenoid is defective.

#### ■ IMPORTANT


- **Do not apply the current to the pulling coil for more than 2 seconds when you check.**

- (1) Connector  
 (2) Battery  
 (3) Switch for Holding Coil  
 (4) Switch for Pulling Coil

**P : Terminal for Pulling Coil**  
**H : Terminal for Holding Coil**

M00000003ENS0049US1

## (6) Turbocharger




### Turbine Side

1. Check the exhaust port (2) and the inlet port (3) side of the turbine housing (1) for exhaust gas leakage.
2. If you find a gas leakage, tighten the bolts and nuts again or replace the gasket with a new one.

- (1) Turbine Housing  
 (2) Exhaust Port  
 (3) Inlet Port

M00000003ENS0050US1




### Compressor Side

1. Check the inlet hose (1) of the compressor cover (2) for air leakage.
2. Check the suction side of the inlet hose for loose connections or cracks.
3. If you find an air leakage, change the clamps (3) and / or the inlet hose.

- (1) Inlet Hose  
 (2) Compressor Cover  
 (3) Clamp

M00000003ENS0051US1







### Radial Clearance

1. If the wheel touches the housing, replace the turbocharger assembly with a new one.

M00000003ENS0052US1

## (7) Electronic Governor



### Speed Sensor

1. Disconnect the connector of the speed sensor (1) (3P).
2. Check the condition of the harness.
3. If the harness is defective, replace it with a new one. Then replace the ECU with a new one.
4. Turn the key switch to the ACC position.
5. Measure the voltage between the terminals of the connector (2) (harness side).
6. If the measurements are not in the factory specifications, the ECU is defective.
7. If the measurements are in the factory specifications, the ECU is correct. In this case, the speed sensor is defective. Then replace it with a new one.

|         |                       |                         |      |
|---------|-----------------------|-------------------------|------|
| Voltage | Factory specification | Terminal 1 – Terminal 3 | 12 V |
|         |                       | Terminal 1 – Terminal 2 | 5 V  |

- (1) Speed Sensor (4) Terminal 2 (Signal)  
 (2) Connector (Harness Side) (5) Terminal 1 (GND)  
 (3) Terminal 3 (+)

M00000003ENS0053US1


### Water Temperature Sensor

1. Disconnect the connector of the water temperature sensor (1) (2P).
2. Check the condition of the harness.
3. If the harness is defective, replace it with a new one.
4. Turn the key switch to the ACC position.
5. Measure the voltage between the terminals of the connector (2) (harness side).
6. If the measurement is not in the factory specification, the ECU is defective. Then replace the ECU with a new one.
7. If the measurement is in the factory specification, the ECU is correct. In this case, the water temperature sensor is defective. Then replace it with a new one.

|         |                       |                         |     |
|---------|-----------------------|-------------------------|-----|
| Voltage | Factory specification | Terminal 1 – Terminal 2 | 5 V |
|---------|-----------------------|-------------------------|-----|

- (1) Water Temperature Sensor (3) Terminal 2 (-)  
 (2) Connector (Harness Side) (4) Terminal 1 (+)

M00000003ENS0054US1



### Oil Pressure Switch





1. Disconnect the connector of the oil pressure switch (1) (1P).
2. Check the condition of the harness.
3. If the harness is defective, replace it with a new one.
4. Measure the resistance between the terminal of the connector (harness side) and chassis.
5. If the measurement is not in the factory specification, the ECU is defective. Then replace the ECU with a new one.
6. If the measurement is in the factory specification, the ECU is correct.

In this case, the oil pressure switch is defective. Then replace it with a new one.

|            |                       |                      |          |
|------------|-----------------------|----------------------|----------|
| Resistance | Factory specification | Terminal 1 – Chassis | Infinity |
|------------|-----------------------|----------------------|----------|

(1) Oil Pressure Switch

M00000003ENS0055US1



**Solenoid**

1. Disconnect the connector of the solenoid (1) (2P).
  2. Check the condition of the harness.
  3. If the harness is defective, replace it with a new one.
  4. Turn the key switch to the ACC position.
  5. Measure the voltage between the terminals of the connector (2) (harness side).
  6. If the measurement is not in the factory specification, the ECU is defective. Then replace the ECU with a new one.
  7. If the measurement is in the factory specification, the ECU is correct.
- In this case, check the solenoid in the procedure below.

|         |                       |                         |      |
|---------|-----------------------|-------------------------|------|
| Voltage | Factory specification | Terminal 1 – Terminal 2 | 12 V |
|---------|-----------------------|-------------------------|------|

**(Reference)**


1. Measure the resistance between the terminals of the connector (solenoid side).
2. If the measurement is not in the factory specification, the solenoid is defective. Then replace the solenoid with a new one.
3. If the measurement is in the factory specification, the solenoid is correct electrically. Then check the movement of the solenoid.
4. Remove the solenoid (1) from the engine.
5. Apply the voltage of 12 V to the solenoid.
6. If the rod of the solenoid does not move smoothly, the solenoid is defective. Then replace the solenoid with a new one.
7. If the rod of the solenoid moves smoothly, the solenoid is correct.

|            |                       |                         |          |
|------------|-----------------------|-------------------------|----------|
| Resistance | Factory specification | Terminal 1 – Terminal 2 | 2 to 4 Ω |
|------------|-----------------------|-------------------------|----------|

- (1) Solenoid
- (2) Connector (Harness Side)
- (3) Terminal 2 (-)
- (4) Terminal 1 (+)

- (A) Key Switch OFF Position
- (B) Key Switch ON Position

M00000003ENS0056US1




**Glow Plug Harness**

1. Disconnect the wiring (1) of the glow plug.
  2. Check the condition of the wiring.
  3. If the wiring is defective, replace it with a new one.
  4. Turn the key switch to the ACC position.
  5. Measure the voltage between the wiring (1) and chassis.
  6. If the measurement is not in the factory specification, the ECU is defective. Then replace the ECU with a new one.
  7. If the measurement is in the factory specification, the ECU is correct.
- In this case, the glow plugs are defective.  
Check each glow plug, and replace the defective glow plug with a new one.

|         |                       |                    |      |
|---------|-----------------------|--------------------|------|
| Voltage | Factory specification | Terminal – Chassis | 12 V |
|---------|-----------------------|--------------------|------|

(1) Wiring of Glow Plug

M00000003ENS0057US1



**Alternator**


1. Disconnect the terminal L (2) of the alternator (2P).
  2. Check the condition of the harness.
  3. If the harness is defective, replace it with a new one.
  4. Measure the resistance between the terminal L (2) of the connector (harness side) and chassis.
  5. If the measurement is not in the factory specification, the ECU is defective. Then replace the ECU with a new one.
  6. If the measurement is in the factory specification, the ECU is correct.
- In this case, the alternator is defective. Then replace it with a new one.

|            |                       |                      |          |
|------------|-----------------------|----------------------|----------|
| Resistance | Factory specification | Terminal L - Chassis | Infinity |
|------------|-----------------------|----------------------|----------|

(1) Alternator

(2) Terminal L (Harness Side)

M00000003ENS0058US1



**Speed Switch**


1. Disconnect the connector of the speed switch.
2. Check the condition of the harness.
3. If the harness is defective, replace it with a new one.
4. Measure the resistance between the terminals of the speed switch when the speed switch turn on or off.
5. If the measurements are in the factory specifications, the ECU is defective. Then replace the ECU with a new one.
6. If the measurements are not in the factory specifications, the speed switch is defective. Then replace the speed switch with a new one.

|            |                       |     |          |
|------------|-----------------------|-----|----------|
| Resistance | Factory specification | ON  | 0 Ω      |
|            |                       | OFF | Infinity |

(1) Speed Switch (Switch Side)

(A) Single Pole, Single Throw  
(B) Single Pole, Double Throw

M00000003ENS0059US1



**Emergency Stop Switch**


1. Disconnect the connector of the emergency stop switch.
2. Check the condition of the harness.
3. If the harness is defective, replace it with a new one.
4. Measure the resistance between the terminals of the emergency stop switch when the emergency stop switch turn on or off.
5. If the measurements are in the factory specifications, the ECU is defective. Then replace the ECU with a new one.
6. If the measurements are not in the factory specifications, the emergency stop switch is defective. Then replace the emergency stop switch with a new one.

|            |                       |            |          |
|------------|-----------------------|------------|----------|
| Resistance | Factory specification | <b>ON</b>  | 0 Ω      |
|            |                       | <b>OFF</b> | Infinity |

(1) Emergency Stop Switch (Switch Side)

**(A) Single Pole, Single Throw**  
**(B) Single Pole, Double Throw**

M00000003ENS0060US1



**Slow Down Switch**


1. Disconnect the connector of the slow down switch.
2. Check the condition of the harness.
3. If the harness is defective, replace it with a new one.
4. Measure the resistance between the terminals of the slow down switch when the slow down switch turn on or off.
5. If the measurements are in the factory specifications, the ECU is defective. Then replace the ECU with a new one.
6. If the measurements are not in the factory specifications, the slow down switch is defective. Then replace the slow down switch with a new one.

|            |                       |            |          |
|------------|-----------------------|------------|----------|
| Resistance | Factory specification | <b>ON</b>  | 0 Ω      |
|            |                       | <b>OFF</b> | Infinity |

(1) Slow Down Switch (Switch Side)

**(A) Single Pole, Single Throw**  
**(B) Single Pole, Double Throw**

M00000003ENS0061US1



**Battery**

1. Measure the voltage of the battery (1).
2. If the measurement is less than the factory specification, charge the battery or replace the battery with a new one.
3. If the measurement is in the factory specification, the ECU is defective. Then replace the ECU with a new one.


|         |                       |                            |      |
|---------|-----------------------|----------------------------|------|
| Voltage | Factory specification | + terminal –<br>– terminal | 12 V |
|---------|-----------------------|----------------------------|------|

(1) Battery

M00000003ENS0062US1

## [2] DISASSEMBLING AND ASSEMBLING

### (1) Draining Engine Oil and Coolant



#### Draining Engine Oil

1. Start and increase the temperature of the engine for approximately 5 minutes.
2. Put an oil pan below the engine.
3. Remove the drain plug (1) to drain the oil.
4. After you drain, tighten the drain plug.

#### **(When reassembling)**

- Fill the engine oil until the upper line on the dipstick (2).


#### ■ IMPORTANT

- **Do not mix different types of oil.**
- **Use the correct SAE Engine Oil by reference to the ambient temperature.**

(1) Drain Plug

(2) Dipstick

M0000003ENS0063US1



#### Draining Coolant




#### CAUTION

- **Do not remove the radiator cap while you operate or immediately after you stop the engine. If not, hot water can flow out from the radiator. Only open the cap after more than 10 minutes for the temperature of the radiator to decrease.**




1. Prepare a bucket.
2. Open the drain cock (1) to drain the coolant.
3. After you drain, close the drain cock.

(1) Drain Cock

M0000003ENS0064US1



## (2) External Components



### Air Cleaner, Muffler and Others

1. Remove the air cleaner and muffler.
2. Remove the fan (1), fan belt (4), alternator (2) and starter (3).

#### **(When reassembling)**

- Check for cracks on the belt surface.

#### ■ **IMPORTANT**

- **After you assemble the fan belt, adjust the fan belt tension.**
- **Do not put the fan in the incorrect direction.**

- |                |              |
|----------------|--------------|
| (1) Fan        | (3) Starter  |
| (2) Alternator | (4) Fan Belt |

M0000003ENS0065US1

### Turbocharger (Equipped with Turbocharger Model)

#### ⚠ **CAUTION**

- **While the engine operates or just after it stops, do not touch the hot turbocharger.**

#### ■ **NOTE**

- **When you remove or install the turbocharger assembly, do not let dust, dirt and other unwanted materials in the oil pipes.**
- **After you replace the turbocharger assembly, fill clean engine oil through the oil filter port of the turbocharger.**
- **Before you start the engine, make sure that the air cleaner is in the correct position.**

1. Remove the inlet hose (1).
2. Remove the joint bolt (2), (7) and remove the oil pipe 1 (8).
3. Remove the bolts 1 (3) and release the clamp (5).
4. Remove the oil pipe 2 (4) and pipe 3 (6).
5. Remove the bolts 2 (10).
6. Remove the turbocharger assembly (9).

#### **(When reassembling)**

- Fill clean engine oil through the oil filter port of the turbocharger.
- Replace the gaskets with new ones.
- Do not let dust, dirt and other unwanted materials in the oil pipes.


#### ■ **NOTE**

- **Put tape or cover on all openings to prevent damage in the oil holes in the turbocharger by unwanted materials.**

- |                |                           |
|----------------|---------------------------|
| (1) Inlet Hose | (6) Oil Pipe 3            |
| (2) Joint Bolt | (7) Joint Bolt            |
| (3) Bolt 1     | (8) Oil Pipe 1            |
| (4) Oil Pipe 2 | (9) Turbocharger Assembly |
| (5) Clamp      | (10) Bolt 2               |

M0000003ENS0066US1

### (3) Cylinder Head and Valves




#### Cylinder Head Cover

1. Remove the lead (4).
2. Remove the breather hose (1).
3. Remove the head cover screws (3).
4. Remove the cylinder head cover (2).

#### (When reassembling)



- Make sure that the cylinder head cover gasket (5) is not defective.

|                   |                           |  |
|-------------------|---------------------------|--|
| Tightening torque | Cylinder head cover screw | 6.87 to 11.2 N·m<br>0.700 to 1.15 kgf·m<br>5.07 to 8.31 lbf·ft |
|-------------------|---------------------------|--|



- |                         |                                |
|-------------------------|--------------------------------|
| (1) Breather Hose       | (5) Cylinder Head Cover Gasket |
| (2) Cylinder Head Cover | (6) Breather Valve             |
| (3) Head Cover Screw    | (7) Plate                      |
| (4) Lead                |                                |

M00000003ENS0067US1



#### Injection Pipes

1. Loosen the screws on the pipe clamps (2).
2. Remove the injection pipes (1).

#### (When reassembling)


- Blow out dust in the pipes.

|                   |                              |  |   |
|-------------------|------------------------------|--|---|
| Tightening torque | Injection pipe retaining nut | D1503-M,<br>D1703-M,<br>D1803-M,<br>V2003-M,<br>V2203-M,<br>V2403-M,<br>V2403-M-T,<br>D1703-M-BG,<br>V2003-M-BG,<br>V2003-M-T-BG,<br>V2203-M-BG,<br>V2403-M-BG | 25 to 34 N·m<br>2.5 to 3.5 kgf·m<br>18 to 25 lbf·ft |
|                   |                              | D1803-M-DI,<br>V2403-M-DI,<br>V2403-M-DI-T   | 15 to 24 N·m<br>1.5 to 2.5 kgf·m<br>11 to 18 lbf·ft |

(1) Injection Pipe

(2) Pipe Clamp

M00000003ENS0068US1



**Nozzle Holder Assembly and Glow Plug**

[D1503-M, D1703-M, D1803-M, V2003-M, V2203-M, V2403-M, V2403-M-T, D1703-M-BG, V2003-M-BG, V2003-M-T-BG, V2203-M-BG, V2403-M-BG]

1. Remove the overflow pipe assembly (3).
2. Remove the nozzle holder assemblies (4) with a 21 mm-deep socket wrench.
3. Remove the copper gasket and heat seal (5).
4. Remove the glow plugs (2).


**(When reassembling)**

- Replace the copper gasket and heat seal with new ones.

|                   |   |   |
|-------------------|---|---|
| Tightening torque | Nozzle holder assembly                  | 49 to 68 N·m<br>5.0 to 7.0 kgf·m<br>37 to 50 lbf·ft |
|                   | Retaining nut of overflow pipe assembly | 20 to 24 N·m<br>2.0 to 2.5 kgf·m<br>15 to 18 lbf·ft |
|                   | Glow plug                               | 20 to 24 N·m<br>2.0 to 2.5 kgf·m<br>15 to 18 lbf·ft |

- |                            |                            |
|----------------------------|----------------------------|
| (1) Lead                   | (4) Nozzle Holder Assembly |
| (2) Glow Plug              | (5) Heat Seal              |
| (3) Overflow Pipe Assembly |                            |

M00000003ENS0069US1



**Nozzle Holder Assembly and Glow Plug**

[D1803-M-DI, V2403-M-DI, V2403-M-DI-T]

1. Remove the overflow pipe assembly.
2. Remove the nozzle holder assemblies (2).
3. Remove the glow plugs (1).


**(When reassembling)**

- Replace the copper gasket with a new one.

|                   |   |   |
|-------------------|---|---|
| Tightening torque | Nozzle holder clamp screw                 | 26 to 29 N·m<br>2.6 to 3.0 kgf·m<br>19 to 21 lbf·ft           |
|                   | Retaining screw of overflow pipe assembly | 9.81 to 11.2 N·m<br>1.00 to 1.15 kgf·m<br>7.24 to 8.31 lbf·ft |
|                   | Glow plug                                 | 20 to 24 N·m<br>2.0 to 2.5 kgf·m<br>15 to 18 lbf·ft           |

- |               |                            |
|---------------|----------------------------|
| (1) Glow Plug | (2) Nozzle Holder Assembly |
|---------------|----------------------------|

M00000003ENS0070US1



**Service Procedure of Nozzle Heat Seal**

[D1503-M, D1703-M, D1803-M, V2003-M, V2203-M, V2403-M, V2403-M-T, D1703-M-BG, V2003-M-BG, V2003-M-T-BG, V2203-M-BG, V2403-M-BG]

■ **IMPORTANT**

- Use a plus (phillips head) screwdriver (1) that has a diameter larger than the heat seal hole (Approximately 6 mm (1/4 in.)).


1. Put the screwdriver (1) lightly into the heat seal hole.
2. Turn screwdriver 3 or 4 times each way.
3. While you turn the screwdriver, slowly pull the heat seal (4) out together with the injection nozzle gasket (3).
4. If the heat seal falls, do the above procedure again.

**(When reassembling)**

- Change the heat seal and injection nozzle gasket when you remove the injection nozzle to clean or for servicing.

- |                      |                             |
|----------------------|-----------------------------|
| (1) Plus Screwdriver | (3) Injection Nozzle Gasket |
| (2) Injection Nozzle | (4) Heat Seal               |

M00000003ENS0071US1



**Rocker Arm and Push Rod**

1. Remove the screws of the rocker arm bracket.
2. Remove the rocker arm assembly (1).
3. Remove the push rods (2).

**(When reassembling)**

- When you put the push rods (2) on the tappets (3), make sure that their ends are correctly engaged with the grooves.


■ **IMPORTANT**





- **After you install the rocker arm, adjust the valve clearance.**

|                   |                          |   |
|-------------------|--------------------------|---|
| Tightening torque | Rocker arm bracket screw | 24 to 27 N·m<br>2.4 to 2.8 kgf·m<br>18 to 20 lbf·ft |
|-------------------|--------------------------|---|

- |                         |            |
|-------------------------|------------|
| (1) Rocker Arm Assembly | (3) Tappet |
| (2) Push Rod            |            |

M00000003ENS0072US1





**Cylinder Head**

1. Loosen the pipe clamp (2) and remove the water return pipe (1).
2. Remove the cylinder head screw in the sequence of **(n or r)** to **(a)**.
3. Lift up the cylinder head (3) to remove.
4. Remove the cylinder head gasket (4).

**(When reassembling)**

- Replace the cylinder head gasket (4) with a new one.
- Apply sufficient oil and tighten the cylinder head screws.
- Tighten the cylinder head screws in a diagonal sequence. Start from the center in the sequence of **(a)** to **(n or r)**.
- Tighten them equally, or the shape of the head changes after some time.

|                   |                     |   |
|-------------------|---------------------|---|
| Tightening torque | Cylinder head screw | 93.2 to 98.0 N·m<br>9.50 to 10.0 kgf·m<br>68.8 to 72.3 lbf·ft |
|-------------------|---------------------|---|

**IMPORTANT**

- Before you replace the cylinder head gasket (4), record the mark (5) on the cylinder head gasket of the engine. Then replace a cylinder head gasket with same mark.



| Gasket Mark and Code Number | Model       |                              |             |   |
|-----------------------------|-------------|------------------------------|-------------|---|
|                             | D1503-M     | D1703-M, D1803-M, D1803-M-DI | V2003-M     | V2203-M, V2403-M, V2403-M-T, V2403-M-DI, V2403-M-DI-T |
| 15                          | 1G720-03600 | 1G750-03600                  | 1G464-03600 | 1G790-03600   |
| 20                          | 1G720-03310 | 1G750-03310                  | 1G464-03310 | 1G790-03310   |
| 25                          | 1G720-03610 | 1G750-03610                  | 1G464-03610 | 1G790-03610   |
| 30                          | 1G720-03620 | 1G750-03620                  | 1G464-03620 | 1G790-03620   |
| 35                          | 1G720-03630 | 1G750-03630                  | 1G464-03630 | 1G790-03630   |

| Gasket Mark and Code Number | Model       |             |              |                        |
|-----------------------------|-------------|-------------|--------------|------------------------|
|                             | D1703-M-BG  | V2003-M-BG  | V2003-M-T-BG | V2203-M-BG, V2403-M-BG |
| 15                          | 1G750-03600 | 1G464-03600 | 1G770-03600  | 1G790-03600            |
| 20                          | 1G750-03310 | 1G464-03310 | 1G770-03310  | 1G790-03310            |
| 25                          | 1G750-03610 | 1G464-03610 | 1G770-03610  | 1G790-03610            |
| 30                          | 1G750-03620 | 1G464-03620 | 1G770-03620  | 1G790-03620            |
| 35                          | 1G750-03630 | 1G464-03630 | 1G770-03630  | 1G790-03630            |

- |  |  |
|--|--|
| <ul style="list-style-type: none"> <li>(1) Water Return Pipe</li> <li>(2) Pipe Clamp</li> <li>(3) Cylinder Head</li> <li>(4) Cylinder Head Gasket</li> <li>(5) Mark</li> </ul> | <ul style="list-style-type: none"> <li><b>(n or r) to (a) : To Loosen</b></li> <li><b>(a) to (n or r) : To Tighten</b></li> <li><b>(A) Gear Case Side</b></li> <li><b>(B) Flywheel Side</b></li> </ul> |
|--|--|

**(To be continued)**

(Continued)



■ **IMPORTANT**

- After you replace an item below, you have to select a cylinder head gasket.
  - Piston
  - Piston pin
  - Small end bushing
  - Connecting rod
  - Crankpin bearings

**To select the cylinder head gasket**

1. Measure the protrusion or recess of the piston head from the level of crankcase cylinder face at 4 points per each piston with a dial gauge.
2. Get the average of the measurements.
3. Use the table below to select an applicable cylinder head gasket.


| Gasket Dimension (Number) | Piston Protrusion   |   |
|---------------------------|---|---|
|                           | D1503-M, D1703-M, D1803-M, V2003-M, V2203-M, V2403-M, V2403-M-T, D1703-M-BG, V2003-M-BG, V2003-M-T-BG, V2203-M-BG, V2403-M-BG | D1803-M-DI, V2403-M-DI, V2403-M-DI-T      |
| 15                        | 0.500 to 0.540 mm<br>0.0197 to 0.0212 in.   | 0.475 to 0.525 mm<br>0.0187 to 0.0206 in. |
| 20                        | 0.550 to 0.590 mm<br>0.0217 to 0.0232 in.   | 0.525 to 0.575 mm<br>0.0206 to 0.0227 in. |
| 25                        | 0.600 to 0.640 mm<br>0.0237 to 0.0251 in.   | 0.575 to 0.625 mm<br>0.0227 to 0.0246 in. |
| 30                        | 0.650 to 0.690 mm<br>0.0256 to 0.0271 in.   | 0.625 to 0.675 mm<br>0.0246 to 0.0266 in. |
| 35                        | 0.700 to 0.740 mm<br>0.0276 to 0.0291 in.   | 0.675 to 0.725 mm<br>0.0266 to 0.0285 in. |

(6) Points of Measurement

[A] D1503-M, D1703-M, D1803-M, V2003-M, V2203-M, V2403-M, V2403-M-T, D1703-M-BG, V2003-M-BG, V2003-M-T-BG, V2203-M-BG, V2403-M-BG

[B] D1803-M-DI, V2403-M-DI, V2403-M-DI-T

M00000003ENS0073US1



**Tappets**

1. Remove the tappets (1) from the crankcase.

**(When reassembling)**


- Before you install the tappets, apply a thin layer of engine oil around them.
- Check the contact between tappets and cams that it turns correctly. If it is damaged, replace the tappets.

■ **IMPORTANT**

- Do not change the combination of tappet and tappet guide.

(1) Tappet

M00000003ENS0074US1



### Valves

1. Remove the valve caps (3).
2. Push the valve spring retainer with the valve spring replacer (1) and remove the valve spring collets (4).
3. Remove the valve spring retainer (5) and valve spring (6).
4. Remove the valve (7).

#### **(When reassembling)**


- Clean the valve stem and the valve guide hole, and apply engine oil sufficiently.
- After you install the valve spring collets (4), lightly tap the stem tip to attach it correctly with the plastic hammer.

#### **■ IMPORTANT**

- **Do not change the combination of valve and valve guide.**

- |                           |                           |
|---------------------------|---------------------------|
| (1) Valve Spring Replacer | (5) Valve Spring Retainer |
| (2) Valve Stem Seal       | (6) Valve Spring          |
| (3) Valve Cap             | (7) Valve                 |
| (4) Valve Spring Collet   |                           |

M00000003ENS0075US1



### Thermostat Assembly


1. Remove the thermostat cover mounting screws, and remove the thermostat cover (1).
2. Remove the thermostat assembly (3).

#### **(When reassembling)**

- Replace the thermostat cover gasket (2) with a new one.
- Apply a liquid gasket (Three Bond 1215 or equivalent) to the water flange 1 (4) and flange 2 (5).

- |                             |                    |
|-----------------------------|--------------------|
| (1) Thermostat Cover        | (4) Water Flange 1 |
| (2) Thermostat Cover Gasket | (5) Water Flange 2 |
| (3) Thermostat Assembly     |                    |

M00000003ENS0076US1



### Water Pump Assembly (If Necessary)

1. Remove the water pump assembly (1) from the gear case.






#### **(When reassembling)**

- Replace the gasket (2) with a new one.

- |                         |            |
|-------------------------|------------|
| (1) Water Pump Assembly | (2) Gasket |
|-------------------------|------------|

M00000003ENS0077US1

### (4) Gear Case and Timing Gears



#### Injection Pump (for Non Turbocharger Model)

##### ■ IMPORTANT

- Before you remove the injection pump assembly (2), remove the solenoid (4), hi-idling body (1), engine stop lever (3) and solenoid guide (6).

1. Remove the solenoid (4) and hi-idling body (1).
2. Remove the engine stop lever (3) and solenoid guide (6).
3. Remove the injection pump assembly (2).




##### (When reassembling)

- Before you attach the solenoid (4), hi-idling body (1) and solenoid guide (6), install the injection pump first into position.
- Replace the hi-idling body gasket (5) with a new one.
- Before you attach the stop lever (3) to the gear case, install the solenoid guide (6) first into position. Then attach the stop lever and monitor how it operates.
- When you install the solenoid (4), keep the O-ring in position.
- Put the push rod of the solenoid into the hole at the center of the solenoid guide (6).

|                   |                |   |
|-------------------|----------------|---|
| Tightening torque | Hi-idling body | 45 to 49 N·m<br>4.5 to 5.0 kgf·m<br>33 to 36 lbf·ft |
|-------------------|----------------|---|

- |                             |                           |
|-----------------------------|---------------------------|
| (1) Hi-idling Body          | (4) Solenoid              |
| (2) Injection Pump Assembly | (5) Hi-idling Body Gasket |
| (3) Stop Lever              | (6) Solenoid Guide        |

M00000003ENS0078US1



### Injection Pump (for Turbocharger Model)

#### ■ IMPORTANT

- Before you remove the injection pump assembly (1), remove the boost compensator assembly (2), hi-idling body (4), solenoid (3) and solenoid guide (5).

1. Remove the boost compensator assembly (2).
2. Remove the hi-idling body (4).
3. Remove the solenoid (3).
4. Remove the solenoid guide (5).
5. Remove the injection pump assembly (1).

#### (When reassembling)

- Before you attach the boost compensator assembly (2), hi-idling body (4), solenoid (3) and solenoid guide (5), install the injection pump first into position.
- Replace the hi-idling body gasket with a new one.
- Before you attach the boost compensator assembly (2) to the gear case, make sure that the solenoid guide (5) is at the initial position.
- When you install the solenoid (3), keep the O-ring in position.
- Put the push rod of the solenoid into the hole at the center of the solenoid guide (5).

#### ■ IMPORTANT




- If you replace new boost compensator, it is necessary to adjust it.

Get the adjustment procedure from KUBOTA.

|                   |                |   |
|-------------------|----------------|---|
| Tightening torque | Hi-idling body | 45 to 49 N·m<br>4.5 to 5.0 kgf·m<br>33 to 36 lbf·ft |
|-------------------|----------------|---|

- (1) Injection Pump Assembly                      (4) Hi-idling Body  
(2) Boost Compensator Assembly              (5) Solenoid Guide  
(3) Solenoid

M0000003ENS0079US1



### Injection Pump (for Smoke Reduction Device)

#### ■ IMPORTANT

- Before you remove the injection pump assembly (1), remove the smoke reduction device (2), hi-idling body (4), solenoid (3) and solenoid guide (5).

1. Remove the smoke reduction device (2).
2. Remove the hi-idling body (4).
3. Remove the solenoid (3).
4. Remove the solenoid guide (5).
5. Remove the injection pump assembly (1).

#### (When reassembling)

- Before you install the smoke reduction device (2), hi-idling body (4), solenoid (3) and solenoid guide (5), install the injection pump first into position.
- Replace the hi-idling body gasket with a new one.
- Before you attach the smoke reduction device (2) to the gear case, make sure that the solenoid guide (5) is at the initial position.
- When you install the solenoid (3), keep the O-ring in position.
- Put the push rod of the solenoid into the hole at the center of the solenoid guide (5).

#### ■ IMPORTANT






- If you replace new smoke reduction device, it is necessary to adjust it.

**Get the adjustment procedure from KUBOTA.**

|                   |                |                  |
|-------------------|----------------|------------------|
| Tightening torque | Hi-idling body | 45 to 49 N·m     |
|                   |                | 4.5 to 5.0 kgf·m |
|                   |                | 33 to 36 lbf·ft  |

- |                             |                    |
|-----------------------------|--------------------|
| (1) Injection Pump Assembly | (4) Hi-idling Body |
| (2) Smoke Reduction Device  | (5) Solenoid Guide |
| (3) Solenoid                |                    |


M0000003ENS0080US1



## Governor Springs and Speed Control Plate

### NOTE






- Specified tool (1)  
1.2 mm (0.047 in.) diameter hard wire with its end hooked,  
total length 200 mm (7.87 in.).  
The point of the wire is bent like a hook to hang the  
governor springs.
1. Remove the injection pump cover.
  2. Remove the mounting nuts and bolts of the speed control plate (6).
  3. Use the specific tool (1) to release the large governor spring (3) from the fork lever (2).
  4. Use the specific tool (1) to release the small governor spring (4) from the fork lever (2).
  5. Set the speed control lever (5) as you can see in the figure.
  6. Remove the speed control plate (6). Do not let the large (3) and small (4) governor springs come off this plate and fall in the gear case.



- |                           |                           |
|---------------------------|---------------------------|
| (1) Specific Tool         | (4) Small Governor Spring |
| (2) Fork Lever            | (5) Speed Control Lever   |
| (3) Large Governor Spring | (6) Speed Control Plate   |

**(To be continued)**

(Continued)





**(When reassembling)**

- Set the end with less clearance (color painted (8) when it is new) of small governor spring (4) to the governor lever (7).
- Set the large governor spring (3) to the governor lever (7).
- Put the specific tool (1) from the injection pump cover side to catch the large governor spring (3). Keep this spring in an extended position and put the speed control plate (6) in its specified position.
- Use the specific tool (1), set the small governor spring (4) on the fork lever (2).
- Use the specific tool (1), set the large governor spring (3) on the fork lever (2).




■ **NOTE**

- **Do not stretch the small governor spring (4) too much because it can cause permanent deformation.**
- **Make sure that the 2 governor springs (3), (4) are tight on the fork lever (2).**
- **Tighten the 2 bolts and 2 nuts on the speed control plate (6).**
- **After you assemble the governor springs, make sure that the speed control lever (5) is at the low-idle position.**
- **After you move the speed control lever (5) to the maximum speed position, make sure that it goes back to the high-idle position.**
- **Attach the injection pump cover in position.**



- |                           |                      |
|---------------------------|----------------------|
| (1) Specific Tool         | (7) Governor Lever   |
| (2) Fork Lever            | (8) Color Painted    |
| (3) Large Governor Spring | (9) 3 mm (0.1 in.)   |
| (4) Small Governor Spring | (10) 2 mm (0.08 in.) |
| (5) Speed Control Lever   | (a) Previous         |
| (6) Speed Control Plate   | (b) Modified         |

M0000003ENS0081US1



**Fan Drive Pulley**

1. Lock the flywheel with the flywheel stopper.
2. Remove the mounting nut (1) of the fan drive pulley with a 46 mm (1.8 in.) deep socket wrench (3).
3. Remove the fan drive pulley (2) with a gear puller (4).
4. Remove the feather key.






**(When reassembling)**

- Apply grease to the splines of coupling.

|                   |                                  |   |
|-------------------|----------------------------------|---|
| Tightening torque | Mounting nut of fan drive pulley | 138 to 156 N·m<br>14.0 to 16.0 kgf·m<br>102 to 115 lbf·ft |
|-------------------|----------------------------------|---|

- |                      |  |
|----------------------|--|
| (1) Nut              | (3) 46 mm (1.8 in.) Deep Socket Wrench |
| (2) Fan Drive Pulley | (4) Gear Puller                        |

M00000003ENS0082US1



**Idle Gear 2 and Hydraulic Pump Base Assembly  
(for Side PTO Model)**

1. Remove the hour meter gear case (if attached).
2. Remove the gear case cover (1).
3. Remove the hydraulic pump base assembly (2).
4. Remove the idle gear 2 stopper (3).
5. Remove the idle gear 2 (4) with a puller (5).
6. Remove the idle gear 2 shaft (7).


**(When reassembling)**

- Replace the washer (6) and gear case cover gasket with new ones.
- Replace the hour meter gear case gasket with a new one.

|                   |                                  |   |
|-------------------|----------------------------------|---|
| Tightening torque | Set screw of idle gear 2 shaft   | 24 to 27 N·m<br>2.4 to 2.8 kgf·m<br>18 to 20 lbf·ft |
|                   | Set screw of idle gear 2 stopper | 49 to 55 N·m<br>5.0 to 5.7 kgf·m<br>37 to 41 lbf·ft |

- |                                  |                                      |
|----------------------------------|--------------------------------------|
| (1) Gear Case Cover              | (6) Washer                           |
| (2) Hydraulic Pump Base Assembly | (7) Idle Gear 2 Shaft                |
| (3) Idle Gear 2 Stopper          | (8) Set Screw of Idle Gear 2 Stopper |
| (4) Idle Gear 2                  | (9) Set Screw of Idle Gear 2 Shaft   |
| (5) Puller                       |                                      |

M00000003ENS0083US1

**Gear Case (for Side PTO Model)**

1. Remove the gear case (1).
2. Remove the O-rings (2).


**(When reassembling)**

- Replace the gear case gasket and O-rings.
- Make sure that there are 4 O-rings (2) in the gear case (1).
- Apply a thin layer of engine oil to the oil seal. Then install the oil seal not to come off the lip.
- Before you install the gear case gasket, apply an adhesive that does not become dry.

(1) Gear Case

(2) O-rings

M00000003ENS0084US1

**Gear Case**

1. Remove the hour meter gear case (if attached).
2. Remove the gear case (1).
3. Remove the O-rings (2).

**(When reassembling)**


- Replace the gear case gasket and O-rings (2).
- Replace the hour meter gear case gasket with a new one.
- Make sure that there are 4 O-rings (2) in the gear case (1).
- Apply a thin layer of engine oil to the oil seal. Then install the oil seal not to come off the lip.
- Before you install the gear case gasket, apply an adhesive that does not become dry.

(1) Gear Case

(3) Oil Seal

(2) O-ring

M00000003ENS0085US1

**Crankshaft Oil Slinger**

1. Remove the crankshaft collar (3).
2. Remove the O-ring (2).
3. Remove the crankshaft oil slinger (1).

**(When reassembling)**


- Attach the crankshaft collar (3) after you install the gear case to the cylinder body.

(1) Crankshaft Oil Slinger

(3) Crankshaft Collar

(2) O-ring

M00000003ENS0086US1

**Idle Gear**

1. Remove the external snap ring.
2. Remove the idle gear collar.
3. Remove the idle gear (2).

**(When reassembling)**

- Align each gear with its mark.
  - Idle gear (2) and crank gear (4)
  - Idle gear (2) and cam gear (3)
  - Idle gear (2) and injection pump gear (1)

(1) Injection Pump Gear


(4) Crank Gear

(2) Idle Gear

(5) Oil Pump Drive Gear

(3) Cam Gear

M00000003ENS0087US1



**Idle Gear (for Balancer Model)**


1. Remove the external snap ring.
2. Remove the idle gear collar.
3. Remove the idle gear (2).

**(When reassembling)**

- Align each gear with its mark.
  - Cam gear (3) and balancer gear (4)
  - Idle gear (2) and crank gear (6)
  - Cam gear (3) and idle gear (2)
  - Idle gear (2) and injection pump gear (1)
  - Idle gear (2) and balancer gear (7)

- |                         |                         |
|-------------------------|-------------------------|
| (1) Injection Pump Gear | (5) Oil Pump Drive Gear |
| (2) Idle Gear           | (6) Crank Gear          |
| (3) Cam Gear            | (7) Balancer Gear       |
| (4) Balancer Gear       |                         |

M00000003ENS0088US1



**Camshaft**

1. Remove the camshaft set screws (1) and pull out the camshaft (2).


**(When reassembling)**

- When you install the idle gear, align the marks on the gears.

|                   |                    |   |
|-------------------|--------------------|---|
| Tightening torque | Camshaft set screw | 24 to 27 N·m<br>2.4 to 2.8 kgf·m<br>18 to 20 lbf·ft |
|-------------------|--------------------|---|

- |                        |              |
|------------------------|--------------|
| (1) Camshaft Set Screw | (2) Camshaft |
|------------------------|--------------|

M00000003ENS0089US1



**Camshaft and Balancer Shaft (for Balancer Model)**

1. Remove the camshaft set screws and pull out the camshaft (1).
2. Remove the set bolts of the balancer shaft 1 and pull out the balancer shaft 1 (2).
3. Remove the set bolts of the balancer shaft 2 and pull out the balancer shaft 2 (3).


**(When reassembling)**





- When you install the balancer shafts (2) and (3), put the first and fourth cylinders piston at the top dead center in compression. Then align all the marks on each gear to assemble the timing gears. Set the idle gear last.

|                   |                                  |   |
|-------------------|----------------------------------|---|
| Tightening torque | Camshaft set screw               | 24 to 27 N·m<br>2.4 to 2.8 kgf·m<br>18 to 20 lbf·ft |
|                   | Set bolt of the balancer shaft 1 | 24 to 27 N·m<br>2.4 to 2.8 kgf·m<br>18 to 20 lbf·ft |
|                   | Set bolt of the balancer shaft 2 | 24 to 27 N·m<br>2.4 to 2.8 kgf·m<br>18 to 20 lbf·ft |

- |                      |                      |
|----------------------|----------------------|
| (1) Camshaft         | (3) Balancer Shaft 2 |
| (2) Balancer Shaft 1 |                      |

M00000003ENS0090US1





### Fuel Camshaft and Fork Lever Assembly

1. Remove the fuel feed pump.
2. Remove the fuel camshaft stopper (1).
3. Remove the 3 mounting screws (2) of the fork lever holder.
4. Pull out the fuel camshaft assembly (5), (6) and fork lever assembly (3), (4), (7) at the same time.

#### **(When reassembling)**

- After installation, make sure that the fork levers (3) and (4) are attached to the fork lever shaft. Make sure also that they can turn smoothly in the holder (7).

- |   |                         |
|---|-------------------------|
| (1) Fuel Camshaft Stopper               | (4) Fork Lever 2        |
| (2) Mounting Screw of Fork Lever Holder | (5) Injection Pump Gear |
| (3) Fork Lever 1                        | (6) Fuel Camshaft       |
|   | (7) Fork Lever Holder   |

M00000003ENS0091US1

### Oil Pump

1. Remove the nut.
2. Pull out the oil pump drive gear (2) with a gear puller (1).
3. Remove the 4 mounting screws of the oil pump. Remove the oil pump (3).

- |                         |              |
|-------------------------|--------------|
| (1) Gear Puller         | (3) Oil Pump |
| (2) Oil Pump Drive Gear |              |

M00000003ENS0092US1



### Crank Gear

1. Pull out the crank gear (2) with a puller (1).
2. Remove the feather key.

- |            |                |
|------------|----------------|
| (1) Puller | (2) Crank Gear |
|------------|----------------|

M00000003ENS0093US1

## (5) Piston and Connecting Rod



### Oil Pan and Oil Strainer

1. Remove the mounting screws of the oil pan.
2. Tap lightly on the rim of the pan with a wooden hammer to remove the oil pan (3).
3. Remove the oil pan gasket (2).
4. Remove the oil strainer (1) and O-ring (4).





#### **(When reassembling)**

- After you clean the oil strainer (1), make sure that the filter mesh is clean and install it.
- Visually check the O-ring (4), apply engine oil and install it.
- Install the O-ring (4) to the oil strainer (1) certainly.
- Replace the oil pan gasket (2) with a new one.
- Tighten the mounting screws of the oil pan in diagonal sequence from the center to tighten equally.

- (1) Oil Strainer  
(2) Oil Pan Gasket

- (3) Oil Pan  
(4) O-ring

M00000003ENS0094US1



### Pistons

[D1503-M, D1703-M, D1803-M, V2003-M, V2203-M, V2403-M, V2403-M-T, D1703-M-BG, V2003-M-BG, V2003-M-T-BG, V2203-M-BG, V2403-M-BG]

1. Fully clean the carbon (1) in the cylinders.
2. Remove the connecting rod cap (3).
3. Turn the flywheel and move the piston to the top dead center.
4. Lightly tap the piston from the bottom of the crankcase with the grip of a hammer to pull the piston out.
5. Pull out the other piston in the same procedure as above.

#### (When reassembling)

- Before you install the piston into the cylinder, apply sufficient engine oil to the piston.
- When you install the piston into the cylinder, point the mark on the connecting rod to the injection pump.



#### ■ IMPORTANT

- Do not change the combination of cylinder and piston. Align the position of each piston by the its mark. For example, mark "1" on the No. 1 piston.
- Set the piston rings with their gaps at 0.79 rad (45 °) from the direction of the piston pin (see the figure).
- Install the pistons with a piston ring compressor (6) carefully.
- When you install the piston in position, do not give a damage to the layer of molybdenum disulfide on the piston skirt. This layer can decrease the clearance with the cylinder liner. Immediately after you press-fit the piston pin, the piston is hot and the layer comes off easily. Only put in the piston after its temperature decreases.

- |                          |                                   |
|--------------------------|-----------------------------------|
| (1) Carbon               | (4) Connecting Rod                |
| (2) Connecting Rod Screw | (5) Layer of Molybdenum Disulfide |
| (3) Connecting Rod Cap   |                                   |

(To be continued)

(Continued)



|                   |                                 |   |
|-------------------|---------------------------------|---|
| Tightening torque | Connecting rod screw (Old type) | 45 to 49 N·m<br>4.5 to 5.0 kgf·m<br>33 to 36 lbf·ft |
|                   | Connecting rod screw (New type) | 41 to 45 N·m<br>4.1 to 4.6 kgf·m<br>30 to 33 lbf·ft |

■ NOTE

- Connecting rod screw





|  | Old Type  | New Type  |
|--|---|---|
| Part No.                               | 15521-22140   | 1J700-22140   |
| The serration shape and the screw head |   |   |
| Tightening torque                      | 45 to 49 N·m<br>4.5 to 5.0 kgf·m<br>33 to 36 lbf·ft | 41 to 45 N·m<br>4.1 to 4.6 kgf·m<br>30 to 33 lbf·ft |

- (6) Piston Ring Compressor
- (7) Serration (Spiral)
- (8) Serration (Axial Direction)
- (9) 26 mm (1.0 in.)
- (10) 13 mm (0.51 in.)

- (A) Top Ring Gap
- (B) Second Ring Gap
- (C) Oil Ring Gap
- (D) Piston Pin Hole

(a) 0.79 rad (45°)

M00000003ENS0095US1



## Pistons

### [D1803-M-DI, V2403-M-DI, V2403-M-DI-T]

1. Fully clean the carbon (1) in the cylinders.
2. Remove the connecting rod cap (3).
3. Turn the flywheel and move the piston to top dead center.
4. Lightly tap the piston from the bottom of the crankcase with the grip of a hammer to pull the piston out.
5. Pull out the other piston in the same procedure as above.

### (When reassembling)

- Before you install the piston into the cylinder, apply sufficient engine oil to the piston.
- When you install the piston into the cylinder, point the mark on the connecting rod to the injection pump.



### ■ IMPORTANT

- Do not change the combination of cylinder and piston. Align the position of each piston by its mark. For example, mark "1" on the No. 1 piston.
- Set the top ring with its gap (A) at 1.6 rad (90 °) from the direction of the piston pin. Then set the second ring and the oil ring with their gaps (B), (C) at 2.09 rad (120 °) from the top ring gap (A). (See the figure.)
- Install the pistons with a piston ring compressor (7) carefully.
- When you install the piston in position, do not give a damage to the layer of molybdenum disulfide on the piston skirt. This layer can decrease the clearance with the cylinder liner. Immediately after you press-fit the piston pin, the piston is hot and the layer comes off easily. Only put in the piston after its temperature decreases.
- When you replace the piston, look at the code number (6) on top of the piston. Use a replacement piston with the same code number.

- |                          |                                   |
|--------------------------|-----------------------------------|
| (1) Carbon               | (4) Connecting Rod                |
| (2) Connecting Rod Screw | (5) Layer of Molybdenum Disulfide |
| (3) Connecting Rod Cap   |                                   |

(To be continued)

(Continued)



|                   |                                 |   |
|-------------------|---------------------------------|---|
| Tightening torque | Connecting rod screw (Old type) | 45 to 49 N·m<br>4.5 to 5.0 kgf·m<br>33 to 36 lbf·ft |
|                   | Connecting rod screw (New type) | 41 to 45 N·m<br>4.1 to 4.6 kgf·m<br>30 to 33 lbf·ft |

■ NOTE






- Connecting rod screw

|  | Old Type  | New Type  |
|--|---|---|
| Part No.                               | 15521-22140   | 1J700-22140   |
| The serration shape and the screw head |   |   |
| Tightening torque                      | 45 to 49 N·m<br>4.5 to 5.0 kgf·m<br>33 to 36 lbf·ft | 41 to 45 N·m<br>4.1 to 4.6 kgf·m<br>30 to 33 lbf·ft |

- (6) Code Number
- (7) Piston Ring Compressor
- (8) Serration (Spiral)
- (9) Serration (Axial Direction)
- (10) 26 mm (1.0 in.)
- (11) 13 mm (0.51 in.)

- (A) Top Ring Gap
- (B) Second Ring Gap
- (C) Oil Ring Gap
- (D) Piston Pin Hole
- (a) 2.09 rad (120 °)

M00000003ENS0096US1



**Piston Ring and Connecting Rod**

[D1503-M, D1703-M, D1803-M, V2003-M, V2203-M, V2403-M, V2403-M-T, D1703-M-BG, V2003-M-BG, V2003-M-T-BG, V2203-M-BG, V2403-M-BG]

1. Remove the piston rings (1), (2) and (3) with a piston ring tool.
2. Remove the piston pin (9) to disconnect the connecting rod (7) from the piston (6).

**(When reassembling)**






- When you install the rings to the piston (6), set the manufacturer mark (12) upward.
- When you install the oil ring (3) on the piston (6), set the expander joint (10) on the opposite side of the oil ring gap (11).
- Apply engine oil to the piston (9).
- Put the piston (6) fully in 80 °C (176 °F) oil for 10 to 15 minutes.
- Align the mark (8) on the connecting rod (7) to the fan-shaped concave (5). Then install the piston pin (9) to connect the connecting rod (7) and the piston (6).

**NOTE**

- Put a mark on the connecting rod (7) and the piston (6) with the same number to keep the same combination.

- |                          |                        |
|--------------------------|------------------------|
| (1) Top Ring             | (7) Connecting Rod     |
| (2) Second Ring          | (8) Mark               |
| (3) Oil Ring             | (9) Piston Pin         |
| (4) Piston Pin Snap Ring | (10) Expander Joint    |
| (5) Fan-Shaped Concave   | (11) Oil Ring Gap      |
| (6) Piston               | (12) Manufacturer Mark |

M00000003ENS0097US1



### Piston Ring and Connecting Rod

#### [D1803-M-DI, V2403-M-DI, V2403-M-DI-T]

1. Remove the piston rings (1), (2) and (3) with a piston ring tool.
2. Remove the piston pin (8) to disconnect the connecting rod (6) from the piston (5).

#### (When reassembling)

- When you install the rings to the piston (5), set the manufacturer mark (12) upward.
- When you install the oil ring (3) on the piston (5), set the expander joint (10) on the opposite side of the oil ring gap (11).
- Apply engine oil to the piston (8).
- Put the piston (5) fully in 80 °C (176 °F) oil for 10 to 15 minutes.
- Align the FW mark (9) that points to the flywheel with the mark (7) that points to the injection pump. Then install the piston pin (8) to connect the connecting rod (6) and the piston (5).


#### ■ NOTE

- Put a mark on the connecting rod (6) and the piston (5) with the same number to keep the same combination.

- |                          |                        |
|--------------------------|------------------------|
| (1) Top Ring             | (7) Mark               |
| (2) Second Ring          | (8) Piston Pin         |
| (3) Oil Ring             | (9) FW Mark            |
| (4) Piston Pin Snap Ring | (10) Expander Joint    |
| (5) Piston               | (11) Oil Ring Gap      |
| (6) Connecting Rod       | (12) Manufacturer Mark |

M00000003ENS0098US1

## (6) Flywheel and Crankshaft



### Flywheel

1. Attach the stopper to the flywheel (1).
2. Remove 2 flywheel screws (2).
3. Put the 2 flywheel guide screws (3) in the holes.
4. Remove all the flywheel screws (2).
5. Remove the flywheel (1) slowly along the flywheel guide screws (3).


#### (When reassembling)

- Put in 2 flywheel guide screws (3).
- Check that there are no metal particles that remain on the flywheel mounting surfaces.
- Apply engine oil to the threads and the flange seat face of the flywheel screw. Then attach the screw.

|                   |                |  |
|-------------------|----------------|--|
| Tightening torque | Flywheel screw | 98.1 to 107 N·m<br>10.0 to 11.0 kgf·m<br>72.4 to 79.5 lbf·ft |
|-------------------|----------------|--|

- (1) Flywheel (3) Flywheel Guide Screws  
(2) Flywheel Screw

M00000003ENS0099US1



### Bearing Case Cover

1. Remove the mounting screws of the bearing case cover. First, remove inner screws (5) and then external screws (3).
2. Remove the bearing case cover (6).

#### ■ IMPORTANT

- **The length of inner screws (5) and external screws (3) are different. Make sure that you use the correct one at the correct position.**



#### (When reassembling)






- Attach the bearing case gasket (1) and the bearing case cover gasket (2) in the correct directions.
- Put the casting mark "UP" of the bearing case cover (6) upward, then install the bearing case cover.
- Apply a thin layer of engine oil to the oil seal. Then install the oil seal not to come off the lip.
- Tighten the mounting screws of the bearing case cover with an equal force on the diagonal line.

|                   |                                      |   |
|-------------------|--------------------------------------|---|
| Tightening torque | Mounting screw of bearing case cover | 24 to 27 N·m<br>2.4 to 2.8 kgf·m<br>18 to 20 lbf·ft |
|-------------------|--------------------------------------|---|

- (1) Bearing Case Gasket (5) Mounting Screw of Bearing Case Cover  
(2) Bearing Case Cover Gasket (6) Bearing Case Cover  
(3) Mounting Screw of Bearing Case Cover (a) Upside  
(4) Oil Seal

M00000003ENS0100US1





**Crankshaft**

■ **NOTE**

- Before you disassemble, measure the side clearance of crankshaft. Measure it when you assemble again.

[D1503-M, D1703-M, V2003-M, V2203-M, D1703-M-BG, V2003-M-BG, V2003-M-T-BG, V2203-M-BG]

1. Remove the screw 2 (1) of the main bearing case.
2. Pull out the crankshaft assembly not to give a damage to the crankshaft bearing 1 (3).

[D1803-M, D1803-M-DI]

1. Remove the screw 2 (1) of the main bearing case.
2. Turn the crankshaft to set the crankpin of the third cylinder to the bottom dead center.
3. Pull out the crankshaft until the crankpin of the second cylinder comes to the center of the third cylinder.
4. Turn the crankshaft by 2.09 rad (120 °) counterclockwise to set the crankpin of the second cylinder to the bottom dead center.
5. Pull out the crankshaft until the crankpin of the first cylinder comes to the center of the third cylinder.

[V2403-M, V2403-M-DI, V2403-M-T, V2403-M-DI-T, V2403-M-BG]

1. Remove the screw 2 (1) of the main bearing case.
2. Turn the crankshaft to set the crankpin of the fourth cylinder to the horizontal directions (right or left).
3. Hold the crankpins to the horizontal directions (right or left) and pull out the crankshaft completely.

(When reassembling)

■ **IMPORTANT**

- When you install the crankshaft assembly, align the screw hole of the main bearing case 2 (2) with the screw hole of the cylinder block.

- Apply oil to the screw 2 (1) of the main bearing case and tighten the screw by hand.

If you cannot turn the screw 2 smoothly, align the screw holes between the cylinder block and the main bearing case correctly.

Then tighten the screw 2 to the specified tightening torque with a torque wrench.






|                   |                              |   |
|-------------------|------------------------------|---|
| Tightening torque | Screw 2 of main bearing case | 69 to 73 N·m<br>7.0 to 7.5 kgf·m<br>51 to 54 lbf·ft |
|-------------------|------------------------------|---|

- (1) Screw 2 of Main Bearing Case
- (2) Main Bearing Case 2
- (3) Crankshaft Bearing 1

(a) Cut place to remove and install the crankshaft

[A] D1803-M, D1803-M-DI

M00000003ENS0101US1



**Main Bearing Case Assembly**

1. Remove the screws 1 of the main bearing case (7). Then remove the main bearing case.
2. Remove other main bearing cases as above.

**(When reassembling)**

- Clean the oil channel in the main bearing case.
- Apply clean engine oil on the bearings.
- Align the numbers (1) and mark (2) on the main bearing case.
- When you install the main bearing case 1 and 2, point the mark "FLYWHEEL" to the flywheel.
- When you install the thrust bearing, point the oil groove (8) externally.
- Install the main bearing case assemblies in the initial positions. Since the diameters of the main bearing cases are different, install them in the sequence of their marks (A, B for 3 cylinders and A, B, C for 4 cylinders) from the gear case side.
- After you tighten the screw 1 of the main bearing case (7) to the specified torque, make sure that the main bearing case moves smoothly.


|                   |                              |   |
|-------------------|------------------------------|---|
| Tightening torque | Screw 1 of main bearing case | 46 to 50 N·m<br>4.7 to 5.2 kgf·m<br>34 to 37 lbf·ft |
|-------------------|------------------------------|---|

- |                      |                                  |
|----------------------|----------------------------------|
| (1) Alignment Number | (5) C                            |
| (2) Alignment Mark   | (6) No Mark                      |
| (3) A                | (7) Screw 1 of Main Bearing Case |
| (4) B                | (8) Oil Groove                   |

M00000003ENS0102US1

## (7) Starter

### Starter



- (1) Through Bolt
- (2) Brush
- (3) C Terminal Nut
- (4) Yoke
- (5) Armature
- (6) Overrunning Clutch
- (7) Idle Gear
- (8) End Frame
- (9) Brush Holder
- (10) Magnet Switch Cover
- (11) Plunger
- (12) B Terminal Nut
- (13) Housing

1. Remove the C terminal nut (3), and disconnect the connecting lead.
2. Remove the 2 through bolts (1).
3. Remove the motor.
4. Remove the end frame (8).
5. Hold the spring up and remove the brush from the brush holder.
6. Remove the brush holder (9).
7. Pull out the armature (5) from the yoke (4).
8. Remove the housing (13).
9. Remove the idle gear (7) and the overrunning clutch (6).
10. Remove the magnet switch cover (10).
11. Remove the plunger (11).

#### ■ NOTE

- Do not cause damage to the brush and commutator.

#### (When reassembling)


- Apply grease (DENSO No. 50 or equivalent) to the idle gear and overrunning clutch parts.

|                   |                |   |
|-------------------|----------------|---|
| Tightening torque | B terminal nut | 5.9 to 11 N·m<br>0.60 to 1.2 kgf·m<br>4.4 to 8.6 lbf·ft |
|-------------------|----------------|---|

M0000003ENS0103US1

## (8) Alternator

### Alternator



1. Remove the pulley (1).
2. Remove the rear end cover (12).
3. Remove the brush holder (11).
4. Remove the IC regulator (10).
5. Remove the 4 screws that hold the stator lead wires.
6. Remove the rectifier (9).
7. Remove the rear end frame (8).
8. Push out the rotor (6) from the drive end frame (2).
9. Remove the retainer plate (5).
10. Push out the bearing (4) from the drive end frame (2) with a press and jig.
11. Lightly hold the rotor with a vise to prevent damage, and remove the bearing (7) with a puller.




#### (When reassembling)

|                   |            |   |
|-------------------|------------|---|
| Tightening torque | Pulley nut | 58.4 to 78.9 N·m<br>5.95 to 8.05 kgf·m<br>43.1 to 58.2 lbf·ft |
|-------------------|------------|---|

M0000003ENS0104US1

### [3] SERVICING

#### (1) Cylinder Head and Valves



#### Top Clearance

1. Remove the cylinder head.
2. With the piston at TDC, use grease to affix three or four plastigauges (1) of a diameter 1.5 mm (0.059 in.) × 5.0 to 7.0 mm (0.20 to 0.27 in.) long to the crown of the piston; keep the gauges away from the intake valve and combustion chamber fittings.
3. Take the piston to an intermediate position, install the cylinder head and tighten the head screws to the specified torque.
4. Turn the crankshaft so the piston goes through TDC.
5. Remove the cylinder head and compare the width of the crushed plastigauges (2) with the scale (3).
6. If they are out of spec, check the oil clearance of the crank pin, journals and piston pin.

#### NOTE


- Top clearance = Width of the crushed plastigauge (2).

|                   |                       |   |   |
|-------------------|-----------------------|---|---|
| Top clearance     | Factory specification | D1503-M, D1703-M, D1803-M, V2003-M, V2203-M, V2403-M, V2403-M-T, D1703-M-BG, V2003-M-BG, V2003-M-T-BG, V2203-M-BG, V2403-M-BG | 0.575 to 0.675 mm<br>0.0227 to 0.0265 in. |
|                   |                       | D1803-M-DI, V2403-M-DI, V2403-M-DI-T  | 0.60 to 0.70 mm<br>0.024 to 0.027 in.     |
| Tightening torque | Cylinder head screws  | 93.2 to 98.0 N·m<br>9.50 to 10.0 kgf·m<br>68.8 to 72.3 lbf·ft   |   |

- (1) Plastigauge
- (2) Crushed Plastigauge
- (3) Scale

- [A] D1503-M, D1703-M, D1803-M, V2003-M, V2203-M, V2403-M, V2403-M-T, D1703-M-BG, V2003-M-BG, V2003-M-T-BG, V2203-M-BG, V2403-M-BG
- [B] D1803-M-DI, V2403-M-DI, V2403-M-DI-T

M00000003ENS0105US1




### Cylinder Head Surface Flatness

1. Clean the cylinder head surface.
2. Put a straightedge on the cylinder head.
3. Measure the clearance with a feeler gauge at the 6 places (see the figure).
4. If the measurement is more than the allowable limit, make it straight with a surface grinder.


■ **IMPORTANT**

- Do not put a straightedge on the combustion chamber.
- Check the valve recessing after you correct.



|                                |                 |                      |
|--------------------------------|-----------------|----------------------|
| Cylinder head surface flatness | Allowable limit | 0.05 mm<br>0.002 in. |
|--------------------------------|-----------------|----------------------|

M00000003ENS0106US1





### Cylinder Head Flaw

1. Prepare an air spray red check.
2. Clean the surface of the cylinder head with detergent (2).
3. Apply some red permeative liquid (1) on the cylinder head surface. After you apply, do not touch it for 5 to 10 minutes.
4. Clean away the red permeative liquid on the cylinder head surface with detergent (2).
5. Apply the white developer (3) on the cylinder head surface.
6. If you found a red flaw, replace the cylinder head.

- (1) Red Permeative Liquid                      (3) White Developer  
 (2) Detergent

M00000003ENS0107US1



**Valve Recessing**

1. Clean the cylinder head surface, valve face and valve seat.
2. Set the valve into the valve guide.
3. Measure the valve recessing with a depth gauge.
4. If the measurement is more than the allowable limit, replace the valve.
5. If it stays more than the allowable limit after you replace the valve, replace the cylinder head.




|                 |                       |  |  |
|-----------------|-----------------------|--|--|
| Valve recessing | Factory specification | D1503-M,<br>D1703-M,<br>D1803-M,<br>V2003-M,<br>V2203-M,<br>V2403-M,<br>V2403-M-T,<br>D1703-M-BG,<br>V2003-M-BG,<br>V2003-M-T-BG,<br>V2203-M-BG,<br>V2403-M-BG | 0.05 (protrusion) to<br>0.15 (recessing) mm<br>0.002 (protrusion) to<br>0.0059 (recessing) in. |
|                 |                       | D1803-M-DI,<br>V2403-M-DI,<br>V2403-M-DI-T   | 0.65 to 0.85 mm<br>0.026 to 0.033 in.  |
|                 | Allowable limit       | D1503-M,<br>D1703-M,<br>D1803-M,<br>V2003-M,<br>V2203-M,<br>V2403-M,<br>V2403-M-T,<br>D1703-M-BG,<br>V2003-M-BG,<br>V2003-M-T-BG,<br>V2203-M-BG,<br>V2403-M-BG | 0.40 (recessing) mm<br>0.016 (recessing) in.   |
|                 |                       | D1803-M-DI,<br>V2403-M-DI,<br>V2403-M-DI-T   | 1.20 mm<br>0.0472 in.  |

(1) Cylinder Head Surface

**(A) Recessing**

**(B) Protrusion**

M00000003ENS0108US1



**Clearance between Valve Stem and Valve Guide**

1. Remove carbon from the valve guide section.
2. Measure the valve stem O.D. with an external micrometer.
3. Measure the valve guide I.D. with a small hole gauge, and calculate the clearance.
4. If the clearance is more than the allowable limit, replace the valves.
5. If the clearance stays more than the allowable limit, replace the valve guide also.

|  |                       |   |
|--|-----------------------|---|
| Clearance between valve stem and valve guide | Factory specification | 0.040 to 0.070 mm<br>0.0016 to 0.0027 in. |
|  | Allowable limit       | 0.10 mm<br>0.0039 in.                     |

|                  |                       |   |
|------------------|-----------------------|---|
| Valve stem O.D.  | Factory specification | 7.960 to 7.975 mm<br>0.3134 to 0.3139 in. |
| Valve guide I.D. | Factory specification | 8.015 to 8.030 mm<br>0.3156 to 0.3161 in. |

M00000003ENS0109US1

**Replacement of Valve Guide**

**(When removing)**

1. Press out the used valve guide with the valve guide replacing tool. (See page "SPECIAL TOOLS".)

**(When installing)**

1. Clean the new valve guide and valve guide bore, and apply engine oil to them.
2. Press fit the new valve guide with the valve guide replacing tool.
3. Ream accurately the I.D. of the valve guide to the specified dimension.

|                                       |                       |   |
|---------------------------------------|-----------------------|---|
| Valve guide I.D. (Intake and exhaust) | Factory specification | 8.015 to 8.030 mm<br>0.3156 to 0.3161 in. |
|---------------------------------------|-----------------------|---|


**■ IMPORTANT**

- Do not hit the valve guide with a hammer during replacement.

(A) When Removing

(B) When Installing


M00000003ENS0110US1



**Valve Seating**




1. Apply a thin layer of Prussian Blue on the valve face. Then put the valve on its seat to check the contact.
2. If the valve is not fully around the seat or the contact is less than 70 % of the factory specification, correct the valve seat. See the next section.
3. If the valve contact width cannot get the factory specification, replace the valve or correct the contact of the valve seat.

|                     |                       |                       |
|---------------------|-----------------------|-----------------------|
| Valve contact width | Factory specification | 2.12 mm<br>0.0835 in. |
|---------------------|-----------------------|-----------------------|



- (1) Correct (3) Incorrect  
 (2) Incorrect

M00000003ENS0111US1



**Correction of Valve and Valve Seat**

■ **NOTE**

- Before you correct the valve and seat, check the valve stem and measure the I.D. of the valve guide section. Repair them if necessary.
- After you correct the valve seat, be sure to check the valve recessing.

**1) Correction of valve**

1. Correct the valve with a valve refacer.

**[D1503-M, D1703-M, D1803-M, V2003-M, V2203-M, V2403-M, V2403-M-T, D1703-M-BG, V2003-M-BG, V2003-M-T-BG, V2203-M-BG, V2403-M-BG]**

|                  |                       |         |                  |
|------------------|-----------------------|---------|------------------|
| Valve face angle | Factory specification | Intake  | 1.0 rad<br>60 °  |
|                  |                       | Exhaust | 0.79 rad<br>45 ° |

**[D1803-M-DI, V2403-M-DI, V2403-M-DI-T]**

|                  |                       |         |                  |
|------------------|-----------------------|---------|------------------|
| Valve face angle | Factory specification | Intake  | 0.79 rad<br>45 ° |
|                  |                       | Exhaust | 0.79 rad<br>45 ° |

**2) Correction of valve seat**

1. Slightly correct the seat surface with a 1.0 rad (60 °) or 0.79 rad (45 °) valve seat cutter.
2. Correct the seat surface with a 0.52 rad (30 °) or 0.26 rad (15 °) valve seat cutter. The width must be near the specified valve seat width (2.12 mm, 0.0835 in.).
3. After you correct the seat, check that the valve seating is flat. Apply a thin layer of compound between the valve face and valve seat, and lap them with a valve lapping tool.
4. Check the valve seating with Prussian Blue. The valve seating surface must show good contact on all sides.

**[D1503-M, D1703-M, D1803-M, V2003-M, V2203-M, V2403-M, V2403-M-T, D1703-M-BG, V2003-M-BG, V2003-M-T-BG, V2203-M-BG, V2403-M-BG]**

|                  |                       |         |                  |
|------------------|-----------------------|---------|------------------|
| Valve seat angle | Factory specification | Intake  | 1.0 rad<br>60 °  |
|                  |                       | Exhaust | 0.79 rad<br>45 ° |


**[D1803-M-DI, V2403-M-DI, V2403-M-DI-T]**

|                  |                       |         |                  |
|------------------|-----------------------|---------|------------------|
| Valve seat angle | Factory specification | Intake  | 0.79 rad<br>45 ° |
|                  |                       | Exhaust | 0.79 rad<br>45 ° |

- (1) Valve Seat Width
- (2) Identical Dimensions

- (A) Check the Contact**
- (B) Correct Seat Width**
- (C) Check the Contact**
- (a) 0.26 rad (15 °) or 0.52 rad (30 °)
- (b) 0.79 rad (45 °) or 1.0 rad (60 °)
- (c) 0.52 rad (30 °) or 0.26 rad (15 °)

M00000003ENS0112US1




**Valve Lapping**

1. Apply the compound equally to the valve lapping surface.
2. Put the valve into the valve guide. Lap the valve on its seat with a valve lapping tool.
3. After you lap the valve, clean away the compound and apply oil, then lap the valve again with oil.
4. Apply Prussian Blue to the contact surface to measure the seated rate.
5. If the seated rate is less than 70 %, lap the valve again.

■ **IMPORTANT**

- After you complete the valve lapping and assemble the valve, check the valve recessing and adjust the valve clearance.

M00000003ENS0113US1



**Free Length and Tilt of Valve Spring**

1. Measure the free length (B) of valve spring with a vernier calipers.
2. If the measurement is less than the allowable limit, replace it.
3. Put the valve spring on a surface plate, and put a square on the side of the valve spring.
4. Make sure that the full side is in contact with the square.
5. Turn the valve spring to measure the maximum tilt (A).
6. If the measurement is more than the allowable limit, replace it.
7. Check the full surface of the valve spring for scratches.
8. If there is a defect, replace it.


|          |                 |                     |
|----------|-----------------|---------------------|
| Tilt (A) | Allowable limit | 1.0 mm<br>0.039 in. |
|----------|-----------------|---------------------|

|                 |                       |                                     |
|-----------------|-----------------------|-------------------------------------|
| Free length (B) | Factory specification | 41.7 to 42.2 mm<br>1.65 to 1.66 in. |
|                 | Allowable limit       | 41.2 mm<br>1.62 in.                 |

(A) Tilt

(B) Free Length

M00000003ENS0114US1




**Setting Load of Valve Spring**

1. Put the valve spring on a tester.
2. Compress the valve spring to the specified setting length.
3. Read the compression load on the gauge.
4. If the measurement is less than the allowable limit, replace the valve spring.

|                                  |                       |  |
|----------------------------------|-----------------------|--|
| Setting load /<br>Setting length | Factory specification | 118 N / 35.0 mm<br>12.0 kgf / 35.0 mm<br>26.5 lbf / 1.38 in. |
|                                  | Allowable limit       | 100 N / 35.0 mm<br>10.2 kgf / 35.0 mm<br>22.5 lbf / 1.38 in. |

M00000003ENS0115US1



**Oil Clearance between Rocker Arm and Rocker Arm Shaft**


1. Measure the rocker arm shaft O.D. with an external micrometer.
2. Measure the rocker arm I.D. with an internal micrometer.
3. Calculate the oil clearance.
4. If the oil clearance is more than the allowable limit, replace the rocker arm and measure the oil clearance again.
5. If the oil clearance stays more than the allowable limit, replace the rocker arm shaft also.

|   |                       |  |
|---|-----------------------|--|
| Oil clearance between rocker arm and rocker arm shaft | Factory specification | 0.016 to 0.045 mm<br>0.00063 to 0.0017 in. |
|   | Allowable limit       | 0.10 mm<br>0.0039 in.                      |

|                       |                       |   |
|-----------------------|-----------------------|---|
| Rocker arm shaft O.D. | Factory specification | 13.973 to 13.984 mm<br>0.55012 to 0.55055 in. |
|-----------------------|-----------------------|---|

|                 |                       |   |
|-----------------|-----------------------|---|
| Rocker arm I.D. | Factory specification | 14.000 to 14.018 mm<br>0.55119 to 0.55188 in. |
|-----------------|-----------------------|---|

M00000003ENS0116US1




**Push Rod Bend**

1. Put the push rod on V blocks.
2. Set a dial indicator with its point on the middle of the push rod.
3. Turn the push rod slowly and read the variation on the indicator.
4. If the measurement is more than the allowable limit, replace the push rod.

|               |                 |                       |
|---------------|-----------------|-----------------------|
| Push rod bend | Allowable limit | 0.25 mm<br>0.0098 in. |
|---------------|-----------------|-----------------------|

M00000003ENS0117US1



**Oil Clearance between Tappet and Tappet Guide Bore**

1. Measure the tappet O.D. with an external micrometer.
2. Measure the tappet guide bore I.D. with a cylinder gauge.
3. Calculate the oil clearance.
4. If the oil clearance is more than the allowable limit or the tappet has a damage, replace the tappet.


|  |                       |  |
|--|-----------------------|--|
| Oil Clearance between tappet and tappet guide bore | Factory specification | 0.020 to 0.062 mm<br>0.00079 to 0.0024 in. |
|  | Allowable limit       | 0.07 mm<br>0.003 in.                       |

|             |                       |   |
|-------------|-----------------------|---|
| Tappet O.D. | Factory specification | 23.959 to 23.980 mm<br>0.94327 to 0.94409 in. |
|-------------|-----------------------|---|

|                        |                       |   |
|------------------------|-----------------------|---|
| Tappet guide bore I.D. | Factory specification | 24.000 to 24.021 mm<br>0.94489 to 0.94570 in. |
|------------------------|-----------------------|---|

M00000003ENS0118US1

## (2) Timing Gears



### Timing Gear Backlash

1. Set a dial indicator (lever type) with its point on the gear tooth.
2. Hold the mating gear and move the gear to measure the backlash.
3. If the backlash is more than the allowable limit, measure the oil clearance in the journal part of each shaft.
4. If the oil clearance is correct, replace the gear.

|   |                       |  |
|---|-----------------------|--|
| Backlash between idle gear and crank gear | Factory specification | 0.04150 to 0.1122 mm<br>0.001634 to 0.004417 in. |
|   | Allowable limit       | 0.15 mm<br>0.0059 in.                            |

|   |                       |  |
|---|-----------------------|--|
| Backlash between idle gear and cam gear | Factory specification | 0.04150 to 0.1154 mm<br>0.001634 to 0.004543 in. |
|   | Allowable limit       | 0.15 mm<br>0.0059 in.                            |

|  |                       |  |
|--|-----------------------|--|
| Backlash between idle gear and injection pump gear | Factory specification | 0.04150 to 0.1154 mm<br>0.001634 to 0.004543 in. |
|  | Allowable limit       | 0.15 mm<br>0.0059 in.                            |

|   |                       |  |
|---|-----------------------|--|
| Backlash between crank gear and oil pump gear | Factory specification | 0.04150 to 0.1090 mm<br>0.001634 to 0.004291 in. |
|   | Allowable limit       | 0.15 mm<br>0.0059 in.                            |

### **For balancer model only**

|  |                       |  |
|--|-----------------------|--|
| Backlash between idle gear and balancer gear (Intake side) | Factory specification | 0.03500 to 0.1160 mm<br>0.001378 to 0.004566 in. |
|  | Allowable limit       | 0.15 mm<br>0.0059 in.                            |


|  |                       |  |
|--|-----------------------|--|
| Backlash between cam gear and balancer gear (Exhaust side) | Factory specification | 0.03500 to 0.1160 mm<br>0.001378 to 0.004566 in. |
|  | Allowable limit       | 0.15 mm<br>0.0059 in.                            |

### **For side PTO model only**

|   |                       |  |
|---|-----------------------|--|
| Backlash between crank gear and idle gear 2 | Factory specification | 0.04150 to 0.1154 mm<br>0.001634 to 0.004543 in. |
|   | Allowable limit       | 0.15 mm<br>0.0059 in.                            |

|  |                       |  |
|--|-----------------------|--|
| Backlash between idle gear 2 and hydraulic pump drive gear | Factory specification | 0.03080 to 0.1062 mm<br>0.001213 to 0.004181 in. |
|  | Allowable limit       | 0.15 mm<br>0.0059 in.                            |

M00000003ENS0119US1




### Side Clearance of Idle Gear

1. Set a dial indicator with its point on the idle gear.
2. Move the idle gear to the front and rear to measure the side clearance.
3. If the measurement is more than the allowable limit, replace the idle gear collar.

|                             |                       |  |
|-----------------------------|-----------------------|--|
| Side clearance of idle gear | Factory specification | 0.12 to 0.48 mm<br>0.0048 to 0.018 in. |
|                             | Allowable limit       | 0.9 mm<br>0.04 in.                     |

M00000003ENS0120US1




### Side Clearance of Camshaft

1. Set a dial indicator with its point on the camshaft.
2. Move the cam gear to the front and rear to measure the side clearance.
3. If the measurement is more than the allowable limit, replace the camshaft stopper.

|                            |                       |  |
|----------------------------|-----------------------|--|
| Side clearance of camshaft | Factory specification | 0.070 to 0.22 mm<br>0.0028 to 0.0086 in. |
|                            | Allowable limit       | 0.30 mm<br>0.012 in.                     |

M00000003ENS0121US1




### Camshaft Bend

1. Hold the 2 end journals of camshaft with V blocks on the surface plate.
2. Set a dial indicator with its point on the middle journal.
3. Turn the camshaft slowly and read the variation on the indicator.
4. If the measurement is more than the allowable limit, replace the camshaft.

|               |                 |                       |
|---------------|-----------------|-----------------------|
| Camshaft bend | Allowable limit | 0.01 mm<br>0.0004 in. |
|---------------|-----------------|-----------------------|

M00000003ENS0122US1



### Cam Height

1. Measure the height of the cam at its highest point with an external micrometer.
2. If the measurement is less than the allowable limit, replace the camshaft.



|                      |                       |   |                       |
|----------------------|-----------------------|---|-----------------------|
| Cam height of intake | Factory specification | D1503-M,<br>D1703-M-BG  | 33.27 mm<br>1.310 in. |
|                      |                       | V2003-M,<br>V2403-M-DI-T,<br>V2003-M-BG,<br>V2203-M-BG  | 33.47 mm<br>1.318 in. |
|                      |                       | D1703-M,<br>D1803-M,<br>V2203-M,<br>V2403-M,<br>V2403-M-T,<br>D1803-M-DI,<br>V2403-M-DI,<br>V2003-M-T-BG,<br>V2403-M-BG | 33.90 mm<br>1.335 in. |
|                      | Allowable limit       | D1503-M,<br>D1703-M-BG  | 33.22 mm<br>1.308 in. |
|                      |                       | V2003-M,<br>V2403-M-DI-T,<br>V2003-M-BG,<br>V2203-M-BG  | 33.42 mm<br>1.316 in. |
|                      |                       | D1703-M,<br>D1803-M,<br>V2203-M,<br>V2403-M,<br>V2403-M-T,<br>D1803-M-DI,<br>V2403-M-DI,<br>V2003-M-T-BG,<br>V2403-M-BG | 33.85 mm<br>1.333 in. |

**(To be continued)**

(Continued)

|                       |                       |  |                       |
|-----------------------|-----------------------|--|-----------------------|
| Cam height of exhaust | Factory specification | D1503-M, V2003-M, V2003-M-T-BG   | 33.47 mm<br>1.318 in. |
|                       |                       | D1703-M, D1803-M, V2203-M, V2403-M, D1803-M-DI, V2403-M-DI, V2403-M-BG | 33.90 mm<br>1.335 in. |
|                       |                       | V2403-M-T, D1703-M-BG, V2003-M-BG, V2203-M-BG                          | 33.27 mm<br>1.310 in. |
|                       |                       | V2403-M-DI-T   | 33.00 mm<br>1.299 in. |
|                       | Allowable limit       | D1503-M, V2003-M, V2003-M-T-BG   | 33.42 mm<br>1.316 in. |
|                       |                       | D1703-M, D1803-M, V2203-M, V2403-M, D1803-M-DI, V2403-M-DI, V2403-M-BG | 33.85 mm<br>1.333 in. |
|                       |                       | V2403-M-T, D1703-M-BG, V2003-M-BG, V2203-M-BG                          | 33.22 mm<br>1.308 in. |
|                       |                       | V2403-M-DI-T   | 32.95 mm<br>1.297 in. |

M00000003ENS0123US1




**Oil Clearance of Camshaft Journal**

1. Measure the camshaft journal O.D. with an external micrometer.
2. Measure the cylinder block bore I.D. for the camshaft with a cylinder gauge.
3. Calculate the oil clearance.
4. If the oil clearance is more than the allowable limit, replace the camshaft.

|                                   |                       |   |
|-----------------------------------|-----------------------|---|
| Oil clearance of camshaft journal | Factory specification | 0.050 to 0.091 mm<br>0.0020 to 0.0035 in. |
|                                   | Allowable limit       | 0.15 mm<br>0.0059 in.                     |

|                          |                       |   |
|--------------------------|-----------------------|---|
| Camshaft journal O.D.    | Factory specification | 39.934 to 39.950 mm<br>1.5722 to 1.5728 in. |
| Cylinder block bore I.D. | Factory specification | 40.000 to 40.025 mm<br>1.5748 to 1.5757 in. |

M00000003ENS0124US1



3TMABAB1P069A


**Oil Clearance between Idle Gear Shaft and Idle Gear Bushing**

1. Measure the idle gear shaft O.D. with an external micrometer.
2. Measure the idle gear bushing I.D. with an internal micrometer.
3. Calculate the oil clearance.
4. If the oil clearance is more than the allowable limit, replace the bushing.
5. If the oil clearance stays more than the allowable limit, replace the idle gear shaft also.

|   |                       |  |
|---|-----------------------|--|
| Oil clearance between idle gear shaft and idle gear bushing | Factory specification | 0.025 to 0.066 mm<br>0.00099 to 0.0025 in. |
|   | Allowable limit       | 0.10 mm<br>0.0039 in.                      |

|                        |                       |   |
|------------------------|-----------------------|---|
| Idle gear shaft O.D.   | Factory specification | 37.959 to 37.975 mm<br>1.4945 to 1.4950 in. |
| Idle gear bushing I.D. | Factory specification | 38.000 to 38.025 mm<br>1.4961 to 1.4970 in. |

M00000003ENS0125US1



3EEABAB1P134A

**Replacement of Idle Gear Bushing**

**(When removing)**

1. Press out the used idle gear bushing with the replacing tool.  
(See page "SPECIAL TOOLS".)


**(When installing)**

1. Clean a new idle gear bushing and idle gear bore, and apply engine oil to them.
2. Press fit the new bushing with the replacing tool.  
Make sure that the bushing end aligns the end of the idle gear.

(A) When Removing

(B) When Installing

M00000003ENS0126US1




3TMABAB1P066A

**Side Clearance of Balancer Shaft (for Balancer Model Only)**

1. Set a dial indicator with its point on the balancer shaft.
2. Move the balancer shaft to the front and rear to measure the side clearance.
3. If the measurement is more than the allowable limit, replace the balancer shaft.

|                                  |                       |  |
|----------------------------------|-----------------------|--|
| Side clearance of balancer shaft | Factory specification | 0.070 to 0.22 mm<br>0.0028 to 0.0086 in. |
|                                  | Allowable limit       | 0.30 mm<br>0.012 in.                     |

M00000003ENS0127US1





3EEABAB1P136A

**Balancer Shaft Bend (for Balancer Model Only)**

1. Hold the balancer shaft with V blocks on the surface plate.
2. Set a dial indicator with its point on the middle journal at a high angle.
3. Turn the balancer shaft slowly and read the variation on the indicator.
4. If the measurement is more than the allowable limit, replace the balancer shaft.

|                     |                 |                       |
|---------------------|-----------------|-----------------------|
| Balancer shaft bend | Allowable limit | 0.02 mm<br>0.0008 in. |
|---------------------|-----------------|-----------------------|

M00000003ENS0128US1



### **Oil Clearance of Balancer Shaft Journal (for Balancer Model Only)**

1. Measure the balancer shaft journal O.D. with an external micrometer.
2. Measure the cylinder block bore I.D. for the balancer shaft with an internal micrometer or cylinder gauge.
3. Calculate the oil clearance.
4. If the oil clearance is more than the allowable limit, replace the balancer shaft.

|   |                       |  |
|---|-----------------------|--|
| Oil clearance of balancer shaft journal 1 | Factory specification | 0.0300 to 0.111 mm<br>0.00119 to 0.00437 in. |
|   | Allowable limit       | 0.20 mm<br>0.0079 in.                        |

|                               |                       |   |
|-------------------------------|-----------------------|---|
| Balancer shaft journal 1 O.D. | Factory specification | 43.934 to 43.950 mm<br>1.7297 to 1.7303 in. |
|-------------------------------|-----------------------|---|

|                               |                       |   |
|-------------------------------|-----------------------|---|
| Balancer shaft bearing 1 I.D. | Factory specification | 43.980 to 44.045 mm<br>1.7315 to 1.7340 in. |
|-------------------------------|-----------------------|---|

|   |                       |  |
|---|-----------------------|--|
| Oil clearance of balancer shaft journal 2 | Factory specification | 0.0300 to 0.111 mm<br>0.00119 to 0.00437 in. |
|   | Allowable limit       | 0.20 mm<br>0.0079 in.                        |

|                               |                       |   |
|-------------------------------|-----------------------|---|
| Balancer shaft journal 2 O.D. | Factory specification | 41.934 to 41.950 mm<br>1.6509 to 1.6515 in. |
|-------------------------------|-----------------------|---|

|                               |                       |   |
|-------------------------------|-----------------------|---|
| Balancer shaft bearing 2 I.D. | Factory specification | 41.980 to 42.045 mm<br>1.6528 to 1.6553 in. |
|-------------------------------|-----------------------|---|

|   |                       |  |
|---|-----------------------|--|
| Oil clearance of balancer shaft journal 3 | Factory specification | 0.020 to 0.094 mm<br>0.00079 to 0.0037 in. |
|   | Allowable limit       | 0.20 mm<br>0.0079 in.                      |

|                               |                       |   |
|-------------------------------|-----------------------|---|
| Balancer shaft journal 3 O.D. | Factory specification | 21.947 to 21.960 mm<br>0.86406 to 0.86456 in. |
|-------------------------------|-----------------------|---|


|                               |                       |   |
|-------------------------------|-----------------------|---|
| Balancer shaft bearing 3 I.D. | Factory specification | 21.980 to 22.041 mm<br>0.86536 to 0.86775 in. |
|-------------------------------|-----------------------|---|

- (1) Balancer Shaft Journal 3  
(2) Balancer Shaft Journal 2

- (3) Balancer Shaft Journal 1

M00000003ENS0129US1

### (3) Piston and Connecting Rod




#### Piston Pin Bore I.D.

1. Measure the piston pin bore I.D. in the horizontal and vertical directions with a cylinder gauge.
2. If the measurement is more than the allowable limit, replace the piston.

|                      |                       |   |
|----------------------|-----------------------|---|
| Piston pin bore I.D. | Factory specification | 25.000 to 25.013 mm<br>0.98426 to 0.98476 in. |
|                      | Allowable limit       | 25.05 mm<br>0.9862 in.                        |

M00000003ENS0130US1




#### Oil Clearance between Piston Pin and Small End Bushing

1. Measure the piston pin O.D. where it touches the bushing with an external micrometer.
2. Measure the small end bushing I.D. with an internal micrometer.
3. Calculate the oil clearance.
4. If the oil clearance is more than the allowable limit, replace the bushing.
5. If the oil clearance stays more than the allowable limit, replace the piston pin also.

|  |                       |  |
|--|-----------------------|--|
| Oil clearance between piston pin and small end bushing | Factory specification | 0.014 to 0.036 mm<br>0.00056 to 0.0014 in. |
|  | Allowable limit       | 0.15 mm<br>0.0059 in.                      |

|                        |                       |   |
|------------------------|-----------------------|---|
| Piston pin O.D.        | Factory specification | 25.004 to 25.011 mm<br>0.98441 to 0.98468 in. |
| Small end bushing I.D. | Factory specification | 25.025 to 25.040 mm<br>0.98524 to 0.98582 in. |

M00000003ENS0131US1



#### Replacement of Small End Bushing

##### **(When removing)**

1. Press out the used small end bushing with the replacing tool. (See page "SPECIAL TOOLS".)


##### **(When installing)**

1. Clean a new small end bushing and bore, and apply engine oil to them.
2. Make sure that the oil hole of the connecting rod aligns the bushing hole. Then press fit the new bushing with the replacing tool.

(A) When Removing

(B) When Installing

M00000003ENS0132US1




### Connecting Rod Alignment

#### ■ NOTE

- **Make sure that the oil clearance of the small end bushing is less than the allowable limit.**
1. Install the piston pin into the connecting rod.
  2. Install the connecting rod on the alignment tool of the connecting rod.
  3. Put a gauge on the piston pin, and move it against the face plate.
  4. If the gauge does not touch fully against the face plate, measure the space between the gauge pin and face plate.
  5. If the measurement is more than the allowable limit, replace the connecting rod.

|                          |                 |                      |
|--------------------------|-----------------|----------------------|
| Connecting rod alignment | Allowable limit | 0.05 mm<br>0.002 in. |
|--------------------------|-----------------|----------------------|

M00000003ENS0133US1





**Piston Ring Gap**

1. Put the piston ring into the lower part of the liner (the least worn out part) with the piston.
2. Measure the ring gap with a feeler gauge.
3. If the ring gap is more than the allowable limit, replace the ring.

|             |                       |   |  |
|-------------|-----------------------|---|--|
| Top ring    | Factory specification | D1503-M, V2003-M, V2403-M-T, D1803-M-DI, V2403-M-DI, V2403-M-DI-T, V2003-M-BG, V2003-M-T-BG   | 0.20 to 0.35 mm<br>0.0079 to 0.013 in. |
|             |                       | D1703-M, D1803-M, V2203-M, V2403-M, D1703-M-BG, V2203-M-BG, V2403-M-BG  | 0.25 to 0.40 mm<br>0.0099 to 0.015 in. |
|             | Allowable limit       | 1.25 mm<br>0.0492 in.   |  |
| Second ring | Factory specification | D1503-M, D1703-M, D1803-M, V2203-M, V2403-M, D1803-M-DI, V2403-M-DI, D1703-M-BG, V2003-M-BG, V2203-M-BG, V2403-M-BG                         | 0.30 to 0.45 mm<br>0.012 to 0.017 in.  |
|             |                       | V2003-M, V2403-M-T, V2403-M-DI-T, V2003-M-T-BG  | 0.40 to 0.55 mm<br>0.016 to 0.021 in.  |
|             | Allowable limit       | 1.25 mm<br>0.0492 in.   |  |
| Oil ring    | Factory specification | D1503-M, D1703-M, D1803-M, V2003-M, V2203-M, V2403-M, V2403-M-T, V2403-M-DI-T, D1703-M-BG, V2003-M-BG, V2003-M-T-BG, V2203-M-BG, V2403-M-BG | 0.25 to 0.45 mm<br>0.0099 to 0.017 in. |
|             |                       | D1803-M-DI, V2403-M-DI  | 0.20 to 0.40 mm<br>0.0079 to 0.015 in. |
|             | Allowable limit       | 1.25 mm<br>0.0492 in.   |  |

M00000003ENS0134US1



**Clearance between Piston Ring and Groove**

1. Clean the rings and the ring grooves, and install each ring in its groove.
2. Measure the clearance between the ring and the groove with a feeler gauge or depth gauge.
3. If the clearance is more than the allowable limit, replace the piston ring.
4. If the clearance stays more than the allowable limit with new ring, replace the piston also.

|          |                       |                           |   |
|----------|-----------------------|---------------------------|---|
| Top ring | Factory specification | D1803-M-DI,<br>V2403-M-DI | 0.050 to 0.090 mm<br>0.0020 to 0.0035 in. |
|          | Allowable limit       |                           | 0.20 mm<br>0.0079 in.                     |

|             |                       |   |  |
|-------------|-----------------------|---|--|
| Second ring | Factory specification | D1503-M,<br>D1703-M,<br>D1803-M,<br>V2003-M,<br>V2203-M,<br>V2403-M,<br>V2403-M-T,<br>V2403-M-ID-T,<br>D1703-M-BG,<br>V2003-M-BG,<br>V2003-M-T-BG,<br>V2203-M-BG,<br>V2403-M-BG | 0.0930 to 0.128 mm<br>0.00367 to 0.00503 in. |
|             |                       | D1803-M-DI,<br>V2403-M-DI   | 0.0780 to 0.110 mm<br>0.00307 to 0.00433 in. |
|             | Allowable limit       |   | 0.20 mm<br>0.0079 in.                        |




|          |                       |   |  |
|----------|-----------------------|---|--|
| Oil ring | Factory specification | D1503-M,<br>D1703-M,<br>D1803-M,<br>V2003-M,<br>V2203-M,<br>V2403-M,<br>V2403-M-T,<br>V2403-M-DI-T,<br>D1703-M-BG,<br>V2003-M-BG,<br>V2003-M-T-BG,<br>V2203-M-BG,<br>V2403-M-BG | 0.020 to 0.060 mm<br>0.00079 to 0.0023 in. |
|          |                       | D1803-M-DI,<br>V2403-M-DI   | 0.030 to 0.070 mm<br>0.0012 to 0.0027 in.  |
|          | Allowable limit       |   | 0.15 mm<br>0.0059 in.                      |

**(A) D1503-M, D1703-M, D1803-M, V2003-M, V2203-M, V2403-M, V2403-M-T, D1703-M-BG, V2003-M-BG, V2003-M-T-BG, V2203-M-BG, V2403-M-BG**

**(B) D1803-M-DI, V2403-M-DI, V2403-M-DI-T**

M00000003ENS0135US1

### (4) Crankshaft



#### Side Clearance of Crankshaft

1. Set a dial indicator with its point on the end of the crankshaft.
2. Move the crankshaft to the front and rear to measure the side clearance.
3. If the measurement is more than the allowable limit, replace the thrust bearings.
4. If the same dimension bearing is not applicable because of the crankshaft journal wear, replace it with an oversize one. Refer to the table and figure.

|                              |                       |  |
|------------------------------|-----------------------|--|
| Side clearance of crankshaft | Factory specification | 0.15 to 0.31 mm<br>0.0059 to 0.012 in. |
|                              | Allowable limit       | 0.5 mm<br>0.02 in.                     |

#### (Reference)

- Oversize dimensions of crankshaft journal

| Oversize    | 0.2 mm<br>0.008 in.                             | 0.4 mm<br>0.02 in.                              |
|-------------|---|---|
| Dimension A | 54.50 to 54.70 mm<br>2.146 to 2.153 in.         | 54.60 to 54.80 mm<br>2.150 to 2.157 in.         |
| Dimension B | 26.20 to 26.25 mm<br>1.032 to 1.033 in.         | 26.40 to 26.45 mm<br>1.040 to 1.041 in.         |
| Dimension C | 2.8 to 3.2 mm radius<br>0.11 to 0.12 in. radius | 2.8 to 3.2 mm radius<br>0.11 to 0.12 in. radius |

The crankshaft journal must be fine-finished to higher than Rmax = 0.4S



M00000003ENS0136US1

#### Crankshaft Bend

1. Hold the 2 end journals of crankshaft with V blocks on the surface plate.
2. Set a dial indicator with its point on the middle journal.
3. Turn the crankshaft slowly and read the variation on the indicator.
4. If the measurement is more than the allowable limit, replace the crankshaft.

|                 |                 |                       |
|-----------------|-----------------|-----------------------|
| Crankshaft bend | Allowable limit | 0.02 mm<br>0.0008 in. |
|-----------------|-----------------|-----------------------|

M00000003ENS0137US1



**Oil Clearance between Crankpin and Crankpin Bearing**

1. Clean the crankpin and crankpin bearing.
2. Put a strip of plastigauge on the center of the crankpin.
3. Install the connecting rod cap and tighten the connecting rod screws to the specified torque, and remove the cap again.
4. Measure the width that it becomes flat with the scale to get the oil clearance.
5. If the oil clearance is more than the allowable limit, replace the crankpin bearing.
6. If the same dimension bearing is not applicable because of the crankpin wear, replace it with an undersize one. Refer to the table and figure.

**NOTE**

- Do not put the plastigauge into the crankpin oil hole.
- When you tighten the connecting rod screws, do not move the crankshaft.

|   |                       |  |
|---|-----------------------|--|
| Oil clearance between crankpin and crankpin bearing | Factory specification | 0.025 to 0.087 mm<br>0.00099 to 0.0034 in. |
|   | Allowable limit       | 0.20 mm<br>0.0079 in.                      |

|                       |                       |   |
|-----------------------|-----------------------|---|
| Crankpin O.D.         | Factory specification | 46.959 to 46.975 mm<br>1.8488 to 1.8494 in. |
| Crankpin bearing I.D. | Factory specification | 47.000 to 47.046 mm<br>1.8504 to 1.8522 in. |




**(Reference)**

- Undersize dimensions of crankpin


| Undersize    | 0.2 mm<br>0.008 in.                                   | 0.4 mm<br>0.02 in.                                    |
|--------------|---|---|
| Dimension A  | 3.3 to 3.7 mm radius<br>0.13 to 0.14 in. radius       | 3.3 to 3.7 mm radius<br>0.13 to 0.14 in. radius       |
| *Dimension B | 1.0 to 1.5 mm relief<br>0.040 to 0.059 in. relief     | 1.0 to 1.5 mm relief<br>0.040 to 0.059 in. relief     |
| Dimension C  | 46.759 to 46.775 mm dia.<br>1.8409 to 1.8415 in. dia. | 46.559 to 46.575 mm dia.<br>1.8331 to 1.8336 in. dia. |

The crankpin must be fine-finished to higher than Rmax = 0.4S  
 \*Holes to be de-burred and edges rounded with 1.0 to 1.5 mm  
 (0.040 to 0.059 in.) relief.

M0000003ENS0138US1



3TMABAB1P079A



3TMABAB1P080A

**Oil Clearance between Crankshaft Journal and Crankshaft Bearing 1**

1. Measure the O.D. of the crankshaft journal with an external micrometer.
2. Measure the I.D. of the crankshaft bearing 1 with an internal micrometer.
3. Calculate the oil clearance.
4. If the oil clearance is more than the allowable limit, replace the crankshaft bearing 1.
5. If the same dimension bearing is not applicable because of the crankshaft journal wear, replace it with an undersize one. Refer to the table and figure.

|   |                       |  |
|---|-----------------------|--|
| Oil clearance between crankshaft journal and crankshaft bearing 1 | Factory specification | 0.0400 to 0.118 mm<br>0.00158 to 0.00464 in. |
|   | Allowable limit       | 0.20 mm<br>0.0079 in.                        |

|                           |                       |   |
|---------------------------|-----------------------|---|
| Crankshaft journal O.D.   | Factory specification | 59.921 to 59.940 mm<br>2.3591 to 2.3598 in. |
| Crankshaft bearing 1 I.D. | Factory specification | 59.980 to 60.039 mm<br>2.3615 to 2.3637 in. |

**(Reference)**

- Undersize dimensions of crankshaft journal

| Undersize    | 0.2 mm<br>0.008 in.                                   | 0.4 mm<br>0.02 in.                                    |
|--------------|---|---|
| Dimension A  | 2.8 to 3.2 mm radius<br>0.11 to 0.12 in. radius       | 2.8 to 3.2 mm radius<br>0.11 to 0.12 in. radius       |
| *Dimension B | 1.0 to 1.5 mm relief<br>0.040 to 0.059 in. relief     | 1.0 to 1.5 mm relief<br>0.040 to 0.059 in. relief     |
| Dimension C  | 59.721 to 59.740 mm dia.<br>2.3513 to 2.3519 in. dia. | 59.521 to 59.540 mm dia.<br>2.3434 to 2.3440 in. dia. |

The crankshaft journal must be fine-finished to higher than Rmax = 0.4S  
 \*Holes to be de-burred and edges rounded with 1.0 to 1.5 mm (0.040 to 0.059 in.) relief.

M0000003ENS0139US1

**Replacement of Crankshaft Bearing 1**

**(When removing)**

1. Press out the used crankshaft bearing 1 with the replacing tool. (See page "SPECIAL TOOLS".)

**(When installing)**



1. Clean a new crankshaft bearing 1 and crankshaft journal bore, and apply engine oil to them.
2. Make sure that the seam (1) of the new bearing 1 (2) points to the exhaust manifold side (see the figure). Then press fit the new bearing 1 (2) with the replacing tool.

|               |                       |                                       |
|---------------|-----------------------|---------------------------------------|
| Dimension (A) | Factory specification | 4.20 to 4.50 mm<br>0.166 to 0.177 in. |
|---------------|-----------------------|---------------------------------------|

- (1) Seam
- (2) Crankshaft Bearing 1
- (3) Cylinder Block

**(A) Dimension**

M0000003ENS0140US1



**Oil Clearance between Crankshaft Journal and Crankshaft Bearing 2**

1. Put a strip of plastigauge on the center of the journal.
2. Install the bearing case and tighten the bearing case screws 1 to the specified torque, and remove the bearing case again.
3. Measure the width that it becomes flat with the scale to get the oil clearance.
4. If the oil clearance is more than the allowable limit, replace the crankshaft bearing 2.
5. If the same dimension bearing is not applicable because of the crankshaft journal wear, replace it with an undersize one. Refer to the table and figure.

**NOTE**

- When you tighten the bearing case screws, do not move the crankshaft.

|   |                       |  |
|---|-----------------------|--|
| Oil clearance between crankshaft and crankshaft bearing 2 | Factory specification | 0.0400 to 0.104 mm<br>0.00158 to 0.00409 in. |
|   | Allowable limit       | 0.20 mm<br>0.0079 in.                        |

|                           |                       |   |
|---------------------------|-----------------------|---|
| Crankshaft journal O.D.   | Factory specification | 59.921 to 59.940 mm<br>2.3591 to 2.3598 in. |
| Crankshaft bearing 2 I.D. | Factory specification | 59.980 to 60.025 mm<br>2.3615 to 2.3631 in. |



**(Reference)**

- Undersize dimensions of crankshaft journal

| Undersize      | 0.2 mm<br>0.008 in.                                   | 0.4 mm<br>0.02 in.                                    |
|----------------|---|---|
| Dimension A    | 2.8 to 3.2 mm radius<br>0.11 to 0.12 in. radius       | 2.8 to 3.2 mm radius<br>0.11 to 0.12 in. radius       |
| *Dimension B   | 1.0 to 1.5 mm relief<br>0.040 to 0.059 in. relief     | 1.0 to 1.5 mm relief<br>0.040 to 0.059 in. relief     |
| Dimension C, D | 59.721 to 59.740 mm dia.<br>2.3513 to 2.3519 in. dia. | 59.521 to 59.540 mm dia.<br>2.3434 to 2.3440 in. dia. |

The crankshaft journal must be fine-finished to higher than Rmax = 0.4S  
 \*Holes to be de-burred and edges rounded with 1.0 to 1.5 mm  
 (0.040 to 0.059 in.) relief.

M0000003ENS0141US1



### Replacement of Crankshaft Sleeve

1. Remove the used crankshaft sleeve (3).
2. Set the sleeve guide (2) to the crankshaft (5).
3. Set the stopper (1) to the crankshaft (5) (see the figure).
4. Increase the temperature of a new sleeve to between 150 and 200 °C (302 and 392 °F).
5. Install the sleeve to the crankshaft with the auxiliary socket for pushing (4) (see the figure). (Refer to "**SPECIAL TOOLS**".)



#### ■ NOTE

- **Make sure that the large chamfer of the sleeve points to outward.**
- **If the temperature of the sleeve is not enough to install, the sleeve can get a damage when you install.**

- |                       |                                  |
|-----------------------|----------------------------------|
| (1) Stopper           | (4) Auxiliary Socket for Pushing |
| (2) Sleeve Guide      | (5) Crankshaft                   |
| (3) Crankshaft Sleeve |                                  |

M00000003ENS0142US1

## (5) Cylinder



### Cylinder Wear


1. Measure the I.D. of the cylinder at the 6 positions (see figure) with a cylinder gauge.
2. Find the maximum and minimum inner diameters.
3. Find the difference between the maximum and the minimum inner diameters.
4. If the maximum I.D. or the difference is more than the allowable limit, bore and hone it to the oversize dimension. (Refer to "**Cylinder Correction (Oversize)**").
5. Check the cylinder wall for scratches. If you find deep scratches, bore the cylinder. (Refer to "**Cylinder Correction (Oversize)**").

|  |                       |   |   |
|--|-----------------------|---|---|
| Cylinder I.D.                                    | Factory specification | D1503-M<br>V2003-M<br>V2003-M-BG<br>V2003-M-T-BG  | 83.000 to 83.022 mm<br>3.2678 to 3.2685 in. |
|  | Allowable limit       | D1703-M<br>D1803-M<br>V2203-M<br>V2403-M<br>V2403-M-T<br>D1803-M-DI<br>V2403-M-DI<br>V2403-M-DI-T<br>D1703-M-BG<br>V2203-M-BG<br>V2403-M-BG | 87.000 to 87.022 mm<br>3.4252 to 3.4260 in. |
| Difference between maximum I.D. and minimum I.D. |                       | D1503-M<br>V2003-M<br>V2003-M-BG<br>V2003-M-T-BG  | 83.170 mm<br>3.2744 in.                     |
|  | Allowable limit       | D1703-M<br>D1803-M<br>V2203-M<br>V2403-M<br>V2403-M-T<br>D1803-M-DI<br>V2403-M-DI<br>V2403-M-DI-T<br>D1703-M-BG<br>V2203-M-BG<br>V2403-M-BG | 87.170 mm<br>3.4319 in.                     |
| Difference between maximum I.D. and minimum I.D. |                       | Allowable limit   | 0.15 mm<br>0.0059 in.                       |

- (A) Top
- (B) Middle
- (C) Bottom (Skirt)

- (a) Right-angled to Piston Pin
- (b) Piston Pin Direction

M0000003ENS0143US1



**Cylinder Correction (Oversize)**

1. If the cylinder wear is more than the allowable limit, bore and hone it to the specified dimension.

|  |   |   |   |
|--|---|---|---|
| Oversize cylinder I.D.                           | Factory specification                                   | D1503-M, V2003-M, V2003-M-BG, V2003-M-T-BG  | 83.250 to 83.272 mm<br>3.2776 to 3.2784 in. |
|  |   | D1703-M, D1803-M, V2203-M, V2403-M, V2403-M-T, D1803-M-DI, V2403-M-DI, V2403-M-DI-T, D1703-M-BG, V2203-M-BG, V2403-M-BG | 87.250 to 87.272 mm<br>3.4351 to 3.4359 in. |
|  | Allowable limit   | D1503-M, V2003-M, V2003-M-BG, V2003-M-T-BG  | 83.420 mm<br>3.2843 in.                     |
|  |   | D1703-M, D1803-M, V2203-M, V2403-M, V2403-M-T, D1803-M-DI, V2403-M-DI, V2403-M-DI-T, D1703-M-BG, V2203-M-BG, V2403-M-BG | 87.420 mm<br>3.4417 in.                     |
| Difference between maximum I.D. and minimum I.D. | Allowable limit   | 0.15 mm<br>0.0059 in.   |   |
| Finishing  | Hone to 2.2 to 3.0 μmRz<br>(0.000087 to 0.000118 in.Rz) |   |   |

2. Replace the piston and piston rings with oversize ones.  
Oversize : 0.25 mm (0.0098 in.)




■ **NOTE**

- **If the maximum I.D. or the difference for the oversize cylinder is more than the allowable limit, replace the cylinder block with a new one.**

- (1) Cylinder I.D. (Before Correction)      (2) Cylinder I.D. (Oversize)

M00000003ENS0144US1

## (6) Oil Pump



### Rotor Lobe Clearance

1. Measure the clearance between the lobes of the inner rotor and the outer rotor with a feeler gauge.
2. Measure the clearance between the outer rotor and the pump body with a feeler gauge.
3. If the clearance is more than the allowable limit, replace the rotor assembly of the oil pump.

|   |                       |  |
|---|-----------------------|--|
| Clearance between inner rotor and outer rotor | Factory specification | 0.030 to 0.14 mm<br>0.0012 to 0.0055 in. |
|   | Allowable limit       | 0.2 mm<br>0.008 in.                      |

|   |                       |   |
|---|-----------------------|---|
| Clearance between outer rotor and pump body | Factory specification | 0.11 to 0.19 mm<br>0.0044 to 0.0074 in. |
|   | Allowable limit       | 0.25 mm<br>0.0098 in.                   |

M00000003ENS0145US1


### Clearance between Rotor and Cover

1. Put a strip of plastigauge on the rotor face with grease.
2. Install the cover and tighten the screws.
3. Remove the cover carefully.
4. Measure the width that plastigauge becomes flat with the scale to get the oil clearance.
5. If the clearance is more than the allowable limit, replace the rotor assembly of the oil pump.

|   |                       |   |
|---|-----------------------|---|
| Clearance between inner rotor and cover | Factory specification | 0.105 to 0.150 mm<br>0.00414 to 0.00590 in. |
|   | Allowable limit       | 0.20 mm<br>0.008 in.                        |

M00000003ENS0146US1

## (7) Starter






### Overrunning Clutch

1. Check the pinion and if it is worn or damaged, replace the clutch assembly.
2. Check that the pinion turns freely and smoothly in the direction that it overruns. Make sure that it does not slip in the direction that it cranks.
3. If the pinion slips or does not turn in the 2 directions, replace the overrunning clutch assembly.

#### ■ NOTE

- Do not clean off the grease in the overrunning clutch with the chemicals or oils.

M00000003ENS0147US1



**Commutator and Mica**

1. Check the contact of the commutator for wear, and grind the commutator with emery paper if it is lightly worn.
2. Measure the commutator O.D. with an external micrometer at some points.
3. If the minimum O.D. is less than the allowable limit, replace the armature assembly.
4. Calculate the difference of the outer diameters. If it is more than the allowable limit, correct the commutator on a lathe to the factory specification.
5. Measure the mica undercut.
6. If the undercut is less than the allowable limit, correct it with a saw blade and chamfer the segment edges.

|                 |                       |  |                     |
|-----------------|-----------------------|--|---------------------|
| Commutator O.D. | Factory specification | D1503-M,<br>D1703-M,<br>V2003-M,<br>V2203-M,<br>D1803-M-DI,<br>D1703-M-BG,<br>V2003-M-BG,<br>V2003-M-T-BG,<br>V2203-M-BG | 30.0 mm<br>1.18 in. |
|                 |                       | D1803-M,<br>V2403-M,<br>V2403-M-T,<br>V2403-M-DI,<br>V2403-M-DI-T,<br>V2403-M-BG   | 35.0 mm<br>1.38 in. |
|                 | Allowable limit       | D1503-M,<br>D1703-M,<br>V2003-M,<br>V2203-M,<br>D1803-M-DI,<br>D1703-M-BG,<br>V2003-M-BG,<br>V2003-M-T-BG,<br>V2203-M-BG | 29.0 mm<br>1.14 in. |
|                 |                       | D1803-M,<br>V2403-M,<br>V2403-M-T,<br>V2403-M-DI,<br>V2403-M-DI-T,<br>V2403-M-BG   | 34.0 mm<br>1.34 in. |

|                               |                       |                                    |
|-------------------------------|-----------------------|------------------------------------|
| Difference of outer diameters | Factory specification | Less than<br>0.02 mm<br>0.0008 in. |
|                               | Allowable limit       | 0.05 mm<br>0.002 in.               |

**(To be continued)**


(Continued)

|               |                       |  |                                       |
|---------------|-----------------------|--|---------------------------------------|
| Mica undercut | Factory specification | D1503-M,<br>D1703-M,<br>D1803-M,<br>V2003-M,<br>V2203-M,<br>V2403-M,<br>V2403-M-T,<br>D1803-M-DI,<br>V2403-M-DI,<br>V2403-M-DI-T,<br>D1703-M-BG,<br>V2003-M-BG,<br>V2003-M-T-BG,<br>V2203-M-BG | 0.45 to 0.75 mm<br>0.018 to 0.029 in. |
|               |                       | V2403-M-BG   | 0.55 to 0.85 mm<br>0.022 to 0.033 in. |
|               | Allowable limit       |  | 0.20 mm<br>0.0079 in.                 |

- (1) Segment
- (2) Depth of Mica
- (3) Mica

- (a) Correct
- (b) Incorrect

M00000003ENS0148US1




**Brush Wear**

1. If the contact face of the brush is dirty or dusty, clean it with emery paper.
2. Measure the brush length (A) with a vernier caliper.
3. If the length is less than the allowable limit, replace the yoke assembly and brush holder assembly.

|                  |                       |  |                      |
|------------------|-----------------------|--|----------------------|
| Brush length (A) | Factory specification | 15.0 mm<br>0.591 in.   |                      |
|                  | Allowable limit       | D1503-M,<br>D1703-M,<br>V2003-M,<br>V2203-M,<br>D1803-M-DI,<br>D1703-M-BG,<br>V2003-M-BG,<br>V2003-M-T-BG,<br>V2203-M-BG | 11.0 mm<br>0.433 in. |
|                  |                       | D1803-M,<br>V2403-M,<br>V2403-M-T,<br>V2403-M-DI,<br>V2403-M-DI-T  | 9.0 mm<br>0.35 in.   |
|                  |                       | V2403-M-BG   | 12.0 mm<br>0.472 in. |


M00000003ENS0149US1




**Brush Holder**

1. Check the continuity across the brush holder and the holder support with a circuit tester.
2. If electricity flows, replace the brush holder assembly.


M00000003ENS0150US1




3EEAEAC1P048A



3EEAEAC1P049A




3EEABAB1P190A



3EEABAB1P191A

## (8) Alternator



3EEABAB1P192A

### Armature Coil

1. Check the continuity across the commutator and armature coil core with the resistance range of circuit tester.
2. If electricity flows, replace the armature assembly.
3. Check the continuity across the segments of the commutator with the resistance range of circuit tester.
4. If electricity does not flow, replace the armature assembly.

M00000003ENS0151US1

### Field Coil

1. Check the continuity across the lead (1) and brush (2) with a circuit tester.
2. If electricity does not flow, replace the yoke assembly.
3. Check the continuity across the brush (2) and yoke (3) with a circuit tester.
4. If electricity flows, replace the yoke assembly.

(1) Lead  
(2) Brush


(3) Yoke

M00000003ENS0152US1

### Bearing

1. Check that the bearing can turn smoothly.
2. If not, replace it.

M00000003ENS0153US1




**Stator**

1. Measure the resistance across each lead of the stator coil with the resistance range of circuit tester.
2. If the measurement is not in the factory specification, replace the stator assembly.
3. Check the continuity across each stator coil lead and core with the resistance range of circuit tester.
4. If it does not show infinity, replace the stator assembly.

|            |                       |                 |
|------------|-----------------------|-----------------|
| Resistance | Factory specification | Less than 1.0 Ω |
|------------|-----------------------|-----------------|

M00000003ENS0154US1




**Rotor**

1. Measure the resistance across the slip rings.
2. If the resistance is not in the factory specification, replace the rotor assembly.
3. Check the continuity across the slip ring and core with the resistance range of circuit tester.
4. If it does not show infinity, replace the rotor assembly.

|            |                       |       |
|------------|-----------------------|-------|
| Resistance | Factory specification | 2.9 Ω |
|------------|-----------------------|-------|

M00000003ENS0155US1




**Slip Ring**

1. Check the slip ring for score.
2. If there is score, correct with an emery paper or on a lathe.
3. Measure the O.D. of the slip ring with a vernier calipers.
4. If the measurement is less than the allowable limit, replace the rotor assembly.

|                |                       |                      |
|----------------|-----------------------|----------------------|
| Slip ring O.D. | Factory specification | 14.4 mm<br>0.567 in. |
|                | Allowable limit       | 14.0 mm<br>0.551 in. |

M00000003ENS0156US1




**Brush Wear**

1. Measure the brush length with a vernier calipers.
2. If the measurement is less than the allowable limit, replace it.
3. Make sure that the brush moves smoothly.
4. If the brush is defective, replace it.



|              |                       |                      |
|--------------|-----------------------|----------------------|
| Brush length | Factory specification | 10.5 mm<br>0.413 in. |
|              | Allowable limit       | 8.4 mm<br>0.33 in.   |

M00000003ENS0157US1

**Rectifier**

1. Check the continuity across each diode of rectifier with the resistance range of circuit tester.
2. The rectifier is correct if the diode in the rectifier conducts electricity only in one direction.

M00000003ENS0158US1

**IC Regulator**

1. Check the continuity across the **B** terminal (2) and the **F** terminal (1) of IC regulator with the resistance range of circuit tester.
2. The IC regulator is correct if it conducts electricity only in one direction.

(1) **F** Terminal(2) **B** Terminal

M00000003ENS0159US1

---

**Editor** : Farm and Industrial Machinery International Service Department  
**Address** : 64, Ishizu-Kitamachi, Sakai-Ku, Sakai-City, Osaka, 590-0823, Japan  
**Phone** : +81-72-241-1129  
**Fax** : +81-72-245-2484  
**E-mail** : ks\_g.ksos-pub@kubota.com

---