ENGLISH VERSION

**WARNING!**

**Read this Operator's Manual carefully before using this machine. Failure to understand and follow the contents of this manual may result in electrical shock, fire and/or serious personal injury.**

**READ CAREFULLY**

HIGH PRESSURE CLEANERS

# SENATOR™ G2

## HIGH PRESSURE WATER CLEANER


**Register Your Product**


Cold Water  Petrol Driven

| **Record Serial Number below and retain product serial number which is located on nameplate.** | |
|---|---|
| UNIT SERIAL NO. | |
| ENGINE SERIAL NO. | |
| PURCHASE DATE | |





SHOWN WITH OPTIONAL TROLLEY KIT



18
19
20
17
16
23
22
5
21
6
15
7
1
2
3
4
8
9
10
11
12
13
14
24
25



26
27
30
28
29
32
31


## Senator G2 (Honda)

1. Engine
2. Unloader Valve
3. High Pressure Outlet (connection to hose coupling)
4. Low Pressure Inlet (for tap connection)
5. Pressure Gauge
6. Emergency Stop
7. Battery Isolator
8. Fuel Fill Point
9. Hand Wash/ Tank Drain
10. Forklift Pockets/Mounting Points
11. Engine Starting System
12. Fuel Tank
13. Anti-Vibration Plate
14. Gearbox
15. Heat Shield
16. Hose Reel Mounting Plate
17. Heat Shield
18. Water Tank
19. Water Tank Lid
20. Water Tank Breather
21. Engine Oil Dipstick
22. Stainless Steel Exoskeleton
23. (Optional) Top Lifting Points
24. Pump Oil Site Glass
25. Pump Oil Dipstick
26. Engine Fuel Filter
27. Gun/Lance Holder
28. JW Triplex Pump
29. Battery
30. Water Inlet Filter
31. Gearbox Oil Site Glass
32. Gearbox Oil Breather












## Standard Equipment


1. J5500K High Pressure Spray Gun
2. J5500K Quick Front Lance Coupling
3. High Pressure Hose Connection
4. Gun Lock Out
5. J5500K LTF Spray Gun Trigger
6. JW Lance with insulation
7. 1/4” Snap Coupling
8. Lance Connection Tail
9. High Pressure Stainless Steel Nozzle
10. 1/4” Snap Tail and Nozzle Protector
11. High Pressure Hose assembly
12. Screw coupling connectors



18
19
20
17
16
23
22
5
21
6
15
7
1
2
3
4
8
9
10
11
12
13
14
24
25



26
27
30
28
29
32
31


## Senator G2 (JX 750)

1. Engine
2. Unloader Valve
3. High Pressure Outlet (connection to hose coupling)
4. Low Pressure Inlet (for tap connection)
5. Pressure Gauge
6. Emergency Stop
7. Battery Isolator
8. Fuel Fill Point
9. Hand Wash/ Tank Drain
10. Forklift Pockets/Mounting Points
11. Engine Starting System
12. Fuel Tank
13. Anti-Vibration Plate
14. Gearbox
15. Heat Shield
16. Hose Reel Mounting Plate
17. Heat Shield
18. Water Tank
19. Water Tank Lid
20. Water Tank Breather
21. Engine Oil Dipstick
22. Stainless Steel Exoskeleton
23. (Optional) Top Lifting Points
24. Pump Oil Site Glass
25. Pump Oil Dipstick
26. Engine Fuel Filter
27. Gun/Lance Holder
28. JW Triplex Pump
29. Battery
30. Water Inlet Filter
31. Gearbox Oil Site Glass
32. Gearbox Oil Breather




## Standard Equipment

1. J5500K High Pressure Spray Gun
2. J5500K Quick Front Lance Coupling
3. High Pressure Hose Connection
4. Gun Lock Out
5. J5500K LTF Spray Gun Trigger
6. JW Lance with insulation
7. 1/4” Snap Coupling
8. Lance Connection Tail
9. High Pressure Stainless Steel Nozzle
10. 1/4” Snap Tail and Nozzle Protector
11. High Pressure Hose assembly
12. Screw coupling connectors

**Table of Contents** **4**
Safety Symbols 5

**General Safety Rules** **6**
Work Area Safety 6
Personal Safety 6
Pressure Cleaner Use & Care 6
Service 6

**High Pressure Cleaning Safety** **6**

**Description, Specifications And Standard Equipment** **7**
Description 7
Specifications 7
Standard Equipment 7

**Machine Assembly & Operation** **8**
Engine Oil 8
Pump/Gearbox Oil 8
Wheels 8

**Pre-Operation Inspection** **8**

**Machine and Work Area Set-Up** **9-10**
Water Supply 10
Hose Setup 10

**Operating Instructions** **10-12**
Pressure Washer Operation 11
Machine Shut Down 11
Hose Reel Brake Adjustment 12
Transportation and Storage 12

**Maintenance Instructions** **12-13**
Cleaning 12
Engine 12
Battery 13
Pump Lubrication/Maintenance 13
Gearbox Lubrication 13
Preparing Pump for Cold Weather Storage 13
Machine Storage 13

**Service And Repair** **14**
Disposal 14
Machine Data Points 15
Honda Engine Maintenance Schedule 16-17
High Pressure Cleaner Maintenance Schedule 18-19
Maintenance Log 19
Troubleshooting 20

*Original Instructions - English

**Safety Symbols**

In this operator's manual and on the product, safety symbols and signal words are used to communicate important safety information. This section is provided to improve understanding of these signal words and symbols.



This is the safety alert symbol. It is used to alert you to potential personal injury hazards. Obey all safety messages that follow this symbol to avoid possible injury or death.

**DANGER** indicates a hazardous situation which, if not avoided, will result in death or serious injury.
**WARNING** indicates a hazardous situation which, if not avoided, could result in death or serious injury.
**CAUTION** indicates a hazardous situation which, if not avoided, could result in minor or moderate injury.
**NOTICE** indicates information that relates to the protection NOTICE of property.



This symbol means read the operator's manual carefully before using the equipment to reduce the risk of injury. The operator's manual contains important information on the safe and proper operation of the equipment



This symbol means according to applicable regulations the machine must not be connected to a drinking/potable water supply without a system separator per EN 12729 Type BA. Water flowing through a system separator is considered non drinkable



This symbol indicates that high pressure jets can be dangerous if improperly used the jet must not be directed at persons animals, live electrical equipment or at the appliance itself.



This symbol indicates the risk of fire and explosion from gasoline or other sources causing burns and other injury.



This symbol indicates the risk of breathing carbon monoxide and causing nausea, fainting or death. Risk of poisoning do not breathe in exhaust fumes.



This symbol indicates the risk of loud noises from the machine, causing a risk to hearing impairment, always use proper ear protection, while working with the machine.



This symbol means always wear safety glasses with side shields or goggles when handling or using this equipment to reduce the risk of eye injury.



This symbol indicates the risk of high pressure water directed at body parts, causing skin puncture and injection injuries.



These symbols indicate a risk of burns and hot surfaces, be aware of hot components.

# General Safety Rules

**⚠ WARNING**

**Read and understand all instructions. Failure to follow all instructions listed below may result in electric shock, fire, and/or serious injury.**

**SAVE THESE INSTRUCTIONS!**

## Work Area Safety

- Keep work area clean and well lit.
- Keep bystanders, children, and visitors away while operating a pressure cleaner. Distractions can cause you to lose control.

## Personal Safety

- Stay alert, watch what you are doing and use common sense when operating a pressure cleaner. Do not use a pressure cleaner while you are tired or under the influence of drugs, alcohol, or medication. A moment of inattention while operating pressure cleaners may result in serious personal injury.
- Dress properly. Do not wear loose clothing.
- Contain long hair. Keep your hair, clothing and gloves away from moving parts. Loose clothes, or long hair can be caught in moving parts.
- Do not overreach. Keep proper footing and balance at all times. This enables better control of the pressure cleaner in unexpected situations.
- Use safety equipment. Always wear eye protection.
- Dust mask, non-skid safety shoes, hard hat, or hearing protection must be used for appropriate conditions will reduce personal injuries.

## Pressure Cleaner Use and Care

- Do not force the pressure cleaner.
- Store idle pressure cleaners out of the reach of children and other untrained persons. Pressure cleaners are dangerous in the hands of untrained users.
- Maintain pressure cleaners with care.
- Check for misalignment or binding of moving parts, breakage of parts and any other condition that may affect the pressure cleaners operation. If damaged, have the pressure cleaner serviced before using. Many accidents are caused by poorly maintained pressure cleaners.

Use only accessories that are recommended by the manufacturer for your model and pressure & flow rated accordingly.

## Service

- Pressure cleaner service must be performed only by qualified repair personnel. Service or maintenance performed by unqualified personnel could result in a risk of injury.
- When servicing a pressure cleaner, use only genuine replacement parts. Follow instructions in the Maintenance section of this manual. Use of unauthorized parts or failure to follow Maintenance Instructions may create a risk of electrical shock or injury.

# High Pressure Cleaning Safety

**⚠ WARNING**

**This section contains important safety information that is specific to this pressure cleaner.**

**Read these precautions carefully before using this High Pressure Cleaning Machine to reduce the risk of electrical shock or other serious injury.**

**SAVE ALL WARNINGS AND INSTRUCTIONS FOR FUTURE REFERENCE!**

Keep this manual with machine for use by the operator.

- Never operate the unit without a pressure control mechanism Hoses can whip, causing striking injuries and spray can penetrate skin and cause serious injury.
- High pressure water can inject under skin resulting in serious injury including amputation. Do not direct spray at people or animals.
- Do not operate unit above the rated working pressure or 60°C (inlet water temperature). This increases the risk of injury, including burns, and damage to the unit.
- One person must control the high pressure cleaning process and water flow.
- Always use appropriate personal protective equipment while handling and using high pressure cleaning equipment. Appropriate personal protective equipment (PPE) includes safety glasses and gloves, and may also include equipment such as latex or rubber gloves, face shields, goggles, protective clothing, respirators, head protection, hearing protection and steel toed footwear.
- Do not eat or smoke while operating or handling high pressure cleaning equipment. This will help prevent contamination with toxic or infectious material.
- Do not spray toxic or flammable liquids. This will reduce the risk of burns, fire, explosion or other injury.

- Gasoline and its vapors are highly flammable and explosive. See engine manual for precautions to reduce the risk of burns, explosions and serious injury while handling and using gasoline.
- Engines produce carbon monoxide, a colorless, odorless poison gas. Breathing carbon monoxide can cause nausea, fainting or death. Do not start and run engine in an enclosed area, even if doors and windows are open. Only operate outside.
- Never attempt to refuel the unit whilst engine is running. Do not spill fuel on or near exhaust take extra care in the refueling process as vapors or liquid can combust due to heat.
- Hot surfaces can cause burns and fire. Keep body parts and flammable material away from hot surfaces.
- Read and understand this manual, the engine manual and the warnings and instructions for all equipment and material being used with this tool before operating. Failure to follow all warnings and instructions may result in property damage and/or serious injury.
- Follow all applicable workplace health and safety regulations and guidelines concerning the use of this equipment.
- Read and understand Australia/New Zealand standard AS/NZS4233.1 High Pressure Systems Part 1: Safe Operation & Maintenance.

If you have any question concerning this Jetwave® product:

– Contact your local Jetwave® distributor.

– Visit jetwave.com.au/find-a-dealer to find your local Jetwave contact point.

# Description, Specifications and Standard equipment

## Description

The Jetwave® Senator™ G2 engine powered High Pressure Cleaner is a portable unit designed to use a combination of water pressure and flow to clean different surfaces from dirt, grease, & grime. Water is pumped through the high pressure plunger pump at increased pressure and flow allowing water to be used at such high pressure to remove dirt and grime from surfaces. The Senator™ G2 High Pressure Cleaner is equipped with a gasoline HONDA™ engine to drive the triplex plunger pump.




**Figure.1 - Machine Serial Number**




**Figure.2 - Senator G2 Cold Water Petrol High Pressure Cleaner**

JETWAVE GROUP

IPX5

| | |
|---|---|
| **Model** | Senator™ G2FI 280-31 |
| **Motor** | Honda™ iGX800 |
| **Power** | 24.9HP / 18.6kW |
| **Max Pressure (P)** | 280 BAR / 4060 PSI / 28 MPa |
| **Max Flow Rate (Q)** | 31 L/PM / 1860 PH |
| **Max Inlet Temperature (T)** | 50° / 122° F |
| **Pump** | JW Junior™ Triplex Plunger |
| **Pump RPM** | 1450 RPM |
| **Inlet Pressure Min / Max** | 0.3-7 BAR / 5-100 PSI / 0.03-0.7 MPa |
| **Nozzle Size** | 08 |
| **Weight** | 155 KG |
| **Manufacture Year** | 2023 |

Jetwave Group Pty Ltd
10-16 Smith Street, Thebarton 5031 SA Australia

MADE IN AUSTRALIA

SAMPLE ONLY

**Figure.3 - Senator G2 Data Plate**

## Standard equipment

A Jetwave Senator™ G2 High Pressure Cleaner comes with:

- High Pressure JW Gun
- Straight single JW Lance
- 15m of DWB 3/8" high pressure hose
- JW Easy Foamer (up to 280 BAR)
- Engine Operator's Manual
- Operator's Manual
- (Optional) Trolley Kit
- (Optional) Hose Reel

See the Jetwave® catalogue for specific equipment supplied with each catalogue number.

The machine serial number is located on the frame. The first letter & digits indicate the year and month of the manufacture. (G = 2021 (Year), 4 = April (Month)).

NOTICE This machine is made high pressure water clean. If properly used it should not damage a surfaces that is in good condition and properly designed, constructed and maintained. If the surface is in poor condition or not properly designed, constructed or maintained, the water cleaning process may not be effective or could cause damage to the surface. The best way to determine the condition of a surface before cleaning is through visual inspection. Improper use of this pressure cleaner can damage the unit and the surface. This machine may not clear all substrate debris.

## Machine Assembly

**⚠ WARNING**

**To prevent serious injury during use and prevent machine damage, follow these procedures for proper assembly.**

### Engine Oil

NOTICE: The unit is shipped with oil in the engine. Operating the engine with low or no oil will result in engine failure. See supplied engine operator's manual for specific information on checking oil, adding oil and oil selection.

### Pump/Gearbox Oil

The unit is shipped with oil in the pump and gearbox. Check oil level (ensure half way on sight-glasses) per Maintenance section.

### Wheels

(Optional Wheel Kit) To assemble the wheels, slide axles through axle location hole, slide wheels on each side find centerline and proceed to install locking collar each side with 4mm allen key tool, refer to instructions.

## Pre-Operation Inspection

**⚠ WARNING**



**Before each use, inspect your pressure cleaner and correct any problems to reduce the risk of serious injury from high pressure water and other causes and prevent unit damage. Always wear appropriate safety equipment, when inspecting your unit.**

1. Make sure that the battery isolator and engine switch is in the OFF position.

2. Clean any oil, grease or dirt from the equipment, including the handles and controls. This aids inspection and helps prevent the machine or control from slipping from your grip.

3. Inspect the high pressure cleaner and accessories for the following:
   - Proper assembly and completeness.
   - Broken, worn, missing, misaligned, binding or loose parts.
   - Presence and readability of the warning labels. (See Figure 4A.)
   - Any other condition which may prevent the safe and normal operation.

If any problems are found, do not use the unit until the problems are corrected.




**Figure.4A - Senator G2 Warning Labels**



**Figure.4B - Senator G2 Fuel Level Gauge**

Clean water filter (Figure 5). Using the drain valve, drain the tank. Unscrew the clear plastic bowl cover anti-clockwise and remove and clean the mesh filter (note: ensure the o-ring is set back into place before screwing plastic bowl back on). Dirt and debris can restrict the water flow to the pump and cause performance issues.




**Figure.5 - Senator G2 Water Filter**

4. Inspect the pressure cleaner nozzle orifices for any damage or blockage. Blockages can be cleaned with a nozzle cleaning tool. Use care not to enlarge nozzle orifices while cleaning. Damaged nozzles or nozzles with enlarged orifices can decrease unit performance and should be replaced.

5. Inspect the hoses, connectors and fittings for wear and damage. If there are any kinks, cracks, breaks or wear through the outer jacket of the hose or other damage, do not use the hose. Damaged hoses can burst or leak high pressure water and cause serious injury. Replacement hoses and fitting should be rated at or higher than the unit pressure rating.

6. Inspect and maintain the engine per the engine operator's manual.

7. Check engine fuel level (Figure 4B). If needed, add unleaded gasoline. See engine operator's manual for requirements. Use caution when handling gasoline. Work in a well ventilated area. Never fill the tank while unit is running, do not overfill tank and do not spill fuel. Make sure tank cap is securely closed.

8. Check the oil level(s) in the pump and gearbox through the sight glass and add oil if needed (see Maintenance Instructions section). Inspect Engine as directed in the engine operator's manual.

# Machine and Work Area Set-up

**⚠ WARNING**



**Always wear safety glasses, gloves and other appropriate protective equipment when setting up your pressure cleaner. Rubber soled, non-slip shoes can help prevent slipping on wet surfaces.**
**Engines produce carbon monoxide, a colorless, odorless poison gas. Breathing carbon monoxide can cause nausea, fainting or death. Do not start and run engine in an enclosed area, even if doors and windows are open. Only operate outside.**

**Set-up the unit and work area according to these procedures to reduce the risk of injury from high pressure water, chemical burns, infections, carbon monoxide and other causes, and prevent unit damage.**

1. Check work area for:
   - Adequate lighting.
   - Flammable liquids, vapors or dust that may ignite. If present, do not work in area until sources have been identified and corrected. The machine is not explosion proof and can cause sparks.
   - Clear, level, stable dry place for machine and operator.
   - If needed, remove the water from the work area. Wood or other coverings may need to be put down.
   - Unit location that is in a well ventilated outdoor area. Do not place the unit indoors, even with doors and windows open. Unit can be located remotely from the point of use.
   - Suitable water supply. Clear path to transport the unit to the set up location.
2. Inspect the surface to be cleaned, and make sure no materials or elements are in the way of the unit.
3. Determine the correct equipment for the application.
4. Make sure all equipment has been properly inspected.
5. Evaluate the work area and determine if any barriers are needed to keep bystanders away. Bystanders can distract the operator. If working near traffic, erect cones, signs or other barriers to alert drivers.
6. Take the unit to the well-ventilated outdoor work area along the clear path. See Transportation Section. Be aware of possible slip hazards. Wear appropriate footwear to help prevent slips.

## Water Supply



**WARNING:** This high pressure cleaner is only allowed to be connected with the drinking water mains, when an appropriate backflow preventer has been installed, as per AS/NZS 60335.2.79. Follow all local standards and regulations applicable to water connection.

According to the applicable regulation, the appliance must never be used on the drinking water supply without a system separator. Use a suitable system separator as per EN 12729 Type BA. Water flowing through a system separator is considered non-drinkable

Run a hose from the water source to the unit water inlet. Use the largest diameter, shortest length hose possible. A 3/4" I.D. Inlet hose is the minimum recommended size.

Dirt and debris in the water supply can cause excess pump wear, clog the unit filter, nozzles and reduce performance.

Do not use water from ponds, lakes or other sources that may be contaminated.

Fill the water tank prior to starting the unit.

The water tank is equipped with a:

- Low water level shut-off to prevent pump damage from insufficient water. This will shut OFF the engine when the tank water level falls below a predetermined level.
- Float valve to shut-off inlet water when the tank is full, preventing water spillage through the tank vent.

Warm water can be used for improved cleaning. Do not use water hotter than 60°C. When using warm water, use appropriate personal protective equipment to reduce the risk of burns.

When using in cold weather, use precautions to prevent water from freezing in the pump. This can damage the pump.




**Figure.6 - Senator G2 Onboard Water & Bypass Tank**

## Hose Set-Up

Use care when routing hoses. Routing hoses over rough surfaces, sharp edges, crossing hoses, etc. can damage the hose jacket. Keeping the unit hose on the reel(s) will help to minimize hose damage.

# Operating Instructions




**Always wear eye protection to protect your eyes against dirt and other foreign objects. Always wear appropriate personal protective equipment for the work environment.**

**Never operate the unit without the hose attached to a spray gun. Hose can whip, causing striking injuries and spray can penetrate skin and cause serious injury.**

**High pressure fluid can inject under skin resulting in serious injury, including amputation. do not direct spray at people or animals. do not operate unit above pressure rating or 60°C (inlet water temperature). This increases the risk of injury, including burns, and damage to the unit. One person must control the unit process and water flow.**

**Always use appropriate personal protective equipment while handling and using high pressure cleaning equipment. Appropriate personal protective equipment always includes safety glasses and gloves, and may also include equipment such as latex or rubber gloves, face shields, goggles, protective clothing, respirators, and steel toed footwear.**

**Follow operating instructions to reduce the risk of injury from whipping hoses, high pressure liquid injection, carbon monoxide and other causes.**

1. Make sure that machine and work area is properly set up and that the work area is free of bystanders and other distractions. If the unit is located remotely from the point of use, another person may be located at the unit.
2. Attach the gun to the high pressure hose via coupling system.
3. Attach the hose to the high pressure outlet on the front of the unit.
4. Turn the battery isolator switch ON (Figure 7) and confirm the Emergency Stop button is in the out position (rotate button clockwise).




**Figure.7 - Emergency Stop & Battery Isolator**

5. Attach your water supply hose to the low pressure water inlet port on the front of the machine. Confirm that the water supply is turned on. Never start the engine without the water supply turned ON. This can damage the pump.
6. Ensure fuel valve is in the OPEN position before starting the machine. When not in use CLOSE the fuel valve as pictured (Figure 8).







**Figure.8 - Fuel Valve Position**

7. Wash Wand Lock Out – the wash wand includes a lock out on the back of the trigger. Flip the lock out down to prevent the operation of the trigger when the wash wand is not in use.
8. Turn the engine switch to the START position, and hold it there until the engine starts. When the engine starts, release the engine switch, allowing it to return to the ON position.




**NOTE:**
- If the engine fails to start within 5 seconds, release the engine switch and wait at least 10 seconds before operating the starter again.
- Using the electric starter for more than 5 seconds at a time will overheat the starter motor and can damage it.

9. **COLD START HONDA GX690**
To start a cold engine, pull the choke knob to the CLOSED position and follow the regular engine start procedure. After engine start, warm up the engine for 2 or 3 minutes, gradually pushing the choke knob to the OPEN position as the engine warms up.





10. **(iGX Engines Only)**: the Honda iGX700/800 is an EFI auto throttle engine with auto choke. Engine will automatically idle down the revs when the trigger is closed on the gun and will automatically rev up when the trigger on the gun is open.
8. If applicable; turn the unloader valve while monitoring the pressure gauge to adjust the pressure as desired. Do not exceed the machine pressure rating.
9. When pressure washing use both hands to grip and direct the gun & lance for greater control. Never direct the gun & lance at people. High pressure fluid can inject under skin resulting in serious injury. Never direct gun & lance at electrical equipment or wiring to reduce the risk of electrical shock. Use care when using the pressure washer. Holding the nozzle too close to a surface can damage it. Test a small, inconspicuous area to confirm the settings work as desired.

10. **COLD START JX750**
To start a cold engine, pull the choke knob OUT and follow the regular engine start procedure. After engine start, warm up the engine for 2 or 3 minutes, gradually pushing the choke knob back into position as the engine warms up, adjust throttle as neccesary.

## Machine Shut Down Procedure

1. When high pressure cleaning task is complete, release high pressure gun trigger.
2. Return to the unit controls.
3. Idle down unit RPMs via throttle control (if applicable)
4. Turn the engine switch to the OFF position




5. Release system back pressure by pressing the trigger on the spray gun.
6. Turn water supply OFF.
7. Disconnect high and low pressure hoses and coil the assembly for safety and proper storage.




**Figure 9. High pressure outlet sticker**




**Figure 10. Low pressure inlet sticker**

## Optional Hose Reel - Brake Adjustment

The primary hose reel is equipped with an adjustable brake to prevent the hose from over spooling off the reel under its own weight. Tightening nut (7mm spanner) increases the drag on the reel, loosening decreases the drag. Adjust as desired. (to resist hose over spooling off reel) (Figure 11). To apply tension brake, grab and pull the black switch to engage brake.





**Figure.11 - Brake Adjustment & Locking Pin**

## Transportation and Storage

1. Turn off the fuel valve and the battery isolation switch.
2. Drain water from unit as needed.
3. Coil hoses and secure equipment appropriately. All loose material must be removed.
4. Unit weighs 155 KGS (approx.) Use appropriate equipment and methods to load and transport.

## Maintenance Instructions

**⚠ WARNING**

**Before performing any maintenance, engine switch battery isolation switch should be in OFF position to prevent inadvertent operation. Open water control valve to release any fluid pressure in system.**

**Always wear safety glasses and gloves when performing any maintenance to help protect against drain chemicals and bacteria.**

## Cleaning

The hose should be cleaned as needed with hot, soapy water and/or disinfectants. Do not allow water to enter the engine or electrical system. Do not clean with pressure washer. Wipe the unit down with a damp cloth.

## Engine

Maintain the engine as directed in the engine operator's manual supplied with the unit. An hour meter is included on the engine to monitor pressure cleaners use.

## Battery

**NOTE!**
Connect negative terminal to black negative post, as unit is shipped disconnected. (if applicable)

**Safety notes regarding the battery**
Please observe the following warning notes when handling batteries.


Observe the directions on the battery, in the instructions for use and in the vehicle operating instructions.


Wear an eye shield


Keep away children from acid and batteries.


Fire, sparks, open light and smoking not allowed.


Danger of causticization


First aid.


Warning note.


Disposal.


Do not throw the battery into the bin.

**Danger**

Risk of injury! Ensure that wounds never come into contact with lead. Always clean your hands after having worked with batteries.

To change battery (if applicable)

1. Unclip strap (if applicable) holding battery box top on, remove top.
2. Disconnect ground (-) cable connection first, followed by positive (+) cable connection.
3. Remove battery.
4. Reverse procedure to install.

Note: Before removing the battery, make sure the negative pole lead is disconnected. Check that the battery pole and pole terminals are adequately protected with pole grease.

Replacement batteries should have the following specifications:

- Size (L x W x H): 176 x 90 x 154 (mm)
- Voltage: 12v
- Cold Cranking Amps (CCA): 310
- 18 Ah
- Terminal Type: Standard - +
- Type: AGM with Acid Pack

## Pump Lubrication/Maintenance

Check the pump oil level prior to each use. Place the unit on a level surface. Wipe any dirt and debris from the area of the dipstick and sight-glass. Oil level should be at the middle of the sight-glass (Figure 12). If needed, remove the dipstick and add SAE 15W-40 Mineral non-detergent oil, fill to half-way on the sight-glass. Do not overfill, reinstall dipstick.





**Figure.12 - Checking Pump and Gearbox Oil Level**

Change oil in pump after first 50 hours of operation and every 250 hours of operation after that, refer to maintenance schedule section. With the pump warm from operation, remove plug on bottom of pump and drain oil into suitable container. Replace plug. Fill to approximately half-way on the sight-glass with SAE 15W-40 Mineral non-detergent oil using the checking procedure.

At 1000 hours of use (less in severe use conditions) the Senator G2 should be taken to a Jetwave Independent Service Center for pump seal and valve service.

## Gearbox Lubrication

Check the gearbox oil level prior to each use. Place the unit on a level surface. Wipe any dirt and debris from the area of the dipstick and sight-glass (Figure 12). Oil level should be at the middle of the sight-glass. If needed, remove the dipstick and add SAE 85W-140 gear lubricant oil, fill to half-way on the sight-glass. Do not overfill, reinstall dipstick.

Change oil in gearbox every 500 hours of operation. With the gearbox warm from operation, remove plug on bottom of gearbox and drain oil into suitable container. Replace plug. Fill to half-way on the sight-glass with SAE 85W-140 gear lubricant oil.


## Preparing Pump for Cold Weather Storage

If the unit will be stored under conditions where the temperature is near or below 0°C, the unit must be properly prepared. If water freezes in the pump, it can damage it.


After the tank is drained (if applicable), remove the hose from the water inlet. Open all valves in the system and use compressed air to force any water out of the system also flush device with anti-freezing agent to prevent freezing during cold weather storage.

## Machine Storage


Store the unit in a well ventilated area protected from the weather elements. Keep the machine in a locked area that is out of reach of children and people unfamiliar with High Pressure Cleaners. This machine can cause serious injury in the hands of untrained users. See Maintenance section for information on cold weather storage. See engine operator's manual for specific information on engine storage.




**Honda Check Oil Level**



**JX 750 Check Oil Level**



## Service And Repair

**⚠ WARNING**

**Improper service or repair can make machine unsafe to operate.**

The “Maintenance Instructions” will take care of most of the service needs of this machine. Any problems not addressed by this section should only be handled by an authorized Jetwave service technician.


High Pressure Cleaner should be taken to a Jetwave Independent Service Center or returned to the factory.

For information on your nearest Jetwave Independent Service Center or any service or repair questions:

- Contact your local Jetwave distributor.
- Visit jetwavegroup.com.au/find-a-dealer/ to find your local Jetwave contact point.
- Contact Jetwave Technical Service Department at service@jetwave.com.au or call (08) 8371 3599

## Disposal / Environmental Protection

Parts of the High Pressure Cleaner contain valuable materials and can be recycled. There are companies that specialize in recycling that may be found locally. Dispose of the components in compliance with all applicable regulations. Contact your local waste management authority for more information.



Please do not release engine oil, pump & gearbox oil, diesel and petrol into the environment. Protect the ground and dispose of used oil in an environmentally-clean manner.



The packaging material can be recycled. Please do not throw the packaging material into household waste; please send it for recycling

## Declaration of Conformity

We hereby declare that the machine described below complies with the relevant basic safety and health requirements of the EU Directives listed below, both in its basic design and construction as well as in the version put into circulation by us. This declaration shall cease to be valid if the machine is modified without our prior approval

**Product:** High pressure cleaner

**Trade Name:** Senator G2

**Relevant EU Directives**
2006/42/EC
2000/14/EC

**Relevant AS/NZS Directives**
60335.5.2.79
4233.1:2013
4233.2:2013

**Applied standards**
EN 1829 -2

**Applied conformity evaluation method**
2000/14/EC: Appendix V
**Sound power level dB(A)**
**Senator G2**
Measured: 105
Guaranteed: 107

The signatories act on behalf of and with the authority of the company management.



L. Seco
Business Director

Jetwave Group Pty Ltd
10-16 Smith Street, Thebarton 5031 SA, Australia
Tel: +61 8 8371 3599
Fax: +61 8 8371 4497
ACN: 056 759 892

| Type | | Senator G2 280-21 | Senator G2 280-26 | Senator G2 350-23 | Senator G2 280-31 |
|---|---|---|---|---|---|
| **Code** | | CW4000-21PEG2 | CW4000-26PEG2 | CW5000-23PEG2 | CW4000-31PEG2FI |
| **Motor** | | | | | |
| Honda Petrol Engine | | GX690, 2 cylinder, 4-stroke OHV | GX690, 2 cylinder, 4-stroke OHV | GX690, 2 cylinder, 4-stroke OHV | iGX800, 2 cylinder, 4-stroke OHV |
| Maximum torque at 3600rpm | kW/HP | 16.5 / 22.1 | 16.5 / 22.1 | 16.5 / 22.1 | 18.6 / 24.9 |
| Operating Speed (Under Load) | RPM | 3200 | 3200 | 3200 | 3200 |
| Fuel Tank | L | 25 | 25 | 25 | 25 |
| Fuel | Type | Petrol, unleaded | Petrol, unleaded | Petrol, unleaded | Petrol, unleaded |
| Battery | V / Ah / CCA | 12 / 18 / 310 | 12 / 18 / 310 | 12 / 18 / 310 | 12 / 18 / 310 |
| **Water Connection** | | | | | |
| Max feed temperature | °C / F | 60 / 140 | 60 / 140 | 60 / 140 | 60 / 140 |
| Min feed volume | l/m (l/h) | 22 / 1320 | 27 / 1620 | 24 / 1440 | 32 / 1920 |
| Max feed pressure | PSI (bar) MPa | 101 / (7) / 0.7 | 101 / (7) / 0.7 | 101 / (7) / 0.7 | 101 / (7) / 0.7 |
| Min feed pressure | PSI (bar) MPa | 4.35 / (0.3) / 0.03 | 4.35 / (0.3) / 0.03 | 4.35 / (0.3) / 0.03 | 4.35 / (0.3) / 0.03 |
| Inlet hose diameter (min.) | Inch / mm | 3/4" / 19mm | 3/4" / 19mm | 3/4" / 19mm | 3/4" / 19mm |
| **Performance Data** | | | | | |
| Working pressure | PSI (bar) MPa | 4060 (280) 28 | 4060 (280) 28 | 5075 (350) 35 | 4060 (280) 28 |
| Max excess operating pressure (safety valve) | PSI (bar) MPa | 5075 (350) 35 | 5075 (350) 35 | 5650 (390) 39 | 5075 (350) 35 |
| Flow rate | l/m (l/h) | 21 / 1260 | 26 / 1560 | 23 / 1380 | 31 / 1860 |
| Nozzle Size | | 05 | 065 | 05 | 08 |
| Type of protection | IP | IPX5 | IPX5 | IPX5 | IPX5 |
| **Oil** | | | | | |
| Pump oil quantity/type | mL | 1040 / SAE 15W-40 | 1040 / SAE 15W-40 | 1040 / SAE 15W-40 | 1040 / SAE 15W-40 |
| Gear oil quantity/type | mL | 320 / 85W-140 | 320 / 85W-140 | 320 / 85W-140 | 320 / 85W-140 |
| Engine oil quantity/type | mL | 1500 / 10W30 | 1500 / 10W30 | 1500 / 10W30 | 1500 / 10W30 |
| **Dimensions & Weight** | | | | | |
| Length x Width x Height | mm | 860 x 550 x 870 | 860 x 550 x 870 | 860 x 550 x 870 | 860 x 550 x 870 |
| Typical operating weight | kg | 150 | 150 | 150 | 150 |
| **Values Determined as per AS/NZS 60335.2.79** | | | | | |
| Max reaction/recoil force of trigger gun | N | 82 | 102 | 100 | 121 |
| Hand spray gun | $m/s^2$ | - | - | - | - |
| Spray lance | $m/s^2$ | - | - | - | - |
| Uncertainty K | $m/s^2$ | - | - | - | - |
| Sound pressure level $L_{pa}$ | dB(A) | 91 | 91 | 91 | 91 |
| Uncertainty $K_{pa}$ | dB(A) | 2 | 2 | 2 | 2 |
| Sound Power Level $L_{wa}$ + Uncertainty $K_{wa}$ | dB(A) | 107 | 107 | 107 | 107 |

| **Type** | | **Senator G2 FI 500-18** | **Senator G2 JX 280-21** | **Senator G2 JX 280-26** | **Senator G2 JX 350-23** |
|---|---|---|---|---|---|
| | | CW7000-18PEG2FI | CW4000-21PEG2JX | CW4000-26PEG2JX | CW5000-23PEG2JX |
| **Motor** | | | | | |
| Petrol Engine | | iGX800, 2 cylinder, 4-stroke OHV | JX750, 2 cylinder, 4-stroke OHV | JX750, 2 cylinder, 4-stroke OHV | JX750, 2 cylinder, 4-stroke OHV |
| Maximum torque at 3600rpm | kW/HP | 18.6 / 24.9 | 17.89 / 24 | 17.89 / 24 | 17.89 / 24 |
| Operating Speed (Under Load) | RPM | 3200 | 3200 | 3200 | 3200 |
| Fuel Tank | L | 25 | 25 | 25 | 25 |
| Fuel | Type | Petrol, unleaded | Petrol, unleaded | Petrol, unleaded | Petrol, unleaded |
| Battery | V / Ah / CCA | 12 / 18 / 310 | 12 / 18 / 310 | 12 / 18 / 310 | 12 / 18 / 310 |
| **Water Connection** | | | | | |
| Max feed temperature | °C / F | 60 / 140 | 60 / 140 | 60 / 140 | 60 / 140 |
| Min feed volume | l/m (l/h) | 19 / 1140 | 22 / 1320 | 27 / 1620 | 24 / 1440 |
| Max feed pressure | PSI (bar) MPa | 101 / (7) / 0.7 | 101 / (7) / 0.7 | 101 / (7) / 0.7 | 101 / (7) / 0.7 |
| Min feed pressure | PSI (bar) MPa | 4.35 / (0.3) / 0.03 | 4.35 / (0.3) / 0.03 | 4.35 / (0.3) / 0.03 | 4.35 / (0.3) / 0.03 |
| Inlet hose diameter (min.) | Inch / mm | 3/4" / 19mm | 3/4" / 19mm | 3/4" / 19mm | 3/4" / 19mm |
| **Performance Data** | | | | | |
| Working pressure | PSI (bar) MPal | 7000 / (480) / 48 | 4060 / (280) / 28 | 4060 / (280) / 28 | 5075 / (350) 35 |
| Max excess operating pressure (safety valve) | PSI (bar) MPa | 8700 / (600) / 60 | 5075 / (350) 35 | 5075 / (350) 35 | 5650 (390) 39 |
| Flow rate | l/m (l/h) | 18 / 1080 | 21 / 1260 | 26 / 1560 | 23 / 1380 |
| Nozzle Size | | 035 | 05 | 065 | 05 |
| Max ambient temperature | °C / F | 40 / 104 | 40 / 104 | 40 / 104 | 40 / 104 |
| Type of protection | IP | IPX5 | IPX5 | IPX5 | IPX5 |
| **Oil** | | | | | |
| Pump oil quantity/type | mL | 1040 / SAE 15W-40 | 1040 / SAE 15W-40 | 1040 / SAE 15W-40 | 1040 / SAE 15W-40 |
| Gear oil quantity/type | mL | 320 / 85W-140 | 320 / 85W-140 | 320 / 85W-140 | 320 / 85W-140 |
| Engine oil quantity/type | mL | 1500 / 10W30 | 1500 / 10W30 | 1500 / 10W30 | 1500 / 10W30 |
| **Dimensions & Weight** | | | | | |
| Length x Width x Height | mm | 860 x 550 x 870 | 860 x 550 x 870 | 860 x 550 x 870 | 860 x 550 x 870 |
| Typical operating weight | kg | 150 | 150 | 150 | 150 |
| **Values Determined as per AS/NZS 60335.2.79** | | | | | |
| Max reaction/recoil force of trigger gun | N | 92 | 82 | 102 | 100 |
| Hand spray gun | $m/s^2$ | - | - | - | - |
| Spray lance | $m/s^2$ | - | - | - | - |
| Uncertainty K | $m/s^2$ | - | - | - | - |
| Sound pressure level $L_{pa}$ | dB(A) | 91 | 91 | 91 | 91 |
| Uncertainty $K_{pa}$ | dB(A) | 2 | 2 | 2 | 2 |
| Sound Power Level $L_{wa}$ + Uncertainty $K_{wa}$ | dB(A) | 107 | 107 | 107 | 107 |

| Type | | Senator G2FI 280-21 | Senator G2FI 280-26 | Senator G2FI 350-23 |
|---|---|---|---|---|
| | | CW4000-21PEG2FI | CW4000-26PEG2FI | CW5000-23PEG2FI |
| **Motor** | | | | |
| Honda Petrol Engine | | iGX700, 2 cylinder, 4-stroke OHV | iGX700, 2 cylinder, 4-stroke OHV | iGX700, 2 cylinder, 4-stroke OHV |
| Maximum torque at 3600rpm | kW/HP | 16.5 / 22.1 | 16.5 / 22.1 | 16.5 / 22.1 |
| Operating Speed | RPM | 3200 | 3200 | 3200 |
| Fuel Tank | L | 25 | 25 | 25 |
| Fuel | Type | Petrol, unleaded | Petrol, unleaded | Petrol, unleaded |
| Battery | V / Ah / CCA | 12 / 18 / 310 | 12 / 18 / 310 | 12 / 18 / 310 |
| **Water Connection** | | | | |
| Max feed temperature | °C / F | 60 / 140 | 60 / 140 | 60 / 140 |
| Min feed volume | l/m (l/h) | 22 / 1320 | 27 / 1620 | 24 / 1440 |
| Max feed pressure | PSI (bar) MPa | 101 / (7) / 0.7 | 101 / (7) / 0.7 | 101 / (7) / 0.7 |
| Min feed pressure | PSI (bar) MPa | 4.35 / (0.3) / 0.03 | 4.35 / (0.3) / 0.03 | 4.35 / (0.3) / 0.03 |
| Inlet hose diameter (min.) | Inch / mm | 3/4" / 19mm | 3/4" / 19mm | 3/4" / 19mm |
| **Performance Data** | | | | |
| Working pressure | PSI (bar) MPa | 4060 / (280) / 28 | 4060 / (280) / 28 | 5075 / (350) 35 |
| Max excess operating pressure (safety valve) | PSI (bar) MPa | 5075 / (350) 35 | 5075 / (350) 35 | 5650 (390) 39 |
| Flow rate | l/m (l/h) | 21 / 1260 | 26 / 1560 | 23 / 1380 |
| Nozzle Size | Oriface | 05 | 065 | 05 |
| Type of protection | IP | IPX5 | IPX5 | IPX5 |
| **Oil** | | | | |
| Pump oil quantity/type | mL | 1040 / SAE 15W-40 | 1040 / SAE 15W-40 | 1040 / SAE 15W-40 |
| Gear oil quantity/type | mL | 320 / 85W-140 | 320 / 85W-140 | 320 / 85W-140 |
| Engine oil quantity/type | mL | 1500 / 10W30 | 1500 / 10W30 | 1500 / 10W30 |
| **Dimensions & Weight** | | | | |
| Length x Width x Height | mm | 860 x 550 x 870 | 860 x 550 x 870 | 860 x 550 x 870 |
| Typical operating weight | kg | 150 | 150 | 150 |
| **Values Determined as per AS/NZS 60335.2.79** | | | | |
| Max reaction/recoil force of trigger gun | N | 82 | 102 | 100 |
| Hand spray gun | $m/s^2$ | - | - | - |
| Spray lance | $m/s^2$ | - | - | - |
| Uncertainty K | $m/s^2$ | - | - | - |
| Sound pressure level $L_{pa}$ | dB(A) | 91 | 91 | 91 |
| Uncertainty $K_{pa}$ | dB(A) | 2 | 2 | 2 |
| Sound Power Level $L_{wa}$ + Uncertainty $K_{wa}$ | dB(A) | 107 | 107 | 107 |

# JX™ Petrol V-Twin JX750 Engine Maintenance Schedule

Always refer to the included manual for more in depth safety, maintenance and operation procedures of the engine.

Always use an approved Jetwave™ servicing agent who uses Genuine parts in order to ensure full 3 year warranty. Service records will need to be provided.

| **REGULAR SERVICE PERIOD**[2]<br><br>Perform at every indicated month or operating hour interval, whichever comes first.<br><br>**ITEM** | | Each Use | First Month or 20 Hrs | Every 3 months or 50 hours | Every 6 Months or 100 Hrs | Every Year or 300 Hrs |
|---|---|---|---|---|---|---|
| **Engine Oil** | Check Level | O | | | | |
| | Change | | O | | O | |
| **Oil Filter** | Replace | Every Year or 200 Hrs | | | | |
| **Cooling Fin** | Check/Clean | Every Year or 100 Hours[1] | | | | |
| **Air Filter** | Check | O | | | | |
| | Clean | | | O[1] | | |
| | Replace | | | | | O[1] |
| **Spark Plug** | Check-Adjust | | | | O | |
| | Replace | | | | | O |
| **Spark arrester** (applicable types) | Clean | | | | O | |
| **Idle Speed** | Check-Adjust | | | | | O |
| **Valve Clarence** | Check-Adjust | | | | | O |
| **Combustion Chamber** | Clean | After Every 500 Hrs | | | | |
| **Fuel Filter** | Check | | | O[1] | | |
| | Replace | | | | O[1] | |
| **Fuel Tube** | Check | Every 2 years (Replace if necessary) | | | | |

1. Service more frequently when used in dusty areas.
2. For commercial use, log hours of operation to determine proper maintenance intervals

# Honda™ Petrol V-Twin GX690 Engine Maintenance Schedule

Based on the 'Maintenance Schedule' in the Honda™ Engine Manual, always refer to the included manual for more in depth safety, maintenance and operation procedures of the engine.

Always use an approved Honda™ servicing agent who uses Genuine Honda parts in order to ensure full 3 year GX Honda warranty. Service records will need to be provided.

| **REGULAR SERVICE PERIOD**[2]<br><br>Perform at every indicated month or operating hour interval, whichever comes first.<br><br>**ITEM** | | Each Use | First Month or 20 Hrs | Every 6 Months or 100 Hrs | Every Year or 300 Hrs | Every 2 Years or 500 Hrs |
|---|---|---|---|---|---|---|
| **Engine Oil** | Check Level | O | | | | |
| | Change | | O | O | | |
| **Engine Oil Filter** | Replace | Every 200 Hrs | | | | |
| **Air Cleaner** | Check | O | | | | |
| | Clean | | | O[1] | | |
| | Replace | | | | | O* |
| **Spark Plug** | Check-Adjust | | | O | | |
| | Replace | | | | O | |
| **Spark arrester** (applicable types) | Clean | | | O | | |
| **Idle Speed** | Check-Adjust | | | | O | |
| **Valve Clarence** | Check-Adjust | | | | O | |
| **Combustion Chamber** | Clean | After Every 1000 Hrs | | | | |
| **Fuel Filter** | Replace | | | | O | |
| **Fuel Tube** | Check | Every 2 years (Replace if necessary) | | | | |

* Replace the paper filter element only.

1. Service more frequently when used in dusty areas.
2. For commercial use, log hours of operation to determine proper maintenance intervals

# Honda™ Petrol V-Twin EFI iGX700 & iGX800 Engine Maintenance Schedule

Based on the 'Maintenance Schedule' in the Honda™ Engine Manual, always refer to the included manual for more in depth safety, maintenance and operation procedures of the engine.

Always use an approved Honda™ servicing agent who uses Genuine Honda parts in order to ensure full 3 year GX Honda warranty. Service records will need to be provided.

| **REGULAR SERVICE PERIOD**[2]<br><br>Perform at every indicated month or operating hour interval, whichever comes first.<br><br>**ITEM** | | Each Use | First Month or 20 Hrs | Every 6 Months or 100 Hrs | Every Year or 300 Hrs | Every 2 Years or 500 Hrs |
|---|---|---|---|---|---|---|
| **Engine Oil** | Check Level | O | | | | |
| | Change | | O | O | | |
| **Engine Oil Filter** | Replace | Every 200 Hrs | | | | |
| **Air Cleaner** | Check | O | | | | |
| | Clean | | | O[1] | | |
| | Replace | | | | | O* |
| **Oil Cooler** (applicable types) | Check | O[3] | | | | |
| **Spark Plug** | Check-Adjust | | | O | | |
| | Replace | | | | O | |
| **Spark arrester** (applicable types) | Clean | | | O | | |
| **Valve Clarence** | Check-Adjust | | | | O | |
| **Combustion Chamber** | Clean | After Every 1000 Hrs | | | | |
| **Fuel Filter** | Replace | | | | O | |
| **Fuel Tube** | Check | Every 2 years (Replace if necessary) | | | | |

* Replace the paper filter element only.

1. Service more frequently when used in dusty areas.
2. For commercial use, log hours of operation to determine proper maintenance intervals.
3. If there are deposits of grass, trash, or other debris, clean regularly.


# Jetwave™ High Pressure Cleaner & Water Jetting System Maintenance Schedule

Refer to the included manual for your high pressure cleaner or water jetting system for safety, pre-inspection, operation, shutdown and more procedures.

Always use an approved Jetwave™ servicing agent who uses Genuine Jetwave parts, to ensure full warranty coverage, service records will need to be provided.

| **REGULAR SERVICE PERIOD**[1]<br>Perform at every indicated month or operating hour interval, whichever comes first.<br>**ITEM** | | Each Use | First 25 Hrs or First Month | First 50 Hrs or First Month | Every 250 Hrs or 6 Months | Every 500 Hrs or 6 Months | Every 1000 Hrs or 1 Year |
|---|---|---|---|---|---|---|---|
| **Pump Oil** | Check Level | O | | | | | |
| | Change | | | O | O | | |
| **Reduction Gearbox** | Check Oil Level | | | O | O | | |
| | Replace | | | | O | | |
| **Pump Conrods**<br>(Torque Spec: 25nM) | Re-tension | | | O | | | |
| **Inlet Water Filter**[2]<br>(Check for build up of debris) | Check | | O | | O | | |
| | Replace | | | | | O | |
| **Hoses**<br>(Check for leaks) | Check | O | | | O | | |
| **Gun & Lance**<br>(Check for leaks) | Check | O | | | | | |
| | Replace | | | | | | O |
| **Fuel Tank Level** | Check | O | | | | | |
| **Unloader Valve**<br>(Check for leaks) | Check | | O | | | | |
| | Replace | | | | | O | |
| **Safety Valve**<br>(Check setting and check for leaks) | Check | | O | | | O | |
| | Replace | | | | | | |
| **Couplings & 0-Rings**<br>(If Leaking or as needed) | Check & Replace | | | | O | | |
| **Pump Seal Kit**[2]<br>(If Leaking or down on pressure) | Replace | | | | | O | |
| **Pump Valve Kit**[2]<br>(If down on pressure) | Replace | | | | | O | |
| **Electrical Connections**<br>(Check for loose connections) | Check | | O | | | | |
| **Battery**<br>(Check for loose connections) | Check | | | | O | | |
| | Replace | Replace as needed | | | | | |

1. For commercial use, log hours of operation to determine proper maintenance intervals
2. Subject to water quality used.




Time interval for checks and replacement listed above are for units subjected to normal operating conditions. Should the unit be subjected to abnormal conditions (eg heavy use, dirty water, extreme temperatures or conditions etc) times should be reduced accordingly.

## Maintenance Log

| Hour Meter Reading | Date | Maintenance Performed | Service Agent |
|---|---|---|---|
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |

# Trouble Shooting

| FAULT | CAUSE | SOLUTION |
|---|---|---|
| **Pump runs normally but pressure does not achieve rated value.** | Pump is sucking air.<br>Valves are worn or dirty.<br>Unloader valve packing worn.<br>Nozzle incorrect or worn.<br>Worn piston packing.<br>Dirty inlet filter. | Check that all hoses and fittings are airtight.<br>Check, clean or replace.<br>Check and replace.<br>Check and replace.<br>Check and replace.<br>Check and clean. |
| **Fluctuating pressure.** | Valves dirty, worn or stuck.<br>Pump sucking air.<br>Worn piston packing.<br>Dirty filter. | Check, clean or replace.<br>Check that all hoses and fittings are airtight.<br>Check and replace.<br>Check and clean. |
| **Presence of water in oil.** | High humidity in air.<br>Piston packing or oil seal worn.<br>Water entering through breather. | Check and change oil twice as often.<br>Check and replace. |
| **Water dripping from pump.** | Piston packing worn.<br>Piston guide o-rings worn. | Check and replace.<br>Check and replace. |
| **Dripping oil.** | Worn oil seals.<br>Oil coming out of breather. | Check and replace.<br>Pump oil level overfull. |
| **Motor does not start when switched on** | Plug not well connected or unreliable power supply.<br>Earth leakage overload. | Check plug, cable and switch.<br><br>Check earth leakage. |

If the unit will not generate the rated pressure or is erratic

- Make sure the engine throttle is properly adjusted to the full open position.
- Turn unloader valve clockwise to increase pressure. Do not force.
- Inspect system for leaks. Use caution during inspection to prevent injury. If leaks are found, shut unit OFF before fixing.
- Ensure the front part lance with nozzle is connected.
- Turn the unit OFF. Check the inlet hose and filter and make sure that they clear of debris.
- Make sure there is adequate water flow to the unit.
- Turn the unit OFF. Remove the nozzle and clean the orifices with the a nozzle cleaning tool.
- Ensure correct nozzle orifice size is used and no signs of excessive wear are evident.
- Activate trigger and run the unit to remove air or debris from the system. Turn the unit OFF before removing or attaching the lance/nozzle.
- Assume a proper operating position.
- Be sure you can control the ON/OFF action of a water control valve. In case of emergency you must be able to turn off water flow.
- Be sure that you have good balance and do not have to overreach.
- You must be able to place one hand on the gun at all times to control and support the lance.

## Notes

## Notes

## Notes




JETWAVE®
GROUP

10-16 Smith Street, Thebarton, 5031
Adelaide, South Australia, AU
+61 8 8371 3599
info@jetwavegroup.com
jetwavegroup.com

jetwavegroup jetwave.group jetwavegroup jetwavegroup jetwave-group

Copyright © 2023 Jetwave® Group Pty Ltd. All Rights Reserved.